

Heat Transfer

20
22

Dr. Yahia
Khraisha

By. Saja
Musleh

* modes of transfer heat :

1. Conduction

$$q = -kA \frac{dT}{dx} \quad \text{Fourier's law}$$

$A \Rightarrow$ Surface area (perpendicular on heat transfer direction)


$\frac{dT}{dx} \Rightarrow$ temperature gradient

$dT \Rightarrow$ driving force

$dx \Rightarrow$ distance (thickness)

Steady state condition : لا يتغير القدر في حالة

* Solid : لا يتغير شيئاً لنقل الحرارة وهذا يحدث في Solid ،
وقد تتغير أيضاً في الغاز والسائل ولكن بشكل (أو زمني) في Fluid في حالة
Stagnant سكون .




$$\text{heat flux} \Rightarrow q'' = \frac{q}{A} = -k \frac{dT}{dx}$$

$$q = \frac{\Delta T}{dx / -kA} = \frac{\Delta T}{R}$$

* هذا الشكل مهم في حال وجود حائط قسوي أو غير متجانس

(composite wall) حائط مركب



$$q = \frac{\Delta T_{\text{overall}}}{\Sigma R}$$



2 Convection

↓

fluid ← انتقال الحرارة من

motion ← حركة السائل في حالة

fluid ← حركة السائل

bulk movement

diffusion

حركة كتلة

انتشار

convection

forcing

natural (free convection)

حركة السوائل دك

حركة السوائل لحرارة

غير طبيعي (باستخدام

والحرارة من غير تدفق

force ← حركة قسري


الانتشار

driven by forced over a surface

drive by density different

 $q = hA\Delta T \Rightarrow$ Newton's law of cooling

$$= \frac{\Delta T}{1/hA} = \frac{\Delta T}{R}$$

 $h \Rightarrow$ heat transfer coefficientThermal boundary layer in
convection heat transfer

* **Heat**: a type of energy 'thermal energy'.

* **Heat transfer**: energy in transit due to temperature difference.

$$q = m C_p \Delta T$$

} type of heat

$q \Rightarrow$ latent heat

change T

phase change & T not change

& phase not change

* **process heat transfer**: A study which focuses on the heat transfer during the physical or chemical process.

for examples:

heating of crude oil in heat exchangers & pipe still heater.

heat exchanger في كبريتات البترول يتم به نقل الحرارة بين السائل والغاز

distillation column يتم به فصل السوائل بواسطة

* **Relation between thermodynamics & heat transfer**:

first law : الطاقة لا تفنى بل تتحول من شكل لآخر

هذا يعني انتقال الحرارة

A hot block	B cold block
-------------------	--------------------

المصدر: سوق النفط (البريد)

المصدر: سوق النفط (البريد)


2nd - mar - 2022

* Temperature gradient:
change of temperature
per distance $\Rightarrow \frac{\Delta T}{\Delta x}$

* Temperature distribution: It is
very important to be known in
order to compute the heat
flow.

* Modes of heat transfer:

- Conduction
- Convection
- Radiation



* process heat transfer: A study which focuses on the
heat transfer during the physical or chemical process.

for examples:

heating of crude oil in heat exchangers & pipe still heater.

heat exchanger في كفاءة لتحويل سائل من سائل آخر

• distillation column يتم فيه فصل السوائل

* Relation between thermodynamics & heat transfer:

- first law : الطاقة لا تفنى بل تتحول من شكل لآخر

وهذا يعني انتقال الحرارة

A	B
hot	cold
block	block

المسافر سوف يفقد طاقته ويأكل (يسهر)
البارد = يكتسب = (يسهر)

- Second law: entropy $\uparrow$ $\Rightarrow$ $S_{final} > S_{initial}$

* Heat transfer on radiation: (vacuum)

$$q = \sigma A T_{ab}^4 \Rightarrow \text{black surface } \underline{E=1}$$

$$q = E \sigma A T_{ab}^4 \Rightarrow \text{actual surface}$$

$T_{ab} \Rightarrow$ above zero (absolute temperature)

convection with ~~air~~ radiation $\downarrow$

E emissivity (0-1)

color of surface

nature of surface

another color

black

0-1

$E=1$

$$q'' = E \sigma (T_1^4 - T_2^4) \Rightarrow \text{difference of temperature}$$

* application of heat transf.

1 Chemical Rxn: exothermic or endothermic, such as combustion.

2 Biological Rxn: like, cooling & freezing of food.

3 Physical change: like, evaporation & Condensation e.g: distillation & Melting &

Hamad Melh

4 Power generation

5 Air conditioning & space heating.

6 Waste Heat recovery

7 Insulation

8 Control of temperature

* General heat transfer and applications :

- Heat rate, pipe lagging & wall insulations

process industry examples of process using heat:

- 1- Steel making
- 2- Chemicals
- 3- non metallic minerals
- 4- food & drink
- 5- paper & printing
- 6- Textiles

* (است) نسج لاستيراد (كافة) كوابل تقوية :

- steel - chemicals

* Comparison between different heat transfer modes:

Conduction	Convection	Radiation
Material continuity	Material continuity	Possible in the absence of material continuity $\Rightarrow$ (vacuum)
$\leftarrow \rightarrow$	$\leftarrow \rightarrow$	$\leftarrow \rightarrow$
Motion not necessary	Depend on fluid motion (fluid dynamic)	Motion not necessary
In solid, liquid & gas	In liq & gas & multiphase mixture	In transparent media, mainly gases

* Thermal conductivity:

قياس الموصلية بالقدرة المارة

for metals $\Rightarrow$ high conductivity

Insulation $\Rightarrow$ low conductivity

gas $\Rightarrow$ low conductivity

- Thermal conductivity function of temperature.

بعض المواد بزيادة T تزداد conductivity، وبعضها لا تتغير مع T

بزيادة الحرارة، بعضها يبقى ثابت بتغير درجة الحرارة.

* Conservation of energy: (first law)

surrounding, S

Control volume
(CV) (system)

Boundary, B

(control surface, CS)

Addition through
inlet $\dot{E}_{in}$

- Accumulation
(storage) $\dot{E}_{st}$
- generation $\dot{E}_g$

loss through
outlet $\dot{E}_{out}$

* energy conservation on a rate basis:

$$\dot{E}_{in} + \dot{E}_g = \dot{E}_{out} + \frac{dE_{st}}{dt} = \dot{E}_{st}$$

units $W = J/s$


Storage



* Inflow & outflow are surface phenomena. ($\dot{E}_{in}$ & $\dot{E}_{out}$)

* generation & accumulation are volumetric phenomena.
($\dot{E}_g$ & $\dot{E}_{acc}$)

* Surface energy balance:
for a control surface



* In general, the determination of h is a very complex problem because h is affected by:

1. The type of flow, laminar, turbulent or transition.
2. The geometry of the body.
3. The physical properties of fluid.
4. The temperature difference.
5. The position along the surface of the body.

تقدير قيمة h بمتوسط، لأن h يتغير مع الموقع على السطح، وبتقدير قيمته في كل نقطة.

mean value over the surface


6. Mechanism is forced or free.



* Example 1 :

The block of 304 stainless steel shown below is well insulated on the front & back surface, & the temperature in the block varies linearly in both x & y direction. find:

- The heat fluxes & heat flows in the x & y -direction.
- " magnitude & direction of the heat flux vector.



* Quantities

quantities

vector

Scalar

magnitude & direction
↓

magnitude only
↓

heat

Temperature

ask : believe & recieve

Soln

heat 1 Area

$$A_x = yz = 10 \times 10^{-2} \times 5 \times 10^{-2} = 0.005 \text{ m}^2$$

$$A_y = xz = 5 \times 10^{-2} \times 5 \times 10^{-2} = 0.0025 \text{ m}^2$$

From table A.1 thermal conductivity of 304 stainless steel is $14.4 \text{ W/m}\cdot\text{K}$

$$\begin{aligned} a) \quad \dot{q}_x &= -k \frac{dT}{dx} \\ &= -14.4 \left(\frac{-5}{5 \times 10^{-2}} \right) = 1440 \text{ W/m}^2 \end{aligned}$$

$$\Delta T_x = \left(\frac{10+0}{2} \right) - \left(\frac{15+5}{2} \right) = -5$$

average of T_2 = average of T_1

$$\begin{aligned} \dot{q}_y &= -k \frac{dT}{dy} \\ &= -14.4 \left(\frac{10}{10 \times 10^{-2}} \right) = -1440 \text{ W/m}^2 \end{aligned}$$

$$\Delta T_y = \left(\frac{10+15}{2} \right) - \left(\frac{5+0}{2} \right) = 10$$

يقل في اتجاه انتقال الحرارة في اتجاه y من T_1 إلى T_2
تزيد في اتجاه انتقال الحرارة في اتجاه x من T_1 إلى T_2

$$\dot{q}_x = \dot{q}_x A = 1440 \frac{\text{W}}{\text{m}^2} \times 0.005 \text{ m}^2 = 7.2 \text{ W}$$

$$\dot{q}_y = \dot{q}_y A = -1440 \frac{\text{W}}{\text{m}^2} \times 0.0025 \text{ m}^2 = -3.6 \text{ W}$$

b)

$$\hat{q} = \hat{q}_x + \hat{q}_y$$


$$\hat{q} = 1440i - 1440j$$

$$\hat{q} = \sqrt{(1440)^2 + (1440)^2} = 2036.5 \text{ W/m}^2$$

magnitude

* direction :

$$\theta = \tan^{-1} \left(\frac{\hat{q}_y}{\hat{q}_x} \right) = \left(\frac{-1440}{1440} \right) = -45$$



* ex: 2

A 5-cm (2 in) schedule 40 steel pipe carries a heat-transfer fluid and is covered with a 2-cm layer of calcium silicate insulation ($k = 0.06 \text{ W/m}\cdot\text{K}$) to reduce the heat loss. The inside and outside pipe diameters are 5.25 cm & 6.03 cm, respectively. If the inner pipe surface is at 150°C & the exterior surface of the insulation is at 25°C , calculate:

- The rate of heat loss per unit length of pipe.
- The temperature of the outer pipe surface.


soln k for insulation = $0.06 \text{ W/m}\cdot\text{K}$

$$r_1 = 0.02625 \text{ m}$$

$$r_2 = 0.03015 \text{ m}$$

$$r_3 = 0.05015 \text{ m}$$

$$k_{\text{steel}} = 43 \text{ W/m}\cdot\text{K} \quad (\text{Table A.1})$$



$$R_1 = \frac{\ln(r_2/r_1)}{2\pi k L}$$

$$= \frac{\ln(0.03015/0.02625)}{2\pi (43)(1)}$$

$$R_1 = 0.00513$$

* critical radius

هو قطر العزلة الحرجة لتقليل

في هذا مقدار الحرارة يفقد

يعني في هذا المقادير يوجد ضياع

في الحرارة حتى مع وجود العزلة

العزلة ولكن في هذا نصل إلى هذا

القطر يقل هذا مقدار الحرارة

ask : before & recieve

$$R_2 = \frac{\ln(r_3/r_2)}{2\pi k}$$

$$= \frac{\ln(0.05015/0.03015)}{2\pi(0.06)} = 1.344723$$

$$q = \frac{\Delta T}{\sum R} = \frac{150 - 25}{1.344723 + 0.000513} = 92.576 \text{ W/m}$$

$$b) \quad q = \frac{\Delta T}{R_i}$$

$$92.576 = \frac{150 - T}{0.000513} \Rightarrow T = 149.95^\circ\text{C}$$

* Resistance of insulation higher than resistance of metal.

لذلك الجهد في المادة العازلة هو فتح فقدان الحرارة.

* ملاحظة أخرى :

في حال q المحسوبة سابقاً بناءً على وجود مقاومة فقط، ولكن

يوجد نوع ثالث من المقاومة وهو مقاومة وجود فراغ بين المادة العازلة

وال pipe، من غير الممكن أن تكون المادة العازلة حاصلة في pipe

بشكل مثالي، لذلك وجود فراغات (يسمى هذا النوع من المقاومة

(thermal contact

contact pressure $\downarrow$ (thermal contact) $\downarrow$ thermal resistance $\uparrow$
thermal resistance, materialized, pipe system $\downarrow$ value

• experimental

: R_{pipe} , $R_{\text{insulation}}$, R_{contact}

$$R = R_{\text{pipe}} + R_{\text{insulation}} + R_{\text{contact}}$$

* Comments:

- It should be pointed out that the calculation in the previous examples tends to overestimate the rate of heat transfer because it assumes that the insulation is in **perfect thermal contact** with the pipe wall.
- Since solid surfaces are not perfectly smooth, there will generally be air gaps between two adjacent solid materials. Since air is a very poor conductor of heat, even a thin layer of air can result in a substantial thermal resistance.



* All modes of heat transfer require the existence of a temperature difference.

* All modes are from the high-temp medium to a lower-temp one.

* In gases & liquids conduction is due to the collision & diffusion of the molecules during their random motion.

* In solids conduction is due to the combination of vibrations of the molecules in a lattice & the energy transport by free electrons.

* Fourier's law:

- Assumptions:

1- Homogeneous medium.

2- One-dimensional heat flow

$$Q = -k A \frac{dT}{dx} \Rightarrow \text{Fourier's law of heat conduction}$$

* when $k \uparrow \Rightarrow$ conduct material

* when $k \downarrow \Rightarrow$ insulator material

$$k \propto \sqrt{T} \Rightarrow k = f(T)$$

* For most gases, at low P
 $k = f(T)$ only

* At high P, close to critical P:

$$k = f(T, P)$$

$$Q = -k A \frac{\Delta T}{\Delta x} \Rightarrow \text{special case from Fourier's law}$$

when $T \Rightarrow$ linear like:

$$T = a + bx$$

$$Q = -k A \frac{dT}{dx}$$

* negative sign $\Rightarrow$ because heat is transferred in the direction of decreasing temperature.

* For liquids & Solids:

- بعض المواد تنزد بزيادة k بزيادة درجة الحرارة.
بعض المواد تنزد بزيادة k بزيادة درجة الحرارة.
بعض المواد تنزد بزيادة k بزيادة درجة الحرارة.
بعض المواد تنزد بزيادة k بزيادة درجة الحرارة.

* Thermal diffusivity:

$$\alpha = \frac{\text{Heat conduct}}{\text{Heat stored}} = \frac{k}{\rho C_p}$$

نسبة الطاقة المنقولة إلى نسبة الطاقة المخزنة

* Newton's law (Convection):

$$Q_{\text{conv}} = h A_s (T_s - T_{\infty})$$

$T_s \Rightarrow T$ of surface

$T_{\infty} \Rightarrow T$ of fluid

* Convection

Nature

forced

↓
difference in
density

↓
external force
applied on fluid

* Conduction $\Rightarrow$ fluid is stagnant

* convection $\Rightarrow$ motion of fluid

* Radiation $\Rightarrow$ تنقل في الفراغ على شكل
electromagnetic waves

* Radiation:


- Is transport of electromagnetic light waves, similar to the transport of light.

- No physical medium is required.

It can take place in a vacuum.


* أمثلة: انتقال الحرارة من الشمس إلى الأرض، انتقال الحرارة من الغازات والصلب.

* examples: Transfer of heat from the sun to the earth.



* ex 3:

A one square meter, 6 mm-thick steel furnace door (conductivity $30 \text{ W/m}\cdot\text{K}$) is insulated on the inside by a 2-cm thick layer of ceramic fiber matting (conductivity $0.05 \text{ W/m}\cdot\text{K}$) and a 10-cm thick layer of refractory brick (conductivity $1.0 \text{ W/m}\cdot\text{K}$). If the temperature of the brick surface in the furnace is 700°C & the outside steel surface of the door is at 50°C , what is the heat loss by conduction through the door? If the maximum temperature of ceramic fiber were limited to 500°C , what would its thickness have to be and what effect would this have on heat loss?

Soln:

$$k = 1.0$$

$$k = 0.05$$

$$k = 30 \text{ W/m}\cdot\text{K}$$

$$R_1 = \frac{\Delta x_1}{kA} = \frac{6 \times 10^{-3}}{30(1)} = 2 \times 10^{-4} \text{ K/W}$$

$$R_2 = \frac{\Delta x_2}{kA} = \frac{2 \times 10^{-2}}{0.05(1)} = 0.4 \text{ K/W}$$

$$R_3 = \frac{\Delta x_3}{kA} = \frac{10 \times 10^{-2}}{1(1)} = 0.1 \text{ K/W}$$

$$q_{loss} = \frac{\Delta T}{ER} = \frac{700 - 50}{(2 \times 10^{-4} + 0.4 + 0.1)} \approx 1300 \text{ W}$$

تتم مقاومة ل steel لدينا صغيرة
مبدأ مقاومة بمقاومة ل insulators

* إذا لم يذكر السؤال قيق
area فنفسه 1 m^2
∴ assume Area = 1 m^2
* قيم resistance للمواد ل
resistance ل insulation
ل metal

* المطلوب رقم 2 : إيجاد thickness لطبقة ل

ceramic في حال فرض ل max temperatur = 500 ، هذا يعني أن
thickness المطلوب لدرجة حرارة غير ل 500°C ، بإيت في درجة حرارة
ل max ل thickness المطلوب

$$q = \frac{\Delta T}{R_2}$$

$$1300 = \frac{T_{max} - 50}{0.4}$$

* T_{max} of ceramic at thickness (0.02m) = 570

نلاحظ أننا أكبر من T_{max} المذكورة في السؤال (500°C) ، يعني بي
أشوف الحد بدرجة حرارة ل thickness

* تغير ل thick يعني
تغير ل resistance وهذا
يعني تغير قيق ل q لنرى
بإيت في قيق ل q بغير
ل ceramic & brick بقرق 500
تتم في ل thick

* إيجاد ل thickness
 $T_{max} = 500$



$$q = \frac{\Delta T \text{ between brick \& ceramic}}{R_3}$$

$$q = \frac{700 - 500}{-1}$$

$$q = 2000 \text{ W}$$

$$q = \frac{\Delta T}{\Delta x / kA}$$

$$T_{\max} = 500^\circ\text{C}$$

$$2000 = \frac{500 - 50}{\Delta x} (0.05 \times 1)$$

$$\Delta x = 1.125 \text{ cm}$$

$$T_{\max} = 500^\circ\text{C} \text{ \& } q_{\text{loss}} = 2000 \text{ W}$$

* Note of ceramic layer:

Max temp $\downarrow$ thick $\downarrow$ $R \downarrow$ $Q \uparrow$



* Extended Surface: (Fins)

تسليخ زائفة

* الهدف من زيادة مساحة السطح وبالتالي زيادة heat rate transfer

$$q = h A \Delta T$$

الهدف زيادة q بزيادة h بزيادة A بزيادة ΔT :


- $h \uparrow \rightarrow q \uparrow$ - ولكن قد يكون قيع h ثابت للمادة المعينة

أي لا يمكن زيادته

- $\Delta T \uparrow \rightarrow q \uparrow$ - قد يكون ΔT ثابت

- $A \uparrow \rightarrow q \uparrow$ - العامل المؤثر لشعاع ، حيث يتم عمل سطح

على سطح ثابت لزيادة A وبالتالي زيادة q .



* heat loss من metal لزيادة q extended surface


* تنتقل الحرارة من سطح A base لبق A fin عن طريق conduction

ثم من سطح A fin بواسطة radiation & convection



energy conservation:

$$q_x = q_{x+dx} + q_{conv} \quad \text{--- 1}$$



* $q_x \Rightarrow$ convection heat transfer

و انتقال الحرارة تم بين سطح و سطح base و سطح P_{fin}

* $q_{x+dx} \Rightarrow$ كمية الحرارة تساوي q_{in} + البقية q




* The convection heat transfer rate may be expressed as:

$$dq_{conv} = h dA_c (T - T_{\infty})$$

* The temperature distribution: Surface area

$$\frac{d^2 T}{dx^2} + \left(\frac{1}{Ac} \frac{dAc}{dx} \right) \frac{dT}{dx} - \left(\frac{1}{Ac} \frac{h}{k} \frac{dAs}{dx} \right) (T - T_{\infty}) = 0 \quad \dots \quad \underline{\underline{1}}$$


if cross section uniform $\Rightarrow$ Delete $\frac{dAc}{dx}$ because $\frac{dAc}{dx} = 0$



$$P = 2w + 2t$$

P_{total}

$$Ac = wt$$



$$P = \pi D$$

P_{total}

$$Ac = \frac{\pi D^2}{4}$$

$$As = \pi D L$$

* Surface area of cylinder = $\pi D L$

= $\pi D x \Rightarrow$ at any point in cylinder

$$A_s = P x$$

$$\frac{dA_s}{dx} = P$$

term $\frac{dA_s}{dx} = P$ في $\frac{d^2 T}{dx^2} - \frac{h}{Ac} \frac{1}{k} P (T - T_{\infty}) = 0$ $\Rightarrow$ $\frac{d^2 T}{dx^2} - \frac{h}{Ac} \frac{1}{k} P (T - T_{\infty}) = 0$ $\Rightarrow$ $\frac{d^2 T}{dx^2} - \frac{h}{Ac} \frac{1}{k} P (T - T_{\infty}) = 0$

$$\frac{d^2 T}{dx^2} - \frac{h}{Ac} \frac{1}{k} P (T - T_{\infty}) = 0 \quad \Rightarrow \quad \frac{d^2 T}{dx^2} - \frac{h}{Ac} \frac{1}{k} P (T - T_{\infty}) = 0$$

excess temperature = $T - T_{\infty} = \theta$

reference (T_{∞} atmosphere)

$$m^2 = \frac{h}{Ac} \frac{P}{k}$$

term $\frac{d^2 \theta}{dx^2} - m^2 \theta = 0$ في $\frac{d^2 \theta}{dx^2} - m^2 \theta = 0$

$$\frac{d^2 \theta}{dx^2} - m^2 \theta = 0 \quad \Rightarrow \quad \frac{d^2 \theta}{dx^2} - m^2 \theta = 0$$


general solution $\theta(x) = C_1 e^{mx} + C_2 e^{-mx}$

$$\theta(x) = C_1 e^{mx} + C_2 e^{-mx}$$

III

Temperature profile

boundary condition in C_1 & C_2 $\frac{dT}{dx} = 0$ at $x = 0$



$$T_b = T_{\text{base}} = \text{given}$$

: T at tip is T_{tip}

1- Convection heat transfer.

~~$T_{\text{tip}} = \text{fixed}$~~

$T_{\text{tip}} = \text{given}$

: boundary cond. $\frac{dT}{dx}$ Surface balance on the tip ρA
 heat transfer = heat transfer
 by conduction by convection

$$E_{\text{in}} = E_{\text{out}}$$

$$-k A_c \frac{dT}{dx} = h A_c (T - T_{\infty})$$

$$-k \frac{d\theta}{dx} = h \theta \quad \Rightarrow \quad \text{boundary condition for convection heat transfer}$$

$$\frac{d\theta}{dx} = \frac{h}{k} \theta$$

θ is $T - T_{\infty}$ at $x = L$

tables ρA fins $\frac{dT}{dx}$

T profile $\Rightarrow$ table 3.4

2 prescribed temperature

المعروف T_{tip} $200 + 25$

$$T_b = \text{fixed}$$

$$T_{tip} = \text{given}$$

3 adiabatic

: surface balance (مع)

$$E_{in} = E_{out}$$

$$-k A_c \frac{dT}{dx} = 0$$

$$\frac{dT}{dx} = 0 \rightarrow \text{is a line}$$

4 Infinite length ($l \rightarrow \infty$)

$$\text{at } l = \infty \quad T = T_{\infty} \quad \theta = T - T_{\infty} = 0$$

T_{∞} same tip 1 value of θ

infinite length 1 $\theta = 0$ is boundary condition 1 $\theta = 0$: $U_{\infty} \rightarrow$

general solution 1 is

$$\theta(x) = C_1 e^{mx} + C_2 e^{-mx}$$

soln

$$\text{at } x=0$$

$$T = T_b$$

$$\theta(0) = T_b - T_{\infty} = \theta_b$$

$$\theta(0) = C_1 e^0 + C_2 e^0$$

$$\theta(0) = C_1 + C_2 = \theta_b$$

B.C 2

at $x = L \rightarrow \infty$ $T = T_{\infty}$ $\theta = 0 = T_{\infty} - T_{\infty}$

$$0 = C_1 e^{mx} + C_2 \frac{-mx}{e}$$

↑
0 p 2 p

$$\therefore C_1 = 0$$

نعم في مابعد

$$\theta_b = C_1 + C_2$$

$$\boxed{\theta_b = C_2}$$

general solution في 1

$$\theta(x) = \theta_b e^{-mx}$$

$$\theta(x) = e^{-mx}$$

θ_b

الها حيدل جاهز لداي لستقا


$$\Rightarrow \frac{T - T_{\infty}}{T_b - T_{\infty}} = e^{-mx} \Rightarrow \text{temperature distribution}$$

table 3.4

← : fine 1 و 2

$q_p = q_b$ (نظرة)

$$q_{in} = q_{out}$$



q_b = heat transfer by conduction between base & fin

q_p = heat transfer from fin

⇒

table 3.4 ← و 2

q_p & T distribution

$$q_b = q_f = -k_A \frac{dT}{dx}$$

$$q_b = q_f = -k A \frac{d\theta}{dx} \bigg|_{x=0}$$

$$q_f = -kA \frac{d\theta_b}{dx} e^{-mx}$$

$$q_p = k A m \theta b e^{-mx} \quad | \quad x=0$$

~~9* 91 m~~

$$\theta_x = \theta_b e^{-mx}$$

at base

$$q_p = k A \theta_b \left(\frac{k_p}{k A_c} \right)^{\frac{1}{2}}$$

$$q_f = \sqrt{k A_c h P} \theta_b$$

* Fine performance: سبب كفاءة lines في تقاطع

- Fine effectiveness $\Leftarrow$ ρ_{eff}

ϵ : It is defined as the ratio of the fin heat transfer rate to the heat transfer rate that would exist without the fin.

$$\underline{\epsilon = q \cdot f}$$

$$\underline{h_{Ac,b} \theta_b}$$

A_c is $\Rightarrow$ Is the fine cross-sectional area at the base

The area of the triangle is $\frac{1}{2} \times \text{base} \times \text{height}$.
 The area of the triangle is $\frac{1}{2} \times \text{base} \times \text{height}$.
 The area of the triangle is $\frac{1}{2} \times \text{base} \times \text{height}$.

~~مسألة 30 قاسية 1 Fine 1 حصة 1~~

base

* مثال لایجاد ع :

* Assume infinite length:

$$q_f = \mu = \sqrt{k_P k_{AC} \theta_b} \quad l \rightarrow \infty$$

$$\epsilon = \frac{\sqrt{k P k A_c}}{h A_{c,b}} = \left(\frac{k P}{h A_c} \right)^{\frac{1}{2}}$$

- بنیادی قیاد کا تعداد 6 ہے۔ زیادہ قیاد k پر metal

- کلمہ قلت کا تنزاع ہے

- کلید زار نسبت $\frac{P}{A_c}$ تیز زار قیاس ϵ ، تیزید $\frac{P}{A_c}$ بنیاده $\frac{P}{A_c}$ و $\frac{P}{A_c}$ و تقیص $\frac{P}{A_c}$

* Notes:

1- k should be as high as possible. (copper, aluminium & iron). (metals)

2- PI_{Ac} should be as high as possible. (Thin plate fins & slender pin fins).

3- Most effective in applications where h is low. (Use of fins justified if when the medium is gas & heat transfer is by natural convection).

4 - max heat rate could be achieved by using very long fins. However, it is not reasonable to use very long fins to achieve near max. heat transfer.

ورکھ زیادہ اچھل بیشکی کبیر
غیر عملی، وسوق رخص ایسی طویل
معیہ، بعد ہذا اچھل نہ تنقیر
قیمت الجدارۃ (تثبت) کے تثبت
قیمت ۱۔ ۶۔

* ضرورت زیادہ قوی ہے

زيادة النسبة $\frac{P}{A_c}$ لتبقى T_{eq}

بنیاد

length of pins

* How to obtain a reasonable length?

بافتراض أن at length $\rightarrow \infty$ $\rightarrow$ درجة حرارة الطرف $\rightarrow$ درجة حرارة الوسط

مساحة لدرجة حرارة الجدار المحيط ، هذا يعني أن لم تنتج حرارة

adiabatic tip fin

← l fin
tip of

q_f at adiabatic $\rightarrow$ في الطرف

$$q_f = \sqrt{h P k A_c} \theta_b \tanh ml$$

Assume 98% of the max possible heat transfer

$$q_{f, \max} = M = (h P k A_c)^{\frac{1}{2}} \theta_b$$

$$0.98 q_{f, \max} = q_{f, \text{adiabatic}}$$

$$0.98 (h P k A_c)^{\frac{1}{2}} \theta_b = (h P k A_c)^{\frac{1}{2}} \theta_b \tanh ml$$

$$\Rightarrow ml = 2.3$$

* conclusion :

It is more suitable to use fin with $l = 2.3 / m$ which

yield 98% max possible heat transfer rather than to use

$l > 2.3 / m$ or infinite length.

Conclusion

If $\varepsilon > 1$ adding fins enhance heat transfer

$\varepsilon = 1$ adding fins has no effect


$\varepsilon < 1$ adding fins decrease heat transfer
(as insulator)

Problem 1 _ Fins

infinite length

A **very long rod** 5 mm in diameter has one end maintained at 100 °C. The surface of the rod is exposed to ambient air at 25 °C with a convection heat transfer coefficient of 100 W/m² K.

1. **Determine the temperature distributions along rods constructed from pure copper, 2024 aluminum alloy, and type AISI 316 stainless steel. What are the corresponding heat losses from the rods?**
2. **Estimate how long the rods must be for the assumption of *infinite length* to yield an accurate estimate of the heat loss.**



very long = infinite length

soln : rod of 100 mm

* pure copper & 2024 aluminum alloy & AISI 316 stainless steel

1. Determine the Temperature distribution & heat losses from the rods.

- Temperature distribution from table 3.4 for infinite length:

$$\frac{\theta}{\theta_b} = e^{-mx}$$

$$\frac{T - T_\infty}{T_b - T_\infty} = e^{-mx}$$

$$T = e^{-mx} (T_b - T_\infty) + T_\infty$$

- heat losses from table 3.4 for infinite length:

$$q = h A_c \theta_b$$

جميع الخواص ثابتة لجميع المواد و rods باعد
قياس ك فتن بافتدني ا metals ، لذل يتم حساب

* k (pure copper) ⇒

q لكل metal

interpolation A.1

$$\frac{393 - 413}{400 - 200} = \frac{x - 413}{335 - 200}$$

حسب قيمه k عند درجه حرارة 335 K

$$\frac{100 + 25}{2} = 62.5^\circ\text{C} \approx 335\text{ K}$$

$$k_{\text{copper}} = 398\text{ W/m}\cdot\text{K}$$

$$P = \pi D = 0.0157\text{ m}$$

$$A_c = \pi \frac{D^2}{4} = 0.0001963\text{ m}^2$$

$$q_{\text{copper heat transfer}} = \sqrt{100 \times 0.0157 \times 398 \times 0.0001963} (100 - 25)$$

$$\textcircled{1} q_{\text{copper}} = 8.3\text{ W}$$

$$\textcircled{2} q_{\text{2024 aluminum}} = \sqrt{100 \times 0.0157 \times 180 \times 0.0001963} (100 - 25) = 5.6\text{ W}$$

$$\textcircled{3} q_{\text{316 stainless steel}} = \sqrt{100 \times 0.0157 \times 14 \times 0.0001963} (100 - 25) = 1.6\text{ W}$$

2 estimate how long the rods must be for the assumption of infinite length?

$$\cdot q q \quad q_{p \max} = q_p \text{ adiabatic}$$

$$\cdot q q \quad (h P k A_c)^{\frac{1}{2}} \theta_b = (h P k A_c)^{\frac{1}{2}} \theta_b \tanh mL$$

$$\cdot q q = \tanh mL$$

$$\cdot q q = \frac{e^{mL} - e^{-mL}}{e^{mL} + e^{-mL}}$$

$$1 + \cdot q q = (e^{mL})^2 (1 - \cdot q q)$$

$$1 - \cdot q q = e^{-2mL} \quad (\cdot 01)$$

$$199 = e^{2mL}$$

$$\ln 199 = 2mL \ln e$$

$$5.2933 = 2mL$$

$$\boxed{mL = 2.65}$$

$$L \text{ for copper} = 2.65 \left(\frac{k A_c}{h P} \right)^{\frac{1}{2}} = 2.65 \left(\frac{398 \times 0.0001463}{100 \times 0.0157} \right)^{\frac{1}{2}} = \underline{\underline{0.19 \text{ m}}}$$

$$L \text{ for aluminium} = 2.65 \left(\frac{180 \times 0.0001463}{100 \times 0.0157} \right)^{\frac{1}{2}} = \underline{\underline{0.13 \text{ m}}}$$

$$L \text{ for stainless steel} = 2.65 \left(\frac{14 \times 0.0001463}{100 \times 0.0157} \right)^{\frac{1}{2}} = \underline{\underline{0.04 \text{ m}}}$$

1. $x = \tanh y$
i.e. $\tanh$

$$x = \tanh y$$

$$x = \frac{e^y - e^{-y}}{e^y + e^{-y}}$$

$$1+x = (e^y)^2 (1-x)$$




Efficiency of Fins, η_f

- Definition: $\eta_f = \frac{q_f}{q_{\max}} = \frac{q_f}{hA_f\theta_b}$ بیتم قدیرہ سے
tables

where A_f is the surface area of the fin.

Look! Max heat transfer takes place when the surface temp. of the fin equals the base temperature.



Assume adiabatic tip fin, the previous eq. becomes

$$\eta_f = \frac{M \tanh mL}{hPL\theta_b} = \frac{\sqrt{hPkA_c}\theta_b \tanh mL}{hPL\theta_b} = \frac{\tanh mL}{mL}$$

$$\eta_f \rightarrow \max \text{ as } L \rightarrow 0 ; \eta_f \rightarrow \min \text{ as } L \rightarrow \infty$$

$n \uparrow$ when $L \downarrow$
الکس دیر

$$q_{\max} \Rightarrow$$

at un. forme I g. l. m. n.

وبالتالي $T - T_{\infty}$ أكبر من

الـ actual لا actual دیکھو فی نقضہ بدرجہ کبریاۃ مع x

Approximation for heat transfer from a convection tip fin

- The heat transfer, q_f , of a convection tip fin; eq. 3.72, can be calculated via using adiabatic tip eq. 3.76 by making a correction for the length; $L_c = L + (t/2)$ for a rectangular fin and $L_c = L + (D/4)$ for a pin fin.
- Therefore, with tip convection, the fin heat transfer rate may be approximated as

$$q_f = M \tanh m L_c$$

where $M = \sqrt{hPkA_c \theta_b}$

$$\text{and } \eta_f = \frac{\tanh mL_c}{mL_c}$$

correction for the length


۲۰۴۳ و قیام ۹۹ تا ۱۰۰۰

معادلات ۱. adiabatic
* عندنا بعض ۲. في معادلات q adiabatic

2. $\leftarrow$ 100's

SPECIAL NOTE

Corrected fin length



Corrected fin length:

$$L_c = L + \frac{A_c}{P} = L + \frac{\frac{\pi D^2}{4}}{\pi D}$$

Multiplying the relation above by the perimeter gives $L_c = L + \frac{D}{4}$

$$A_{\text{corrected}} = A_{\text{fin (lateral)}} + A_{\text{tip}}$$

$$L_{c, \text{rectangular fin}} = L + \frac{t}{2}$$

$$L_{c, \text{cylindrical fin}} = L + \frac{D}{4}$$

Corrected fin length L_c is defined such that heat transfer from a fin of length L_c with insulated tip is equal to heat transfer from the actual fin of length L with convection at the fin tip.

Notes

1. Errors associated with the approximation are negligible if (ht/k) or $(hD/2k) \leq 0.0625$

2. If $w \gg t$ for rectangular fin

$$\therefore P \approx 2w$$

$$mL_c = \left(\frac{hp}{kA_c}\right)^{1/2} L_c = \left(\frac{h2w}{kwt}\right)^{1/2} L_c = \left(\frac{2h}{kt}\right)^{1/2} L_c$$

Introducing a corrected fin profile area, $A_p = L_c t$

$$\therefore mL_c = \left(\frac{2h}{kt}\right)^{1/2} \left(\frac{L_c}{L_c}\right)^{1/2} L_c = \left(\frac{2h}{ktL_c}\right)^{1/2} L_c^{3/2} = \left(\frac{2h}{kA_p}\right)^{1/2} L_c^{3/2}$$

See Figure 3.18 and figure 3.19 $\{\eta \text{ vis } (\frac{h}{kA_p})^{1/2} L_c^{3/2}\}$

Fig. is developed from this eq. $\eta_f = \frac{\tanh mL_c}{mL_c}$




FIGURE 3.18 Efficiency of straight fins (rectangular, triangular, and parabolic profiles).




FIGURE 3.19 Efficiency of annular fins of rectangular profile.


TABLE 3.5 E

Straight Fins**Rectangular^a**

$$A_f = 2wL_c$$

$$L_c = L + (t/2)$$

$$A_p = tL$$




$$\eta_f = \frac{\tanh mL_c}{mL_c} \quad (3.89)$$

Triangular^a

$$A_f = 2w[L^2 + (t/2)^2]^{1/2}$$

$$A_p = (t/2)L$$




$$\eta_f = \frac{1}{mL} \frac{I_1(2mL)}{I_0(2mL)} \quad (3.93)$$

Parabolic^a

$$A_f = w[C_1L + (L^2h)\ln(t/L + C_1)]$$

$$C_1 = [1 + (t/L)^2]^{1/2}$$

$$A_p = (t/3)L$$




$$\eta_f = \frac{2}{[4(mL)^2 + 1]^{1/2} + 1} \quad (3.94)$$

Circular Fin**Rectangular^a**

$$A_f = 2\pi(r_{2c}^2 - r_1^2)$$

$$r_{2c} = r_2 + (t/2)$$

$$V = \pi(r_2^2 - r_1^2)t$$



$$\eta_f = C_2 \frac{K_1(mr_1)I_1(mr_{2c}) - I_1(mr_1)K_1(mr_{2c})}{I_0(mr_1)K_1(mr_{2c}) + K_0(mr_1)I_1(mr_{2c})} \quad (3.91)$$


$$C_2 = \frac{(2r_1/m)}{(r_{2c}^2 - r_1^2)}$$

Pin Fins**Rectangular^b**

$$A_f = \pi DL_c$$

$$L_c = L + (D/4)$$

$$V = (\pi D^2/4)L$$




$$\eta_f = \frac{\tanh mL_c}{mL_c} \quad (3.95)$$

Triangular^b


$$A_f = \frac{\pi D}{2} [L^2 + (D/2)^2]^{1/2}$$

$$V = (\pi/12)D^2L$$



$$\eta_f = \frac{2}{mL} \frac{I_2(2mL)}{I_1(2mL)} \quad (3.96)$$


Problem 2 Fin




لوفتة 1 annular دے بڑھنے شے مستطیل

An annular aluminum fin of **rectangular profile** is attached to a circular tube having an outside diameter of 25 mm and a surface temperature of 250°C . The fin is 1 mm thick and 10 mm long, and the temperature and the convection coefficient associated with the adjoining fluid are 25°C and $25 \text{ W/m}^2 \cdot \text{K}$, respectively.


(a) What is the heat loss per fin?



Subject : _____



circular tube



annular fin

الشيء الذي نحتاجه

= thickness

width of rectangular

base of tube

$T_b = 250^\circ\text{C}$

length of annular =
length of rectangular

Chart (3.19) is used to find the maximum temperature T_{max} on the x-axis

$$x\text{-axis} \Rightarrow L_c^{3/2} \left(\frac{h}{k A_p} \right)^{1/2}$$

$$L_c = L + \frac{t}{2} = 10 \times 10^{-3} + \frac{1 \times 10^{-3}}{2} = 10.5 \times 10^{-3} \text{ m}$$

$$A_p = L_c t = (10.5 \times 10^{-3})^2 (1 \times 10^{-3}) = 10.5 \times 10^{-6} \text{ m}^2$$

$$k = 240 \text{ W/m}\cdot\text{K}$$

$$h = 25 \text{ W/m}^2\cdot\text{K}$$

Subject : _____

$$x\text{-axis} \Rightarrow r_c^{\frac{3}{2}} \left(\frac{h}{k A_p} \right)^{\frac{1}{2}}$$

$$= (10.5 \times 10^{-3})^{\frac{3}{2}} \left(\frac{25}{240 \times 10.5 \times 10^{-6}} \right)^{\frac{1}{2}}$$

$$= 1$$

المعرفة أي المسافات بين السطحين r_{2c}/r_1

$$r_2 = r_1 + l$$

$$r_2 = (12.5 + 10) \times 10^{-3} = 22.5 \times 10^{-3} \text{ m}$$

$$r_{2c} = r_2 + \frac{l}{2}$$

$$r_{2c} = 22.5 \times 10^{-3} + \frac{1 \times 10^{-3}}{2} = 23 \times 10^{-3} \text{ m}$$

$$\frac{r_{2c}}{r_1} = \frac{23 \times 10^{-3}}{12.5 \times 10^{-3}} = 1.84$$

$$\eta = 0.97$$

من chart في الجدول

$$q_p = \eta q_{\max}$$

$$= \eta h \theta_b$$

$$= 0.97 (25)$$

$$= \eta h A_p \theta_b$$

$$= \eta h 2\pi (r_{2c}^2 - r_1^2) \theta_b$$

$$= 0.97 (25) (2\pi) (23^2 - 12.5^2) \times 10^{-6} (250 - 25)$$

$$q_p = 12.8 \text{ W}$$

سطحين 2 surface of annular θ_b و A_p المساحة

المساحة (πr^2) المساحة θ_b المساحة θ_b

المساحة

ask : & recieve

S T A R S N O T E B O O K

* Forced convection:


- In external flow

- In pipes & Ducts

Newton's law $\leftarrow$ Forced convection

* forced convection in external flow:

plate surface



? flat surface

1. heat transfer (hydrodynamic)



2. momentum transfer (velocity)

3. mass


* 2 boundary layer $\leftarrow$ plate

fluid

(fluid)



* boundary layer : هو المسافة التي يحدث فيها تغير (T or ν)



* يستخدم 3 معادلات بمتغير واحد و كل واحد له علاقة بال Correlation ،
التالي ←

$$Nu = \underbrace{C}_{\text{constant}} Re^m Pr^n \underbrace{(F)}_{\text{correction factor}}$$

$F = \left(\frac{\mu}{\mu_s} \right)^{0.14}$ يتعلق بـ viscosity ويعتمد على نوع fluid
وقد تسمى قوة F إلى 1

* التجربة ، الملاحظة ، التنبؤ ،
على Correlation ،
من التجربة ، التجربة ←
(empirical)

* المعادلات المستخدمة
في الحساب على Nu :
- momentum balance
- Temperature balance
- mass balance

$$Nu = \frac{hL}{k}$$

* factors effect^{pp} on h value:

2. Type of flow

Turbulent

3 geometry

- The heat transfer coefficient is obtained from the following correlations:

$$Na = \underline{hL}$$

2.

$$R_e = \frac{R_L \parallel r_o}{\mu}$$

قد زکەر length ک وقد زکەر

Phase 1 was diameter

It the ratio of convective to conductive heat transfer at a boundary in a fluid.

- Reynolds number: It is the ratio of inertial forces to viscous forces within a fluid.

5th properties of design is simplicity

* In these equations all fluid properties are evaluated at the film temperature - T_f , defined by:

$$T_f = \frac{T_\infty + T_s}{2}$$

لنذكر أهم خصائص المعادلات التي تحتوي على T أو TP ، لنذكر لنذكر
اختصاراً $properties$ المستخدمة في المعادلات بشأن T في الصورة
في المعادلات ، وإذا كانت T باهتة فجميع $\lambda \in$

properties at T_{∞}

properties at TP $\leftarrow$ + $\frac{g_{12}}{2}$ in b TP in c is 1/2 in

* لما اُشوق معارف قَتَوِي على تار ليلتي اعلم

- Hence, the rate of heat transfer between the plate & the fluid is given by:

$$q_v = hA (T - T_\infty)$$

* گندیت :

بہی اس سب قید ۹۱ :

اول شي نيجي Reynolds number check. بعد نفع لثقلو، بعد

2/1 حسب قیود h و Na و اگر این دو درجه آزادی استفاده

في المعادلات فوقكم (T_{∞} or T_P) لدرجة الحرارة فتلق من T إلى الوسط

$q = hA(T - T_{\infty})$ ← Newton's law ³ قانون دلف

* معادلات Nu موجوده :-

tables , کتابچه ها

با استفاده از regime , یعنی

محدوده Re به regime تم دارد

معادلات Nu به کار می آید ، تم به حسب قیاس


h به Nu تم دارد طبق h Newton's law

و حسب قیاس q

* $\dot{m}$ و T و $fluid$ در $pipe$ و $یک$ $نقطه$:

1 = Entrance (developed)

2 = Fully developed




velocity profile

is changing

velocity profile

doesn't change

Turbulent & laminar $\rightarrow$ Re



* Derivation of Nu (Theory) for Laminar


في حساب Nu .

* Nu (empirical) for turbulent

turbulent

* Flow past cylinder:

المعادلة التي كانت مستخدمة في حساب Nu في مسطح في مسطح
في مسطح Flat plate ، ومع ذلك في الأسطوانة cylinder
وتم الحصول على Nu من التجربة.



* at stagnation point:

$$v = 0 \Rightarrow k = 0 \quad \& \quad P_{\max}$$

* at point z :

$$P = 0 \quad \& \quad v_{\max} \Rightarrow k_{\max}$$



Turbulent or laminar design

انتقار التيارات

Turbulent $\Rightarrow$ Re أكبر Nu أكبر

$$\therefore h \uparrow$$

$$Nu = C Re^m Pr^n (F)$$

$$Re \uparrow \quad Nu \uparrow$$

$$Nu = \frac{hL}{k}$$

$$Nu \uparrow \quad h \uparrow$$

$$q = hA \Delta T$$

$$h \uparrow \quad q \uparrow$$

$$Pr_s \Rightarrow \text{at } T_s$$

يعني Pr على سطح
surface

$$Re_D \Rightarrow \frac{\rho u_{\infty} D}{\mu}$$

= cylinder

$$Re_L \Rightarrow \frac{\rho u_{\infty} L}{\mu}$$

= plate

خواص المواد التي نعبرها


وذلك بسبب أخطاء في

- properties & experimental
& human error.



* Internal flow : Laminar & Turbulent regimes

- Laminar hydrodynamic B.L development in a circular tube.



Fluid 1

Fluid 2

pipe 1

thickness boundary layer

(parabolic velocity)

في داخل البنية السطحية

(الحدود)

* Notes: In general, the entrance length, $x_h = f(Re)$

$\Delta (x/D)_{lam} = 0.05 Re \Rightarrow$ entrance length for laminar flow

- A force balance on a differential fluid element gives a parabolic velocity for fully developed laminar flow.

$$u(r) = \frac{-1}{4\mu} \left(\frac{dp}{dx} \right) r_0^2 \left[1 - \left(\frac{r}{r_0} \right)^2 \right]$$

drop pressure

$$u_m = -r_0^2 \frac{dp}{dx}$$


where:

$u_m \Rightarrow$ mean velocity

$$\frac{u_r}{u_m} = 2 \left[1 - \left(\frac{r}{r_0} \right)^2 \right]$$

u_{max} at $r=0 \Rightarrow$ initial $\vec{u}$

- Turbulent hydrodynamic B.L in a circular tube:



* Notes

- Unlike laminar flow, the entrance length, x_n is not function in Re_D .

- Experiments have shown that:

$$10 < \left(\frac{x_n}{D} \right) < 60$$

أي $20, 30$ إلى $(10-60)$ من $\frac{x_n}{D}$ يعني


x_n من 10 إلى 60

- velocity profile for fully developed turbulent flow is not parabolic & is flatter due to turbulent mixing in the radial direction.

velocity profile is turbulent & is flat due to mixing

- For simplicity, assume that fully developed occurs at $(x/D) > 10$

* Thermal B-L development in a heated circular tube:



$\frac{P^T}{T_s}$ is the position of the thermal entrance region

Notes:

- For laminar flow, the thermal entrance length, x_t :

$$x_t = f(Re, Pr)$$


$$\frac{x_t}{D} = 0.05 Re Pr$$

- For turbulent, $x_t \neq f(Re, Pr) \sim (x_t/D) > 10$ or

assume $(x_t/D) = 10$

17-mar

* Correlations for forced convection in pipes and Ducts:



Figure

* need to find T_{b1} & T_{b2} for pipes

T_{in} & T_{out} (fluid)

T_{bulk} or T_b (fluid)

$T_{average}$

$T(r)$ (fluid)

$T(r)$

3T is is - pipe 1 is T_{b1} & T_{b2} isothermal surface 1 is T_{b1} & T_{b2}

$$T_{w1} = T_{w2} \text{ (fluid)}$$

4T is T_{b1} & T_{b2} (fluid)

$$T_{w1} = T_{w2} \text{ (fluid)}$$

- Correlations are given for each of the three flow regimes: turbulent, transition & laminar.

The physical situation described by the correlations is given in Figure 1. Fluid enters the pipe at an average temperature T_{b1} & leaves at an average temperature T_{b2} (T_b stands for bulk temperature. It is the fluid temperature averaged over the flow area).

The pipe wall temperature is T_{w1} at the entrance & T_{w2} at the exit.

regime 1. is with its correlations 2. is 2 *

* Turbulent Region :

with respect to heat transfer in circular pipes, fully developed turbulent flow is achieved at a Reynolds number of approximate 10^4 . For this flow regime $Re \geq 10^4$ the following correlation is widely used:

$$Nu = 0.027 Re^{0.8} Pr^{1/3} \left(\mu / \mu_w \right)^{0.14} \Rightarrow \text{Sieder - Tate correlation}$$

T & μ fraction 1 is

where:

- $Nu \equiv$ Nusselt Number $\equiv hD/k$
- $Re \equiv$ Reynolds Number $\equiv D \rho v / \mu$
- $Pr \equiv$ Prandtl number $\equiv C_p \mu / k$
- $D \equiv$ inside pipe diameter
- $v \equiv$ average fluid velocity
- $C_p, \mu, \rho, k =$ fluid properties evaluated at the average bulk fluid temperature
- $\mu_w \equiv$ fluid viscosity evaluated at average wall temperature.

average bulk fluid temperature & average wall temperature.

physical properties
average bulk fluid
temperature.
at average wall temperature

* The average bulk fluid temperature & average wall temperature are given by:

$$T_{b,avg} = \frac{T_{b1} + T_{b2}}{2}$$

$$T_{w,avg} = \frac{T_{w1} + T_{w2}}{2}$$

* Note:

- The equation is frequently written with the coefficient 0.027 replaced by 0.023. The latter value gives a somewhat more conservative estimate for the heat-transfer coefficient, which is often desirable for design purpose.

$$Nu = 0.027 Re^{1/3} Pr^{1/3} \left(\frac{\mu}{\mu_w} \right)^{1/4}$$

0.027 replaced by 0.023

design ask

- The previous correlation is valid for fluids with Prandtl numbers between 0.5 and 17000 & for pipes with $L/D > 10$.

- For short pipes with $10 < L/D < 60$, the right-hand side of the equation is often multiplied by the factor $[1 + (D/L)^{2/3}]$ to correct for entrance & exit effects

$$Nu = 0.027 Re^{.8} Pr^{1/3} (\mu/\mu_w)^{.14} [1 + (D/L)^{2/3}]$$

في حالة short pipes إذا كان $10 \leq L/D \leq 60$ ، تأثير entrance (developed) ، في Nu ،
 correction factor $\left[1 + (D/L)^{2/3} \right]$

*Notes:

- The correlation is generally accurate to within $\pm 20\%$ to $\pm 40\%$. It is more accurate for fluids with low to moderate Prandtl numbers ($0.5 \leq Pr \leq 100$), which includes all gases & low viscosity process liquids such as water, organic solvents, light hydrocarbons.

* ρ is a fluid property & P_r is a fluid property & ρ is a fluid property
 & accurate data $\leftarrow$ correlations
 accurate data $\leftarrow$ correlations

- It is less accurate for highly viscous liquids, which have correspondingly large Prandtl numbers.

$$\mu \downarrow \quad Pr \downarrow$$

accurate data from
correlations $\uparrow$

$$Pr = C_p \mu / k$$

$$\Rightarrow \mu \uparrow \quad Pr \uparrow$$

accurate data from
correlations $\downarrow$



* For laminar flow in circular pipes ($Re < 2100$), the Sieder-Tate correlation takes the form:

$$Nu = 1.86 [Re Pr D/L]^{1/3} (\mu/\mu_w)^{0.14}$$

• This equation is valid for $0.5 < Pr < 17000$ and $[Re Pr D/L]^{1/3} (\mu/\mu_w)^{0.14} > 2$, and is generally accurate to within $\pm 25\%$.

• If $[Re Pr D/L]^{1/3} (\mu/\mu_w)^{0.14} < 2$, correction factor is 1.5!


• For $[Re Pr D/L]^{1/3} (\mu/\mu_w)^{0.14} < 2$, the Nusselt number should be set to 3.66, which is the theoretical value for laminar flow in an infinitely long pipe with constant wall temperature.

• If $[Re Pr D/L]^{1/3} (\mu/\mu_w)^{0.14} < 2$, correction factor is 1.5!

$$\text{if } Nu = 3.66$$

• Fluid properties are evaluated at $T_{b,ave}$, except for μ_w , which is evaluated at $T_{w,ave}$.

• Also, at low Reynolds numbers heat transfer by natural convection can be significant (see Natural convection), and this effect is not accounted for in the Sieder-Tate correlation.



إذا طُبِّقَت correlations
السابقة وكان Re قليل
فإن تعطيني نتائج h
المسيطر أكثر هو Natural

convection

Natural	forced
↓	↓
$q = \frac{\Delta T}{1/Ah}$	حسبي h قيم
	--- Nu, Pr

when Re is low :

نظروا معادلات Natural



* For transition Region:

- For flow in the transition region ($2100 < Re < 10^4$), the Hausen equation correlation

$$Nu = 0.186 [Re^{2/3} - 125] Pr^{1/3}$$

- Heat transfer calculations in the transition region are subject to a higher degree of uncertainty than those in the laminar & fully developed turbulent regimes.

- Although industrial equipment is sometimes designed to operate in the transition region, it is generally recommended to avoid working in this flow regime if possible.

- An alternative equation for the transition & turbulent regimes has been proposed by Gnielinski:

$$Nu_D = \frac{(f/8)(Re_D - 1000) Pr}{1 + 12.7 (f/8)^{1/2} (Pr^{2/3} - 1)} \left[1 + \left(\frac{Pr}{Pr_s}\right)^{2/3} \right]$$

• $6 < Pr < 2000$
 $Re > 2300$

$f \Rightarrow$ Darcy friction factor:

$$f = (0.782 \ln Re - 1.51)^{-2}$$

approximation of Colebrook equation

* $f \Rightarrow$ friction factor

* f is a function of Re & Pr

ask: believe & recieve

* ducts and conduits with non-circular cross-sections.

The pipe non circular

circular, في دية، كات دية فيق دية، لست

D equivalent في دية، لست في دية، لست D

$$D_{eq} = 4 \times \text{hydraulic radius} = 4 \times \text{flow area}$$

التي دية ← wetted parameter


- This approximation generally gives reliable results for turbulent flow. However, it is not recommended for laminar flow.

* لست لست شيو دية

laminar flow in non-circular ducts is flow in the annulus of a double pipe heat exchanger.

- for laminar annular flow, the following equation given by Gnielinski is recommended:

$$Nu = 3.66 + 1.2 (D_2/D_1)^{0.8} + 0.49 [1 + 0.14 (D_2/D_1)^{0.5}] [Re Pr D_e/L]^{0.8} \\ 1 + 0.117 [Re Pr D_e/L]^{0.467}$$



where:

D_1 : out side diameter of inner

D_2 : inside " " outer

D_e : equivalent diameter = $D_2 - D_1$



$$D_h = D_e = \frac{4A}{P}$$

$$D_h = \frac{\pi (D_2^2 - D_1^2)}{\pi (D_1 + D_2)} = \frac{(D_2 - D_1)(D_2 + D_1)}{(D_1 + D_2)}$$

$$D_h = D_2 - D_1$$

• Nu number in a previous equation based on D_e .

* $q = h A \Delta T$ where h is the heat transfer coefficient, A is the area, and ΔT is the temperature difference.

$$q = h A \Delta T$$

• T_b & T_w are bulk and wall temperatures respectively.

$$\Delta T_{ln} = \frac{\Delta T_1 - \Delta T_2}{\ln(\Delta T_1 / \Delta T_2)}$$

where:

$$\Delta T_1 = |T_{w1} - T_{b1}|$$

$$\Delta T_2 = |T_{w2} - T_{b2}|$$

يعني الفرق بين T_w و T_b هو ΔT

ΔT is the temperature difference

$$q = h A \Delta T_{ln}$$

where:

ΔT_{ln} = logarithmic mean temperature

* في حالت زكو فيو $\Delta T_{avg} \approx \Delta T_{lm}$:

- عند زكو ΔT_1 & ΔT_2 قـ يـاتـ مـ بـوضـ

$$\Delta T_1 = 50$$

$$\Delta T_2 = 60$$

$$\Delta T_{avg} = \frac{50 + 60}{2} = 55$$

$$\Delta T_{lm} = \frac{60 - 50}{\ln(60/50)} = 54.85$$

$$\Delta T_{avg} \approx \Delta T_{lm}$$

- عند زكو السـفـ laminar & $Re \text{ Pr } D/L > 0$ ، يـصـحـ

الفـقـ بـ ΔT_{avg} & ΔT_{lm} قـلـ



* Example 1 :

Air at 20°C is blown over a 6cm OD pipe that has a surface temperature of 140°C . The free stream air velocity is 10 m/s. What is the rate of heat transfer per meter of pipe?

Solu :

في خطوات معينة في السؤال :

1- Schematic (رسم تخطيطي للسؤال)2- assumptions (الفرضيات التي يتخذها بالسؤال)3- assumptions (الفرضيات التي يتخذها بالسؤال)

- assume steady state

- assume the length = 1m

- assume uniform surface temperature

3- Physical properties (الخواص الفيزيائية للسؤال)

والتي هي الخواص الفيزيائية في السؤال :

- ρ , μ , k , Pr

* يفتقر في هذه المسألة
نوع من tables في
التي μ و ρ

والتي هي الخواص الفيزيائية في السؤال :

$$Re = \frac{\rho \cdot V \cdot D}{\mu} = \frac{V \cdot D}{\nu}$$

بأن ρ و μ في Pr و μ و ρ في
وحدة فقط وهي ν فقط في

طريقة في
interpolation

*Note:

type of viscosity

kinematic


dynamic

$$\nu = \frac{\mu}{\rho}$$

Re régime régime

tables 1 no Nu, 1 no Nu

$$q = A h \Delta T$$



$$\frac{293.15 k}{293.15 - 250} = \frac{15.89 - 11.44}{300 - 250} = \frac{x - 11.44}{293.15 - 250}$$

$$\therefore \nu = 15.28 \times 10^{-6} \frac{\text{m}^2}{\text{s}}$$

$$\frac{293.15 k}{293.15 - 250} = \frac{-707 - 720}{300 - 250} = \frac{x - 720}{293.15 - 250}$$

$$\text{Pr} = 0.709$$

$$\frac{k}{293.15} = \frac{26.3 - 22.3}{300 - 250} = \frac{x - 22.3}{293.15 - 250} \Rightarrow k = 25.75 \times 10^{-3}$$

$$\text{Re} = \frac{\rho V D}{\mu} = \frac{10 \text{ m/s} \times 6 \times 10^{-2} \text{ m}}{15.28 \times 10^{-6} \frac{\text{m}^2}{\text{s}}} =$$

$$\text{Re} = 39267$$

$\therefore$ flow is turbulent

Nu given tables 1 no, is

turbulent's table

- Re in pipe < 2300

$\therefore$ flow is laminar

- Re > 2900

$\therefore$ flow is turbulent

ask : believe & recieve

Eq: 2

$$Nu = C Re^m Pr^n (Pr/Pr_s)^{\frac{1}{4}}$$

$$Pr_s = \frac{413.15k}{450 - 400} = \frac{413.15 - 400}{413.15 - 400}$$

$$Pr_s = 0.689$$

$$413.15$$

if $Pr \leq 10 \Rightarrow n = 0.37$

$$Nu = 0.193 (39267)^{0.618} (0.709)^{0.37} \left(\frac{0.709}{0.689} \right)^{\frac{1}{4}}$$

$$Nu = 118.17$$

$$Nu = \frac{hD}{k}$$

$$118.17 = \frac{h(0.06)}{25.75 \times 10^{-3}}$$

$$h = 50.7 \text{ W/k.m}^2$$

$$q = hA(T_s - T_\infty)$$

$$q = 50.7 (\pi DL) (T_s - T_\infty)$$

$$\frac{q}{L} = 50.7 (\pi \cdot 0.06) (140 - 20)$$

$$\frac{q}{L} = 1196.8 \frac{\text{W}}{\text{m}}$$




* Example 2:

A duct carries hot waste gas from a process unit to a pollution control device. The duct cross section is 4 ft x 4 ft & it has a surface temperature of 140°C.

Ambient air at 20°C flows across the duct with a wind speed of 10 m/s. Estimate the rate of heat loss per meter of duct length.

Soln



$$Nu = C Re_D^m Pr^{\frac{1}{3}}$$

∴ non-circular cylinder

∴ 20°C 20 m/s

Physical properties of air at

at T_f

$$T_f = \frac{T_{air} + T_s}{2} = \frac{20 + 140}{2} = 80^\circ\text{C}$$

$$\nu \Rightarrow \frac{26.41 - 20.92}{353.15 - 350} = \frac{x - 20.92}{353.15 - 350}$$

$$\nu = 21.266 \times 10^{-6} \text{ m}^2/\text{s}$$

$$k \Rightarrow \frac{33.8 - 30}{400 - 350} = \frac{x - 30}{353.15 - 350}$$

$$Pr \Rightarrow \frac{69 - 0.7}{353.15 - 350} = \frac{x - 0.7}{353.15 - 350}$$

$$k = 30.24 \times 10^{-3}$$

$$Pr = 0.699$$

width $\Rightarrow$

square in

$$Re = \frac{D \cdot v}{\nu} = \frac{w \cdot v}{\nu}$$

$$\frac{4 \text{ ft}}{1 \text{ ft}} \cdot \frac{0.3048 \text{ m}}{1 \text{ ft}} \times \frac{10 \text{ m/s}}{21.266 \times 10^{-6} \text{ m}^2/\text{s}}$$

$$Re = 573309.5$$

$\therefore$ turbulent regime

$$Nu = C Re^m Pr^{\frac{1}{3}}$$

$$= 0.02 (573309.5)^{0.675} (0.699)^{\frac{1}{3}}$$

$$Nu = 697.7$$

$$Nu = \frac{hD}{k}$$

$$697.7 = \frac{h (1.22)}{30.24 \times 10^{-3}}$$

$$h = 17.29 \text{ W/m}^2 \cdot \text{K}$$

$$q = hA (T_s - T_\infty)$$

$$q = 17.29 (4 \times (4 \text{ ft} \cdot \frac{0.3048 \text{ m}}{1 \text{ ft}}) L) (140 - 20)$$

عدد رينولدز المتحرك $\Rightarrow 4$
في انتقال الحرارة، القاعدة
تكون لـ مقدار الطاقة المتدفقة
بداً ففادته مع الأسطح المتدفقة


$$\frac{q}{L} = 17.29 (4 \times 1.22) (120)$$

$$\frac{q}{L} = 10118.38 \text{ W/m}$$

* Ex 4:

Carbon dioxide at 300 K & 1 atm is to be pumped through a duct with a 10 cm $\times$ 10 cm square cross-section at a rate of 250 kg/h. The walls of duct will be at temperature of 450 K. What distance will the CO₂ travel through the duct before its temperature reaches a 400 K?

Solu



* Physical Properties at $T_{avg} = \frac{300 + 400}{2} = 350K$

$$\rho|_{350} \Rightarrow \frac{1.4743 - 1.5618}{360 - 340} = \frac{x - 1.5618}{350 - 340}$$

$$\rho|_{350} = 1.518 \text{ kg/m}^3$$

$$\mu|_{350} \Rightarrow \frac{173 - 165}{360 - 340} = \frac{x - 165}{350 - 340}$$

$$\mu|_{350} = 169 \times 10^{-7} \text{ N}\cdot\text{s/m}^2$$

$$k|_{350} \Rightarrow \frac{21.2 - 19.7}{360 - 340} = \frac{x - 19.7}{350 - 340}$$

$$k|_{350} = 20.45 \times 10^{-3} \text{ W/m}\cdot\text{K}$$



$$Pr|_{350} \rightarrow \frac{.741 - .746}{360 - 340} = \frac{x - .746}{350 - 340}$$

$$Pr|_{350} = .7435$$

$$\mu_w|_{450} = 210 \times 10^{-7} \text{ N}\cdot\text{s}/\text{m}^2$$

$$Cp|_{350} \rightarrow \frac{.908 - .891}{360 - 340} = \frac{x - .891}{350 - 340}$$

$$Cp|_{350} = .8995 \frac{\text{kJ}}{\text{kg}\cdot\text{K}}$$

$$Deq = \frac{4 A}{\text{wet } P} = \frac{4}{\frac{(10 \times 10^{-2} \times 10 \times 10^{-2})}{4(10 \times 10^{-2})}} = .1 \text{ m}$$

$$Re = \frac{\rho \downarrow Deq}{\mu}$$

$$Re = \frac{1.518 \frac{\text{kg}}{\text{m}^3} \times 4.57 \frac{\text{m}}{\text{s}} \times .1 \text{ m}}{169 \times 10^{-7} \frac{\text{N}\cdot\text{s}}{\text{m}^2}} = 41049$$

$$Re = 41049$$

$\therefore$ turbulent regime

$$Nu = .027 Re^{0.8} Pr^{1/3} (\mu/\mu_w)^{0.14}$$

$$Nu = .027 (41049)^{0.8} (.7435)^{1/3} \left(\frac{169 \times 10^{-7}}{210 \times 10^{-7}} \right)^{0.14}$$

$$Nu = 116.38$$

$$\dot{V} = \frac{\text{mass rate}}{\rho}$$

$$\dot{V} = \frac{250 \text{ kg}}{1.518 \frac{\text{kg}}{\text{m}^3}} \frac{1}{3600 \text{ s}} = .0457 \text{ m}^3/\text{s}$$

$$\text{velocity} = \frac{\dot{V}}{\text{area}}$$

$$\text{velocity} = \frac{.0457 \text{ m}^3/\text{s}}{.01 \text{ m}^2} = 4.57 \frac{\text{m}}{\text{s}}$$

$$Nu = \frac{h D_{eq}}{k}$$

$$116.38 = \frac{h \times 1}{20.45 \times 10^{-3}}$$

$$h = 23.8 \text{ W/m}^2 \cdot \text{K}$$

$$q = C_p m \Delta T$$

$$q = 0.8995 (250) (400 - 300) \frac{\text{kJ}}{\text{kg} \cdot \text{K}} \times \frac{\text{kg}}{\text{h}} \times \frac{\text{K}}{3600 \text{ s}}$$

$$q = 6.246 \text{ kW} = 6.246 \times 10^3 \text{ W}$$

$$q = h A \Delta T_m$$

$$6.246 \times 10^3 \text{ W} = 23.8 \frac{\text{W}}{\text{m}^2 \cdot \text{K}} (4 \times 10 \times 10^{-2} \text{ m}^2) 91 \text{ K}$$

$$L = 7.2 \text{ m}$$

$$\Delta T_1 = 450 - 300 = 150$$

$$\Delta T_2 = 450 - 400 = 50$$

$$\Delta T_m = \frac{150 - 50}{\ln(150/50)}$$

$$\Delta T_m = 91$$

* كيف يمكن قياس قيمتي k or h عملياً بالمختبر؟

- يجب heater power وبعض سطح المادة لمقدار معين


في الطريقة .

- بقيس أبعاد الجسم وحسب A

- بحسب ΔT على السطح الأمامي والسطح الخلفي من thermometer

وإذا أكثر من جهاز لقياس درجة الحرارة

على أكثر من نقطة .



$$q = k A \frac{dT}{dx}$$

أصبحت كل القيم معلومة فاعدا k نحسبها من معادلات

Fourier's

وبقيت الفكرة بحسب قيمتي h و k في قانون Newton's

$$q = h A \Delta T$$



* Ex 5: experiment

Experiments have been conducted on an electric cylinder 12.7 mm in diameter & 94 mm long. The cylinder is heated internally by an electrical heater and is subjected to cross flow of air in a low-speed wind tunnel. Under a specific set of operating conditions for which the upstream air velocity & temperature were maintained at $u = 10 \text{ m/s}$ & 26.2°C , respectively, the heater power dissipation was measured to be $P = 46 \text{ W}$, while the average cylinder surface temperature was determined to be $T_s = 128.4^\circ\text{C}$. It is estimated that 15% of the power dissipation is lost through the cumulative effect of surface radiation & conduction through the end pieces.

- 1- Determine the convection heat transfer coefficient from the experimental observations.
- 2- Compare the experimental result with the convection coefficient computed from an appropriate correlation.



air 10 m/s $T = 26.2^\circ\text{C}$

$$T_s = 128.4^\circ\text{C}$$

$$12.7 \text{ mm}$$

$$94 \text{ mm}$$

$$q = q_s (1 - 0.15)$$

$$\frac{\text{loss}}{\text{steps}} = 46 (0.85) = \underline{\underline{39.1 \text{ W}}}$$

$$q = h A \Delta T$$

$$39.1 \text{ W} = h \pi D L (T_s - T_\infty)$$

$$39.1 \text{ W} = h \pi (12.7 \times 10^{-3}) \text{ m} (94 \times 10^{-3}) \text{ m} (128.4 - 26.2) \text{ K}$$

$$h = 102.4 \text{ W/m}^2 \cdot \text{K}$$

experiments $\rightarrow$ h is a function of Re and Pr

correlation $\rightarrow$ h is a function of Re and Pr

2 Physical properties at T_∞

$$\nu = \frac{\mu}{\rho} = \frac{15.89 \times 10^{-6} \text{ m}^2/\text{s}}{299.35 \text{ kg/m}^3}$$

$$Pr = 0.707$$


$$k = 26.3 \times 10^{-3} \text{ W/m} \cdot \text{K}$$

$$Pr_s = 401.55 = 0.690$$

$$Re = \frac{V D}{\nu} = \frac{10 \text{ m/s} \times 12.7 \times 10^{-3} \text{ m}}{15.89 \times 10^{-6} \text{ m}^2/\text{s}} = 7992.448$$

$\therefore$ Turbulent flow

$$Nu = C Re^m Pr^n (Pr/Pr_s)^{1/4}$$



$$C = 0.193$$

$$m = 0.618$$

$$n = 0.37 \Rightarrow Pr \leq 10$$

$$Nu = 0.193 (7992.448)^{0.618} (-0.707)^{0.37} \left(\frac{-0.707}{0.690} \right)^{\frac{1}{4}}$$

$$Nu = 44.09$$

$$Nu = \frac{hD}{k}$$

$$44.09 = \frac{h (12.7 \times 10^{-3})}{26.3 \times 10^{-3}}$$

$$h = 91.3 \text{ W/m}^2 \cdot \text{K}$$

* ملاحظة: الدكتور استخدم أكثر من correlation وكانت

قيمة h تقريباً بتراوح بين (80 - 110) $\pm$ رقم



24th - mar - 2022

* Flow across Bank of tubes:

Bank of tubes $\leftarrow$ heat exchanger

external flow


: one tube

boundary layer

regime

transition of laminar


turbulent



* Bank of tubes $\Rightarrow$ tubes

turbulent flow

heat transfer



arrangement في تصميم (توزيع) tubes في وحدة التبريد


* Type of arrangement

Aligned


توزيع tubes في صف واحد

Staggered

توزيع tubes في صفين متداخلين



(Aligned)




(Staggered)

where:

$S_T \Rightarrow$ Transverse Pitch

$S_L \Rightarrow$ Longitudinal Pitch



* $\text{أهم شيء المصاحبة به}$ Tubes بتلعب دور كبير في heat transfer

* Notes:

- The configuration (ترتيب) is characterized by the tube diameter D and by the transverse pitch S_T and longitudinal pitch S_L measured between tube centers.

- Conditions within the bank are dominated by boundary layer separation effects and by wake interactions, which in turn influence convection heat transfer.


- Flow around the tubes in the first Row of a tube bank is similar to that for a single (isolated) cylinder in cross flow.

single tube , correlation في أول row



* من اسؤال كيف بي اكتب v_{max} في اقطر انبوب؟ Re_{max} !

الكتابة 1 : **Aligned**



في هذه الحالة 1 Fluid
بين كل 1 bank of tubes
من قبل A
من قبل Fluid 1 tubes
من قبل A

والسؤال في هذه الحالة A
بين 1 tubes في حالة
ترتيب Aligned والفرق هو

في هذه الحالة A area

• A 1 v_{max} - Continuity equation

$Q_{in} = Q$ between tubes density

$$A v = A_1 v_{max}$$

$$(S_T) v = (S_T - D) v_{max}$$

$$S_T v = (S_T - D) v_{max}$$

$$v_{max} = \frac{S_T v}{S_T - D} = \frac{S_T}{S_T - D} v$$


at A₁

السرعة في A₁


Fluid 1

* v_{max} في area

velocity



Staggered : $2A_2$



في صنف الكائنات $2A_2$ fluid
 بينفيل $2A_2$ bank of tubes
 من A_1 fluid $2A_2$ ثم يتدفق
 بين tubes $2A_2$ من خلال مساحة
 check $2A_2$ A_1 في
 area $2A_2$ في $2A_2$
 $2A_2$

في $2A_2$ assumption $2A_2$

$$2A_2 < A_1$$

فقط $2A_2$ $2A_2$

assumption $2A_2$ $2A_2$

up & down

$2A_2$ $2A_2$

$2A_2 < A_1$ في $2A_2$


$$2(S_D - D) < (S_T - D)$$

كيف $2A_2$ $2A_2$ $2A_2$

نظر $2A_2$ $2A_2$

$$S_D = \left(\left(\frac{S_T}{2} \right)^2 + (S_L)^2 \right)^{\frac{1}{2}}$$

بعض $2A_2$ $2A_2$



ask : believe & recieve

$$2 \left[\left(\left(\frac{S_T}{2} \right)^2 + (S_L)^2 \right)^{\frac{1}{2}} - D \right] \leq S_T - D \quad \div 2$$

$$\left(\left(\frac{S_T}{2} \right)^2 + (S_L)^2 \right)^{\frac{1}{2}} - D \leq \frac{S_T - D}{2}$$

$$\left[\left(\frac{S_T}{2} \right)^2 + (S_L)^2 \right]^{\frac{1}{2}} \leq \frac{S_T}{2} + \frac{D}{2}$$

$$S_D < \frac{S_T + D}{2}$$

this means $2A_2 < A_1^2$

A_2 is $< \text{max (given)}$

$$\text{max } (2A_2) = \text{max } A$$

Fluid is flowing in the pipe

$$\text{max} = \frac{AV}{2A_2}$$

$$\text{max} = \frac{S_T \sqrt{2}}{2(S_D - D)} = \frac{S_T}{2(S_D - D)} \sqrt{2}$$

A_1 is $< \text{max}$ $\rightarrow$ S_D is $< \text{max}$ $\rightarrow$ S_T is $< \text{max}$

$$\text{max} = \frac{S_T}{A_1 (S_T - D)} \sqrt{2}$$

design is not *


assumption is



* ex: Pressurized water is often available at elevated temperatures and may be used for space heating or industrial process applications. In such cases it is customary to use a tube bundle in which the water is passed through the tubes, while air is passed in cross flow over the tubes. Consider a staggered arrangement for which the tube outside diameter is 16.4 mm and the longitudinal and transverse pitches are $S_L = 34.3 \text{ mm}$ & $S_T = 31.3 \text{ mm}$. There are seven rows of tubes in the air flow direction and eight tubes per row. Under typical operating conditions the cylinder surface temperature is at 70°C , while the air upstream temperature and velocity are 15°C and 6 m/s , respectively. Determine the air-side convection coefficient.

Soln

المسألة: تحديد معامل انتقال الحرارة من الهواء إلى الماء في حزمة أنابيب.



assumption *
 1. tubes
 T_s Assume uniform wall temperature $\rightarrow T_s$
 $T_0 \leftarrow$ external flow temperature T_i
 $\Delta T_2 = T_s - T_0$
 $\Delta T_1 = T_s - T_i$
 $\Delta T_{lm} = \frac{\Delta T_1 - \Delta T_2}{\ln \left(\frac{\Delta T_1}{\Delta T_2} \right)}$
 ask : believe & recieve

* physical properties of Air at 15°C (288.15 K)

$$\nu = 14.835 \times 10^{-6} \text{ m}^2/\text{s}$$

$$\frac{11.44 - 15.89}{250 - 300} = \frac{x - 15.89}{288.15 - 300}$$

$$Pr = 0.71$$

$$\frac{0.707 - 0.720}{300 - 250} = \frac{x - 0.720}{288.15 - 250}$$

$$k = 25.352 \times 10^{-3} \text{ W/m}\cdot\text{K}$$

$$\frac{26.3 - 22.3}{300 - 250} = \frac{x - 22.3}{288.15 - 250}$$

* physical properties of air at surface 70°C (343.15 K)

$$Pr = 0.701$$

$$\frac{0.7 - 0.707}{350 - 300} = \frac{x - 0.707}{343.15 - 300}$$

* check of area ($2A_2 < A_1$)

$$S_D = \left(\left(\frac{1}{2} S_T \right)^2 + (S_L)^2 \right)^{\frac{1}{2}}$$

$$S_D = \left(\left(\frac{31.3 \times 10^{-3}}{2} \right)^2 + (34.3 \times 10^{-3})^2 \right)^{\frac{1}{2}}$$

$$S_D = 37.7 \times 10^{-3} \text{ m}$$

$$S_D < \frac{S_T + D}{2}$$

$$\frac{(31.3 \times 10^{-3}) + (16.4 \times 10^{-3})}{2}$$

$$S_D > 23.85 \times 10^{-3}$$

$$S_D > \frac{S_T + D}{2}$$

$\therefore$ Askx at Air & recieve

$$\therefore \downarrow_{\max} (A_1) = \downarrow A$$

$$\downarrow_{\max} = \frac{S_T}{(S-D)} \downarrow$$

$$\downarrow_{\max} = \frac{31.3 \times 10^{-3}}{2(31.3 \times 10^{-3} - 16.4 \times 10^{-3})} \times 6 \frac{\text{m}}{\text{s}}$$

$$\downarrow_{\max} = 12.604 \frac{\text{m}}{\text{s}}$$

$$\text{Re}_{D_{\max}} = \frac{D \downarrow_{\max}}{\nu} = \frac{16.4 \times 10^{-3} \times 12.604}{14.835 \times 10^{-6}} =$$

$$\text{Re}_{D_{\max}} = 13933$$

$$C_1 \Rightarrow$$

$$\frac{S_T}{S_L} = \frac{31.3 \times 10^{-3}}{34.3 \times 10^{-3}} = 0.9 < 2$$

$$\therefore C_1 = 0.35 \left(\frac{S_T}{S_L} \right)^{1/5} = 0.3427$$

$$m = 0.6$$

$$\left| \text{Nu}_D \right| = 0.3427 (13933)^{0.6} \cdot 71^{0.36} \left(\frac{0.71}{0.701} \right)^{1/4} = 93.15$$

$$\text{Nu}_D \geq 20$$

$$\text{Nu}_D = \left| \text{Nu}_D \right| \cdot C_2$$

$$\text{Nu}_D < 20$$

$$\text{Nu}_D \geq 20$$

$$\left| \text{Nu}_D \right| = 93.15 \times 0.95 = 88.5$$

$$\text{Nu}_D < 20$$

$$h = \text{Nu}_D \frac{k}{D} = 88.5 \times 25.352 \times 10^{-3} \frac{\text{W}}{\text{m} \cdot \text{K}} \frac{1}{16.4 \times 10^{-3} \text{m}} = 136 \frac{\text{W}}{\text{m}^2 \cdot \text{K}}$$

* energy balance :

Newton's law of cooling

$$\underline{\underline{1}} \quad \dots \quad \dot{q} = hA \Delta T_{lm} = \bar{h} (N \pi D L) \Delta T_{lm} = (\rho V S_T N_T L) c_p (T_s - T_i)$$

↓
كتلة المائع

where:

$N \Rightarrow$ Total number of tubes

$N_T \Rightarrow$ number of tubes per row $\Rightarrow$ عدد التتاليات في الصف

$$N_T = 1 + \text{عدد الممرات بين الأنابيب}$$

تubes

$$\underline{\underline{2}} \quad \dots \quad \Delta T_{lm} = \frac{\Delta T_1 - \Delta T_2}{\ln \left(\frac{\Delta T_1}{\Delta T_2} \right)}$$

Combine Eqs (1) & (2), we obtain

$$\frac{T_s - T_o}{T_s - T_i} = \exp \left[- \frac{\pi D N \bar{h}}{\rho V N_T S_T c_p} \right]$$

* نستخدم هذه المعادلة في الغالب لإيجاد قيمة T_o ، في أغلب

الأمثلة تكون T_o غير معروفة

وقد نستخدم أيضاً لإيجاد h ولكن غير دقيقة



29th - may - 2022

* Heat exchanger :

cold & hot fluid flow in tubes & tubes are separated by insulation

H.E $\Rightarrow$ heat exchanger

H.E Calculations

Thermal &

Mechanical calculations

hydraulic calculations

* hydraulic $\Rightarrow$

هو العلم الذي يدرس التوافق الهيكلي

للموائج

ويعتبر من أقدم التخصصات في الموائج

* Mechanical $\Rightarrow$ mainly stress on pipes ---

وحجته تكون على الـ

Thermal & hydraulic



Heat exchanger problems

Rating

H-E في المعروف أنه

نقل كفاءة مع البنية ، فتم عمل

خوصات معينة لتقدير

استعمال H-E بأفضل

نتم عمل تقدير بتكليف

وكرر كين يتم عمل الخوصات ؟

بشون performance (الشوا)

في H-E حسب (المعطيات)

• overall specification

• يجب data مقارنة مع

performance ! إذا لم تكن به التقارب

يكرر في مشاكل heat exchanger

Design

2 streams يجب

cold

hot

temperature flowrate

• specification : يجب

- required dimension

- number of tubes

- total surface area

- h overall

• يجب


* يجب من هذه المعطيات تقدير H-E أو استعمال




= heat exchanger

- Double-pipe equipment

: 2 tubes



Parallel or (co-current) flow




Counter-current flow

Inner fluid


Annulus fluid

Concentric tube exchanger

* Simple double-pipe exchanger (one hairpin)



hairpin : 2 tubes



* characteristic of hairpin exchanger :

- Batteries of hairpins connected in series or in series-parallel arrangements are commonly employed to provide adequate surface area for heat transfer.

- The outer pipe may be insulated to minimize heat transfer to or from the environment.

إدارة

- Nozzles may be provided on the inner pipe (tube) side as well as on the annulus side to facilitate connection to process piping.

يمكن توفير فتحات في جانب الأنبوب الداخلي
وكذلك في جانب الحجرة لتسهيل التوصيل
بأنابيب العملية.

- Multi-tube exchanger are also available in which the inner pipe is replaced by a bundle of U-tubes.

تتوفر أيضاً مبادلات متعددة
الأنابيب حيث يتم استبدال
الأنبوب الداخلي بحزمة من أنابيب
U.



- Simple double-pipe exchangers are commercially available with outer pipe sizes ranging from 2 to 8 in and inner pipes from 3/4 to 6 in.

size 1/4 to 6 in

- Multi-tube units with outer-pipe sizes as large as 36 in are commercially available.

36 in

- Double-pipe exchangers are commonly used in applications involving relatively low flow rates & high temperatures or pressure, for which they are well suited.

(low capacity)


- Other advantages include low installation cost, ease of maintenance, and flexibility.

simplicity

low cost

* Shell and Tube Equipment

A shell and tube exchanger consists of a bundle of tubes contained in a cylindrical shell.



- Tubes could be fixed or removable.

- Tube sheets are used to fix the tubes & to prevent fluids mixing.

- A number of different head & shell designs are commercially available.

ask & believe & receive

TEMA designations for shell & tube exchanger: عبارت به شرکتی

Front end

Shell types

قسمت جلویی و پشتی
H.E Rear end types

Head types

قسمتی بر اساس شکل

قسمتی بر اساس شکل

قسمتی بر اساس شکل

بر اساس جنسیت

بر اساس جنسیت

بر اساس جنسیت

* به هم ترکیب H.E و ۲ راجع

*Notes:


- The tubular exchanger Manufacturers Association (TEMA) employs a three-letter code to specify the front-end & shell & rear end types.

به این ترتیب کد H.E & AES

- Shells $\Rightarrow$ are available with inside diameters in discrete size up to 120 in. Shells up to 24 in. in diameter are generally made from steel pipes, while larger sizes are made from rolled steel plate.

shells 120 in size of inside diameter
24 in و 120 in و size of inside diameter
24 in و 120 in و size of inside diameter
rolled steel plate (rolled Diameter) بال

- Tubes $\Rightarrow$ are available with sizes from 1/4 to 2 in. outside diameter. Finned tubing is also available.



31th - mar - 2022

Shell side 1 في heat transfer coefficient 1

- Equivalent diameter for shell side:

$$De = \frac{4 \text{ Area}}{\text{wetted perimeter}}$$

$$De = \frac{4(S_T^2 - \pi(OD_+)^2/4)}{\pi(OD_+)}$$

كيف استقيمت العلاقة؟

المساحة عبارة عن مربع مطروح

منه 4 دوائر دائرية

يعني عندي 4 دوائر كل دائرة 1/4 منها

فهي مساحت المربع -

مساحة المربع عبارة عن (طول الضلع)²

$$= S_T^2$$


ولكن المربع راجع منه 4 أجزاء

عبارة عن ربع الدائرة ، فإذا

طعنت له 4 أجزاء فكل دائرة كاملة

لذلك المساحة عبارة عن

مساحة المربع - مساحة دائرة



المساحة عبارة عن المساحة المربعة

منه 4 دوائر يعني دائرة

كاملة لذلك المساحة عبارة عن

مساحة دائرة



كيف اشتق القوانيين ١٢

$$De = \frac{4 \left((S_T/2) (0.86 S_T) - \pi (OD)^2 / 8 \right)}{\pi (OD) / 2}$$

اشتق الباق في التمهيد من الموائع
وهو مثل مساحة المثلث في الموائع ويعني زوايا
 $= 60^\circ$


المثلث في عبارة في مثلث في

منه أوجد في أدراج الكبريات

$$\frac{1}{2} \times \text{base} \times \text{high} = \text{مساحة المثلث}$$

$S_T =$ القاعدة

$0.86 S_T =$ ارتفاع



نظري في الموائع

$\therefore \text{Area} =$

$$(S_T)^2 = \left(\frac{1}{2} S_T \right)^2 + (\text{high})^2 \quad \frac{1}{2} \times \text{base} \times \text{high} = \frac{1}{2} (\pi (OD)^2)$$

$$0.75 S_T^2 = (\text{high})^2$$

$$\text{high} = 0.86 S_T$$

$$= \left(\frac{1}{2} S_T \times 0.86 S_T \right) - \frac{1}{8} (\pi OD^2)$$

* اشتق الموائع في الموائع

الموائع والسبب في جميع الموائع

نظري = $\pi \times$ دوائر الموائع ، والموائع

الموائع في جميع الموائع ١٨٠° وهو $\frac{1}{2}$ مجموع

الموائع الموائع

* wetted perimeter :

مساحة $\frac{1}{2}$ دائرة

$$= \frac{1}{2} (\pi OD)$$

* Baffles :

- Baffles are a number of discs installed inside the shell side of the H.E.

- Used to support the tube bundle and to withstand vibrations and bending

- Typical types are :

Segmental baffles

عادةً ما تكون disk في كل فتحة

من فتحة tubes ، ويبلغ 25%

تقريباً من مساحة disk لتتبع

شكل الفتحة ، أهمية هذا الشكل

هو أن يتركز الضغط في fluid

في فتحة tubes وتكون أكثر مركزة


في fluid في الفتحة التي لها المساحة الأكبر

ويتركز في fluid في فتحة الأكبر مساحة

في فتحة tubes ، ويحدث

اضطراب (turbulent) في fluid

في heat exchanger



* موانع أو Baffles :

- Increase pressure drop

لزيادة الضغط في المبادل heat exchanger
أو pressure drop

وذلك من خلال الموانع

- المسافات بين baffles و disk

Types of baffles

Cut - Segmental
baffle

Disk and doughnut
baffle


Orific baffle

Single

Double

Segmental
baffle



Segmental
baffle



Doughnut



Disk



* تكون موانع في Fluid Line
أو في المساحات بين baffles

* تشبه الموانع موانع
fluid في قنطرة المبادل
بالمبادل

يتم زيادة قطر المبادل
في قطر tube
في المبادل
أو tube
(gap) المساحة
في fluid
في المبادل

- Baffle 1 سمت *

- change direction of fluid
- Increase the mixing $\Rightarrow$ Increase heat transfer


* Notes:

The baffles serve the function of directing the flow of the shell side fluid across the tube bundle, thereby enhancing the rate of heat transfer

* Notes:

Sealing strips (metal strips attached to the baffles) are used to minimize the channeling of fluid between the outer row of tubes and the shell.

Sealing strips



بaffles به سبب این که در بین baffles و tubes درجهت جریان را تغییر می دهد و از channeling جلوگیری می کند و باعث افزایش انتقال حرارت می شود.

Sealing strips به سبب این که در بین baffles و tubes درجهت جریان را تغییر می دهد و از channeling جلوگیری می کند و باعث افزایش انتقال حرارت می شود.



* Tube and shell passes:

- Tube side:

▷ Multiple passes are achieved by means of U-tubes or by partitioning the headers.

▷ The number of tube-side passes is usually one, two, four or six, but may be as high as 16.

تدفق السائل في أنابيب ← passes من مدخل (inlet) إلى مخرج (outlet).

- Shell side:

▷ Multiple passes on the shell side are achieved by partitioning the shell with a longitudinal baffle (type F-shell) or by connecting two or more single-pass shells together.


▷ Number of shell-side passes is usually between one and six.

Space area ← المساحة المتاحة للسائل في أنابيب
length of heat exchanger ← طول مبادل الحرارة

1-2 heat exchanger


* لَمْ يَكُنْ تَقِيَهُ

shell 1. $\frac{1}{2}$ and $\frac{1}{4}$
(series) $\frac{1}{2}$ and $\frac{1}{4}$



* محمد رفیق اتھار اکرکت زفھر فصار جدید

* حَقِّي عَلَى عِصَارِ وَاهِدٍ لـ shell




2-4 heat exchanger


2 $\Rightarrow$ number of shell pass

$4 \Rightarrow$ number of tube pass

shell 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100



One shell pass and one tube pass $\Rightarrow$ pure counter flow



Common type of (1-2) exchanger




* Notes:


- The main advantage of shell and tube exchanger is that they provide a relatively large amount of heat transfer surface per unit of volume and weight, and require a minimum number of connections. They are extremely versatile, and can be designed to meet almost any heat transfer service. As a result, they are used in a wide variety of applications.
- Flow pattern in the shell is a sinuous motion both transverse and parallel to the tubes.

--- up-down-up ← baffle ↓ ↓ ↓ fluid ↓ ↓ ↓

- Streams by pass: part of the fluid bypasses the main heat transfer surface as a result of various leakages. The bypass streams include the tube-to-baffle leakage stream, the tube bundle to shell bypass stream, and the baffle to shell leakage stream.

(تسرب) leakages ← heat exchanger ↓





Idealized main stream flow

* Shell side leakage and


bypass:

- Tube to baffle leakage stream
- tube & baffle leakage stream
- actual cross-flow stream
- bundle to shell bypass stream
- baffle to shell leakage stream
- partitioning longitudinal

* Shell - Side Bypass Flows:

Stream	Percentage in turbulent flow	Percentage in laminar flow
Cross flow	30 - 65	10 - 50
Bundle bypass	15 - 35	30 - 80
Baffle - shell leakage	6 - 21	6 - 48
Tube - shell leakage	9 - 23	0 - 10

leakage




Look:

- The main stream flowing across the tube bundle may comprise less than 50% of the total shell-side flow due to bypass flow.
- The presence of these bypass streams complicates the analysis of shell-side heat transfer and pressure drop.

* The overall Heat-Transfer Coefficient:

- Consider the double-pipe section as shown below.
- Let the hot fluid (arbitrarily) to flow through the inner pipe.



* Explain the heat transfer from hot to cold streams.

* To describe this overall process, an overall heat transfer coefficient, U , is defined by:

$$q = U A \Delta T_m \rightarrow \text{driving force}$$

هنا q هو معدل انتقال الحرارة A المساحة الكلية للأنابيب

hot tube A المساحة الكلية للأنابيب ΔT_m الفرق في درجات الحرارة

المتوسط ΔT_m هو الفرق في درجات الحرارة

بالنسبة الى $\pi D L$ = area $\pi D L$ و D هو القطر

inside diameter & out side diameter


(out side) D_o $\pi D_o L$ $\therefore$ Area = $\pi D_o L$

$$\therefore \text{Area} = \pi D_o L$$

* Heat transfer area:

The heat transfer area, A , is the surface area of the inner pipe, and may be based on either the inside and outside diameter. In practice, however, the out side diameter is commonly used, so that:

$$A = A_o = \pi D_o L$$



في هذه الحالة $heat$ $\rightarrow$ cold $\rightarrow$ hot

$$A = \pi D_i L$$

tube $\rightarrow$ D_i $\pi D_i L$

في هذه الحالة $heat$ $\rightarrow$ cold $\rightarrow$ hot

insulation $\rightarrow$ D_i $\pi D_i L$

* Temperature difference:

- The temperature difference, ΔT_m , is the mean temperature difference between the two fluid streams.

- It can be shown that when U is independent of position along the exchanger, ΔT_m is the logarithmic mean temperature difference.

$$\Delta T_m = \Delta T_{lm} = \frac{\Delta T_2 - \Delta T_1}{\ln(\Delta T_2 / \Delta T_1)}$$

• where ΔT_1 & ΔT_2 are the temperature difference at the two ends of the exchanger.

- The above equation is valid regardless of whether counter flow or parallel flow is employed.



* Thermal resistance & OHTC "U"

OHTC $\Rightarrow$ overall heat transfer coefficient

- Thermal resistance:

$$R_{th} = \frac{1}{UA}$$

$$\frac{1}{UA_o} = \frac{1}{h_i A_i} + \ln(D_o/D_i) + \frac{1}{h_o A_o} \quad \text{--- 1}$$

inner fluid

inner tube

outer fluid & outer surface

(inner diameter)

outer tube

(inner tube)

where: h_i & h_o are the heat transfer coefficients for flow in the inner & outer pipes

$A_i \Rightarrow$ surface area of the inner pipe based on the inside diameter.


$$A_i = \pi D_i L$$

$$U = \left[\frac{D_o}{h_i D_i} + \frac{D_o \ln(D_o/D_i)}{2k} + \frac{1}{h_o} \right]^{-1} \quad \text{--- 2}$$

• Equation 2 is correct when the heat exchanger is new & the heat transfer surfaces are clean.

heat exchanger 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99, 100, 101, 102, 103, 104, 105, 106, 107, 108, 109, 110, 111, 112, 113, 114, 115, 116, 117, 118, 119, 120, 121, 122, 123, 124, 125, 126, 127, 128, 129, 130, 131, 132, 133, 134, 135, 136, 137, 138, 139, 140, 141, 142, 143, 144, 145, 146, 147, 148, 149, 150, 151, 152, 153, 154, 155, 156, 157, 158, 159, 160, 161, 162, 163, 164, 165, 166, 167, 168, 169, 170, 171, 172, 173, 174, 175, 176, 177, 178, 179, 180, 181, 182, 183, 184, 185, 186, 187, 188, 189, 190, 191, 192, 193, 194, 195, 196, 197, 198, 199, 200, 201, 202, 203, 204, 205, 206, 207, 208, 209, 210, 211, 212, 213, 214, 215, 216, 217, 218, 219, 220, 221, 222, 223, 224, 225, 226, 227, 228, 229, 230, 231, 232, 233, 234, 235, 236, 237, 238, 239, 240, 241, 242, 243, 244, 245, 246, 247, 248, 249, 250, 251, 252, 253, 254, 255, 256, 257, 258, 259, 260, 261, 262, 263, 264, 265, 266, 267, 268, 269, 270, 271, 272, 273, 274, 275, 276, 277, 278, 279, 280, 281, 282, 283, 284, 285, 286, 287, 288, 289, 290, 291, 292, 293, 294, 295, 296, 297, 298, 299, 300, 301, 302, 303, 304, 305, 306, 307, 308, 309, 310, 311, 312, 313, 314, 315, 316, 317, 318, 319, 320, 321, 322, 323, 324, 325, 326, 327, 328, 329, 330, 331, 332, 333, 334, 335, 336, 337, 338, 339, 340, 341, 342, 343, 344, 345, 346, 347, 348, 349, 350, 351, 352, 353, 354, 355, 356, 357, 358, 359, 360, 361, 362, 363, 364, 365, 366, 367, 368, 369, 370, 371, 372, 373, 374, 375, 376, 377, 378, 379, 380, 381, 382, 383, 384, 385, 386, 387, 388, 389, 390, 391, 392, 393, 394, 395, 396, 397, 398, 399, 400, 401, 402, 403, 404, 405, 406, 407, 408, 409, 410, 411, 412, 413, 414, 415, 416, 417, 418, 419, 420, 421, 422, 423, 424, 425, 426, 427, 428, 429, 430, 431, 432, 433, 434, 435, 436, 437, 438, 439, 440, 441, 442, 443, 444, 445, 446, 447, 448, 449, 450, 451, 452, 453, 454, 455, 456, 457, 458, 459, 460, 461, 462, 463, 464, 465, 466, 467, 468, 469, 470, 471, 472, 473, 474, 475, 476, 477, 478, 479, 480, 481, 482, 483, 484, 485, 486, 487, 488, 489, 490, 491, 492, 493, 494, 495, 496, 497, 498, 499, 500, 501, 502, 503, 504, 505, 506, 507, 508, 509, 510, 511, 512, 513, 514, 515, 516, 517, 518, 519, 520, 521, 522, 523, 524, 525, 526, 527, 528, 529, 530, 531, 532, 533, 534, 535, 536, 537, 538, 539, 540, 541, 542, 543, 544, 545, 546, 547, 548, 549, 550, 551, 552, 553, 554, 555, 556, 557, 558, 559, 560, 561, 562, 563, 564, 565, 566, 567, 568, 569, 570, 571, 572, 573, 574, 575, 576, 577, 578, 579, 580, 581, 582, 583, 584, 585, 586, 587, 588, 589, 590, 591, 592, 593, 594, 595, 596, 597, 598, 599, 600, 601, 602, 603, 604, 605, 606, 607, 608, 609, 610, 611, 612, 613, 614, 615, 616, 617, 618, 619, 620, 621, 622, 623, 624, 625, 626, 627, 628, 629, 630, 631, 632, 633, 634, 635, 636, 637, 638, 639, 640, 641, 642, 643, 644, 645, 646, 647, 648, 649, 650, 651, 652, 653, 654, 655, 656, 657, 658, 659, 660, 661, 662, 663, 664, 665, 666, 667, 668, 669, 670, 671, 672, 673, 674, 675, 676, 677, 678, 679, 680, 681, 682, 683, 684, 685, 686, 687, 688, 689, 690, 691, 692, 693, 694, 695, 696, 697, 698, 699, 700, 701, 702, 703, 704, 705, 706, 707, 708, 709, 710, 711, 712, 713, 714, 715, 716, 717, 718, 719, 720, 721, 722, 723, 724, 725, 726, 727, 728, 729, 730, 731, 732, 733, 734, 735, 736, 737, 738, 739, 740, 741, 742, 743, 744, 745, 746, 747, 748, 749, 750, 751, 752, 753, 754, 755, 756, 757, 758, 759, 760, 761, 762, 763, 764, 765, 766, 767, 768, 769, 770, 771, 772, 773, 774, 775, 776, 777, 778, 779, 780, 781, 782, 783, 784, 785, 786, 787, 788, 789, 790, 791, 792, 793, 794, 795, 796, 797, 798, 799, 800, 801, 802, 803, 804, 805, 806, 807, 808, 809, 810, 811, 812, 813, 814, 815, 816, 817, 818, 819, 820, 821, 822, 823, 824, 825, 826, 827, 828, 829, 830, 831, 832, 833, 834, 835, 836, 837, 838, 839, 840, 841, 842, 843, 844, 845, 846, 847, 848, 849, 850, 851, 852, 853, 854, 855, 856, 857, 858, 859, 860, 861, 862, 863, 864, 865, 866, 867, 868, 869, 870, 871, 872, 873, 874, 875, 876, 877, 878, 879, 880, 881, 882, 883, 884, 885, 886, 887, 888, 889, 890, 891, 892, 893, 894, 895, 896, 897, 898, 899, 900, 901, 902, 903, 904, 905, 906, 907, 908, 909, 910, 911, 912, 913, 914, 915, 916, 917, 918, 919, 920, 921, 922, 923, 924, 925, 926, 927, 928, 929, 930, 931, 932, 933, 934, 935, 936, 937, 938, 939, 940, 941, 942, 943, 944, 945, 946, 947, 948, 949, 950, 951, 952, 953, 954, 955, 956, 957, 958, 959, 960, 961, 962, 963, 964, 965, 966, 967, 968, 969, 970, 971, 972, 973, 974, 975, 976, 977, 978, 979, 980, 981, 982, 983, 984, 985, 986, 987, 988, 989, 990, 991, 992, 993, 994, 995, 996, 997, 998, 999, 1000, 1001, 1002, 1003, 1004, 1005, 1006, 1007, 1008, 1009, 1010, 1011, 1012, 1013, 1014, 1015, 1016, 1017, 1018, 1019, 1020, 1021, 1022, 1023, 1024, 1025, 1026, 1027, 1028, 1029, 1030, 1031, 1032, 1033, 1034, 1035, 1036, 1037, 1038, 1039, 1040, 1041, 1042, 1043, 1044, 1045, 1046, 1047, 1048, 1049, 1050, 1051, 1052, 1053, 1054, 1055, 1056, 1057, 1058, 1059, 1060, 1061, 1062, 1063, 1064, 1065, 1066, 1067, 1068, 1069, 1070, 1071, 1072, 1073, 1074, 1075, 1076, 1077, 1078, 1079, 1080, 1081, 1082, 1083, 1084, 1085, 1086, 1087, 1088, 1089, 1090, 1091, 1092, 1093, 1094, 1095, 1096, 1097, 1098, 1099, 1100, 1101, 1102, 1103, 1104, 1105, 1106, 1107, 1108, 1109, 1110, 1111, 1112, 1113, 1114, 1115, 1116, 1117, 1118, 1119, 1120, 1121, 1122, 1123, 1124, 1125, 1126, 1127, 1128, 1129, 1130, 1131, 1132, 1133, 1134, 1135, 1136, 1137, 1138, 1139, 1140, 1141, 1142, 1143, 1144, 1145, 1146, 1147, 1148, 1149, 1150, 1151, 1152, 1153, 1154, 1155, 1156, 1157, 1158, 1159, 1160, 1161, 1162, 1163, 1164, 1165, 1166, 1167, 1168, 1169, 1170, 1171, 1172, 1173, 1174, 1175, 1176, 1177, 1178, 1179, 1180, 1181, 1182, 1183, 1184, 1185, 1186, 1187, 1188, 1189, 1190, 1191, 1192, 1193, 1194, 1195, 1196, 1197, 1198, 1199, 1200, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1209, 1210, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1218, 1219, 1220, 1221, 1222, 1223, 1224, 1225, 1226, 1227, 1228, 1229, 1230, 1231, 1232, 1233, 1234, 1235, 1236, 1237, 1238, 1239, 1240, 1241, 1242, 1243, 1244, 1245, 1246, 1247, 1248, 1249, 1250, 1251, 1252, 1253, 1254, 1255, 1256, 1257, 1258, 1259, 1260, 1261, 1262, 1263, 1264, 1265, 1266, 1267, 1268, 1269, 1270, 1271, 1272, 1273, 1274, 1275, 1276, 1277, 1278, 1279, 1280, 1281, 1282, 1283, 1284, 1285, 1286, 1287, 1288, 1289, 1290, 1291, 1292, 1293, 1294, 1295, 1296, 1297, 1298, 1299, 1300, 1301, 1302, 1303, 1304, 1305, 1306, 1307, 1308, 1309, 1310, 1311, 1312, 1313, 1314, 1315, 1316, 1317, 1318, 1319, 1320, 1321, 1322, 1323, 1324, 1325, 1326, 1327, 1328, 1329, 1330, 1331, 1332, 1333, 1334, 1335, 1336, 1337, 1338, 1339, 1340, 1341, 1342, 1343, 1344, 1345, 1346, 1347, 1348, 1349, 1350, 1351, 1352, 1353, 1354, 1355, 1356, 1357, 1358, 1359, 1360, 1361, 1362, 1363, 1364, 1365, 1366, 1367, 1368, 1369, 1370, 1371, 1372, 1373, 1374, 1375, 1376, 1377, 1378, 1379, 1380, 1381, 1382, 1383, 1384, 1385, 1386, 1387, 1388, 1389, 1390, 1391, 1392, 1393, 1394, 1395, 1396, 1397, 1398, 1399, 1400, 1401, 1402, 1403, 1404, 1405, 1406, 1407, 1408, 1409, 1410, 1411, 1412, 1413, 1414, 1415, 1416, 1417, 1418, 1419, 1420, 1421, 1422, 1423, 1424, 1425, 1426, 1427, 1428, 1429, 1430, 1431, 1432, 1433, 1434, 1435, 1436, 1437, 1438, 1439, 1440, 1441, 1442, 1443, 1444, 1445, 1446, 1447, 1448, 1449, 1450, 1451, 1452, 1453, 1454, 1455, 1456, 1457, 1458, 1459, 1460, 1461, 1462, 1463, 1464, 1465, 1466, 1467, 1468, 1469, 1470, 1471, 1472, 1473, 1474, 1475, 1476, 1477, 1478, 1479, 1480, 1481, 1482, 1483, 1484, 1485, 1486, 1487, 1488, 1489, 1490, 1491, 1492, 1493, 1494, 1495, 1496, 1497, 1498, 1499, 1500, 1501, 1502, 1503, 1504, 1505, 1506, 1507, 1508, 1509, 1510, 1511, 1512, 1513, 1514, 1515, 1516, 1517, 1518, 1519, 1520, 1521, 1522, 1523, 1524, 1525, 1526, 1527, 1528, 1529, 1530, 1531, 1532, 1533, 1534, 1535, 1536, 1537, 1538, 1539, 1540, 1541, 1542, 1543, 1544, 1545, 1546, 1547, 1548, 1549, 1550, 1551, 1552, 1553, 1554, 1555, 1556, 1557, 1558, 1559, 1560, 1561, 1562, 1563, 1564, 1565, 1566, 1567, 1568, 1569, 1570, 1571, 1572, 1573, 1574, 1575, 1576, 1577, 1578, 1579, 1580, 1581, 1582, 1583, 1584, 1585, 1586, 1587, 1588, 1589, 1590, 1591, 1592, 1593, 1594, 1595, 1596, 1597, 1598, 1599, 1600, 1601, 1602, 1603, 1604, 1605, 1606, 1607, 1608, 1609, 1610, 1611, 1612, 1613, 1614, 1615, 1616, 1617, 1618, 1619, 1620, 1621, 1622, 1623, 1624, 1625, 1626, 1627, 1628, 1629, 1630, 1631, 1632, 1633, 1634, 1635, 1636, 1637, 1638, 1639, 1640, 1641, 1642, 1643, 1644, 1645, 1646, 1647, 1648, 1649, 1650, 1651, 1652, 1653, 1654, 1655, 1656, 1657, 1658, 1659, 1660, 1661, 1662, 1663, 1664, 1665, 1666, 1667, 1668, 1669, 1670, 1671, 1672, 1673, 1674, 1675, 1676, 1677, 1678, 1679, 1680, 1681, 1682, 1683, 1684, 1685, 1686, 1687, 1688, 1689, 1690, 1691, 1692, 1693, 1694, 1695, 1696, 1697, 1698, 1699, 1700, 1701, 1702, 1703, 1704, 1705, 1706, 1707, 1708, 1709, 1710, 1711, 1712, 1713, 1714, 1715, 1716, 1717, 1718, 1719, 1720, 1721, 1722, 1723, 1724, 1725, 1726, 1727, 1728, 1729, 1730, 1731, 1732, 1733, 1734, 1735, 1736, 1737, 1738, 1739, 1740, 1741, 1742, 1743, 1744, 1745, 1746, 1747, 1748, 1749, 1750, 1751, 1752, 1753, 1754, 1755, 1756, 1757, 1758, 1759, 1760, 1761, 1762, 1763, 1764, 1765, 1766, 1767, 1768, 1769, 1770, 1771, 1772, 1773, 1774, 1775, 1776, 1777, 1778, 1779, 1780, 1781, 1782, 1783, 1784, 1785, 1786, 1787, 1788, 1789, 1790, 1791, 1792, 1793, 1794, 1795, 1796, 1797, 1798, 1799, 1800, 1801, 1802, 1803, 1804, 1805, 1806, 1807, 1808, 1809, 1810, 1811, 1812, 1813, 1814, 1815, 1816, 1817, 1818, 1819, 1820, 1821, 1822, 1823, 1824, 1825, 1826, 1827, 1828, 1829, 1830, 1831, 1832, 1833, 1834, 1835, 1836, 1837, 1838, 1839, 1840, 1841, 1842, 1843, 1844, 1845, 1846, 1847, 1848, 1849, 1850, 1851, 1852, 1853, 1854, 1855, 1856, 1857, 1858, 1859, 1860, 1861, 1862, 1863, 1864, 1865, 1866, 1867, 1868, 1869, 1870, 1871, 1872, 1873, 1874, 1875, 1876, 1877, 1878, 1879, 1880, 1881, 1882, 1883, 1884, 1885, 1886, 1887, 1888, 1889, 1890, 1891, 1892, 1893, 1894, 1895, 1896, 1897, 1898, 1899, 1900, 1901, 1902, 1903, 1904, 1905, 1906, 1907, 1908, 1909, 1910, 1911, 1912, 1913, 1914, 1915, 1916, 1917, 1918, 1919, 1920, 1921, 1922, 1923, 1924, 1925, 1926, 1927, 1928, 1929, 1930, 1931, 1932, 1933, 1934, 1935, 1936, 1937, 1938, 1939, 1940, 1941, 1942, 1943, 1944, 1945, 1946, 1947, 1948, 1949, 1950, 1951, 1952, 1953, 1954, 1955, 1956, 1957, 1958, 1959, 1960, 1961, 1962, 1963, 1964, 1965, 1966, 1967, 1968, 1969, 1970, 1971, 1972, 1973, 1974, 1975, 1976, 1977, 1978, 1979, 1980, 1981, 1982, 1983, 1984, 1985, 1986, 1987, 1988, 1989, 1990, 1991, 1992, 1993, 1994, 1995, 1996, 1997, 1998, 1999, 2000, 2001, 2002, 2003, 2004, 2005, 2006, 2007, 2008, 2009, 2010, 2011, 2012, 2013, 2014, 2015, 2016, 2017, 2018, 2019, 2020, 2021, 2022, 2023, 2024, 2025, 2026, 2027, 2028, 2029, 2030, 2031, 2032, 2033, 2034, 2035, 2036, 2037, 2038, 2039, 2040, 2041, 2042, 2043, 2044, 2045, 2046, 2047, 2048, 2049, 2050, 2051, 2052, 2053, 2054, 2055, 2056, 2057, 2058, 2059, 2060, 2061, 2062, 2063, 2064, 2065, 2066, 2067, 2068, 2069, 2070, 2071, 2072, 2073, 2074, 2075, 2076, 2077, 2078, 2079, 2080, 2081, 2082, 2083, 2084, 2085, 2086, 2087, 2088, 2089, 2090, 2091, 2092, 2093, 2094, 2095, 2096, 2097, 2098, 2099, 2100, 21

لدينا مع كثر استعمال A.E في سبب تكلسات تزيد من
 وقاوت انتقال الحرارة



Scales build up
 (تكلسات)

* Adding these two additional
 resistances to the main

OHTE equation:

$$U_D = \left[\frac{D_o}{h_i D_i} + \frac{D_o h (D_o / D_i)}{2k} + \frac{1}{h_o} + \frac{R_{Di} D_o}{D_i} + \frac{R_{Do}}{D_o} \right]^{-1}$$

where:


U_D is the overall coefficient after
 fouling has occurred.

- It is necessary to provide more heat transfer area than is
 actually required when the exchanger is clean.

Subject : _____


* مع مرور الزمن ينمو طبقة H.E تكلست ، نتيجة انتقال الحرارة ،
يتم حساب هذه التلوثات experimental ، وتوجد في tables حسب نوع
ال fluid حسب تكلست .

Fouling mechanisms



* ex: A double pipe heat exchanger will be used to cool a hot stream from 350°F to 250°F by heating a cold stream from 80°F to 120°F . The hot stream will flow in the inner pipe, which is 2-in. schedule 40 carbon steel with a thermal conductivity of $26 \text{ Btu/h} \cdot \text{ft}^2 \cdot ^{\circ}\text{F}$. Fouling factors of $0.001 \text{ h} \cdot \text{ft}^2 \cdot ^{\circ}\text{F}$ should be provided for each stream. The heat transfer coefficients are estimated to be $h_i = 200$ & $h_o = 350 \text{ Btu/h} \cdot \text{ft}^2 \cdot ^{\circ}\text{F}$ and the heat load is $3.5 \times 10^6 \text{ Btu/h}$.

- For counter-current operation, what surface area is required?
- For co-current operation, what surface area is required?





Subject: _____

soln

Heat pump

al



From table:

$$D_i = 2.067 \text{ in}$$

$$D_o = 2.375 \text{ in}$$

$$\Delta T_{lm} = \Delta T_1 - \Delta T_2$$

$$\ln(\Delta T_1 / \Delta T_2)$$

$$= \frac{230 - 170}{\ln(230 / 170)}$$

$$\ln(230 / 170)$$

$$\Delta T_1 = 350 - 120 = 230$$

$$\Delta T_2 = 250 - 80 = 170$$

$$\Delta T_{lm} = 198.5^\circ \text{F}$$

$$U_D = \left(\frac{D_o}{h_i D_i} + \frac{D_o \ln(D_o / D_i)}{2k} + \frac{1}{h_o} + R_{D_i} \frac{D_o}{D_i} + R_{D_o} \right)^{-1}$$

$$= \frac{2.375}{2.067 (200)} + \frac{2.375 \ln(2.375 / 2.067)}{2 (26)}$$

$$+ \frac{1}{350} + \frac{0.001 (2.375)}{2.067} + 0.001 \Big)^{-1}$$

$$= 88.65 \text{ Btu/h} \cdot \text{ft}^2 \cdot ^\circ \text{F}$$

$$A = \frac{q}{U \Delta T_{lm}} = \frac{3.5 \times 10^6 \text{ Btu/h}}{88.65 \text{ Btu/h} \cdot \text{ft}^2 \cdot ^\circ \text{F} (198.5)^\circ \text{F}}$$

$$= 198.9 \text{ ft}^2$$

ask :: believe & recieve

Subject: _____

b) co-current

$$\Delta T_1 = 350 - 80 = 270$$

$$\Delta T_2 = 130$$

$$\Delta T_{lm} = \frac{\Delta T_1 - \Delta T_2}{\ln(\Delta T_1 / \Delta T_2)}$$

$$\Delta T_{lm} = \frac{270 - 130}{\ln(270 / 130)} = 191.5^\circ F$$

$$A = \frac{3.5 \times 10^6}{88.65(191.5)} = 206 \text{ ft}^2$$

* Comments:

A co-current > A counter

المساحة المطلوبة في co-current أقل من المساحة المطلوبة في counter flow
coast

$$q = U A \Delta T_{lm}$$

تدفق الحرارة


$$A \uparrow \Delta T_{lm} \downarrow \quad \& \quad \Delta T_{lm} \uparrow \quad A \downarrow$$

زيادة المساحة في co-current تعني انخفاض ΔT_{lm}

& $\Delta T_{lm} \Rightarrow$ driving force for heat transfer

فزيادة driving force تعني انخفاض المساحة المطلوبة

* في حالة co-current يكون الفرق في درجات الحرارة بين inlet و exit صغيراً
بالمقارنة مع counter flow



Subject : _____

area Δp و $\dot{Q}$: counter 1 & design 1 ΔT و $\dot{Q}$


$T \Rightarrow$ hot fluid 1 ΔT

$t \Rightarrow$ cold fluid " "



5th - Apr - 2022


* Temperature profiles with lengths:




Condenser : change phase

hot stream $\Rightarrow$ condensation

cold fluid




Single phase , Co-current



Counter , single phase



* Special operating conditions:




hot stream

التي تدخل من اليمين

Counter or co-current


performance




التي تدخل من اليسار

cold stream

التي تدخل من اليسار



* The LMTD Correction Factor



Combination between Counter and co-current



! combination) ΔT_m ΔT_{lm} ΔT_{lm}

(11) H-E ΔT_m pure (counter or co-current) ΔT_m

correction ΔT_m (LMTD) ΔT_m

$$\Delta T_m = F (\Delta T_m)_{\text{pure}}$$

combination

where: $F \Rightarrow$ Correction factor

$\therefore F$ ΔT_m ΔT_m

$N \Rightarrow$ # of shell-side passes

$R = \frac{T_a - T_b}{t_b - t_a} \rightarrow$ Temperature range of hot stream
Temperature range of cold stream

$P = \frac{t_b - t_a}{T_a - t_a} \rightarrow$ Temperature range of cold stream

maximum temperature range for H-E

$\therefore \Delta T_m$ ΔT_m ΔT_m

for $R \neq 1$, compute

$$\alpha = \left(\frac{1 - RP}{1 - P} \right)^{1/N}$$

$$S = \frac{\alpha - 1}{\alpha - R}$$



$$\therefore F = \sqrt{R^2 + 1} \ln \left(\frac{1-S}{1-RS} \right)$$

$$(R-1) \ln \left[\frac{2-S(R+1-\sqrt{R^2+1})}{2-S(R+1+\sqrt{R^2+1})} \right]$$

* for $R=1$, compute

$$S = \frac{P}{N - (N-1)P}$$

$$N - (N-1)P$$

$$F = \frac{S\sqrt{2}}{(1-S) \ln \left[\frac{2-S(2-\sqrt{2})}{2-S(2+\sqrt{2})} \right]}$$

معادلات F لا تستخدم في اكل دوائتها في كتاب ابراهيم فهد

أما في مجال الهندسة تستخدم chart method في اطار صيد F

* يوجد 3 charts فكل واحد F chart استعمال باقتدار

of tube passes وطريقة # of shell passes

* ملاحظة :

Chart 1 يستخدم لـ $(1-2) H.E$

" " " " $(1-4) H.E$

of shell passes اذا تغير # of tube passes


بشكل chart في طرق صيد F

* المبريد 1 3 وحدة لـ one shell pass

التي 2 لـ two shell pass

التي 3 لـ three shell pass

of tube passes بقدر التكرار



بسطح من P كذا

عاجدي يتقاطع مع R ثم بعد ذلك

أفقياً يتقاطع مع F دبابه قبة F

* ما تأثير قبة F على H.E ؟

$$Q = U A F (\Delta T_m)$$

تأثير قبة F على H.E (pure) $F = 1$ ، يكون

وكلما قلت قبة F قل مقدار heat transfer

∴ Note:


F must be not less than 0.8



* في عمليات design يكثر الخلط بين H_0 و H_1 (1-2) ، وإذا كنت تريد

قوة F على نقطة A Shell 2 - مقدار قوة F ، إذا لم يبقَ بالعرض ينقل إلى
Shell 3 على نقطة B مقدار قوة F المتوجب

of shell $\uparrow \Rightarrow F \uparrow$



up range, lower sub. shell, and the # of shell rising trial

* Ex 1: A fluid is to be heated from 100°F to 160°F by heat exchange with a hot fluid that will be cooled from 230°F to 150°F . The heat transfer rate will be $540,000 \text{ Btu/h}$ and the hot fluid will flow in the tubes. Will a (1-2) exchanger (an exchanger with one shell pass and a multiple of two tube passes) be suitable for this service? Find the mean temperature difference in the exchanger.


هل يمكن استخدام مبادل H.E مع 1-2
 . ليس مناسباً not suitable بل مناسباً suitable

$$N = \frac{1}{2}$$

soln:

$$R = \frac{T_a - T_b}{t_b - t_a} = \frac{160 - 100}{230 - 150} = 0.75$$


$$P = \frac{t_b - t_a}{T_a - t_a} = \frac{150 - 230}{100 - 230} = -0.615$$



$\therefore$ (1-2) exchanger chart $\rightarrow F$ ليس مناسباً

$F = 0.72 < 0.8$, not suitable & should be not used

Two shell passes $\Rightarrow F = 0.94$ will be suitable



* Mean temperature difference

$$\Delta T_1 = 230 - 160 = 70^\circ\text{F}$$

$$\Delta T_2 = 150 - 100 = 50^\circ\text{F}$$

$$\Delta T_m = F (\Delta T_{lm})$$


$$= 0.94 \left(\frac{70 - 50}{\ln(70/50)} \right) \approx 56^\circ\text{F} \Rightarrow \text{driving force for H-E}$$

* ex 2: Double pipe thermal analysis:

Thermal analysis of a double-pipe exchanger is illustrated in the following example:

10000 lb/h of benzene is to be heated from 60°F to 120°F by heat exchange with an online stream that will be cooled from 150°F to 100°F . A number of 16 ft hairpins consisting of 2 in. by 1.25 in. schedule 40 stainless steel pipe (type 316, $k = 9.4 \text{ Btu/h}\cdot\text{ft}\cdot^\circ\text{F}$) are available and will be used for this service. how many hairpins will be required?


Soln



150 psi و 100 psi
16x2

10m و 15m و 20m و 25m و 30m و 35m و 40m و 45m و 50m و 55m و 60m و 65m و 70m و 75m و 80m و 85m و 90m و 95m و 100m

* reference of length for hairpins = 16, 18, 20



* Basic Assumptions:


- Assume heat from hot stream to cold stream

- Assume benzene flows in the inner pipe

outer pipe is in the shell

- Properties at average properties or according to the correlation conditions.

* Sketch T-x diagram



Mean temperature difference calculations

$$\Delta T = 50^\circ\text{F} \left\{ \begin{array}{l} 100^\circ\text{F} \longrightarrow 160^\circ\text{F} \\ 150^\circ\text{F} \longleftarrow 230^\circ\text{F} \end{array} \right\} \quad \Delta T = 70^\circ\text{F}$$

$$(\Delta T_{\ln})_{cf} = \frac{\Delta T_2 - \Delta T_1}{\ln(\Delta T_2 / \Delta T_1)} = \frac{70 - 50}{\ln(70/50)} = 59.6^\circ\text{F}$$


$$\Delta T_m = F(\Delta T_{\ln})_{cf} = 0.94 \times 59.6 = 56^\circ\text{F}$$

* hairpins consisting of 2 in by 1.25 in.

⇒ by ⇒ (2 in x 1.25 in) comp

2 in schedule ⇒ outer pipe

1.25 schedule ⇒ inner pipe



* what is the mass flowrate of aniline?

$$-q_{\text{loss}} = q_{\text{accept}}$$

$$-q_{\text{aniline}} = q_{\text{Benzene}}$$

$$-m_1 c_p \Delta T = m_2 c_p \Delta T$$

? 1 ✓ ✓ ✓
from table from table

herma

ble-pipe e
g example:


10,000 lb/h of benzene is to be heated from 60°F to 120°F by heat exchange with an aniline stream that will be cooled from 150°F to 100°F. A number of 16 ft hairpins consisting of 2 in. by 1.25 in. schedule 40 stainless steel pipe (type 316, $k = 9.4 \text{ Btu/h. ft. } ^\circ\text{F}$) are available and will be used for this service. how many hairpins will be required?




Basic Assumptions


- Assume heat from hot stream = cold stream. (adiabatic)
- Assume benzene flows in the inner pipe.
- Properties at average properties or according to the correlation conditions.
- Assume counter current

Sketch T-x diagram



Solution _ Procedure






بصورت ϕ_i و ϕ_o نسبت به h_i و h_o اصلاح می شود

مثلاً T_{sur} اصلاح می شود

$$\phi = \frac{h_{avg}}{h_{sur}}$$

$$N = \frac{L_{total \text{ calculated}}}{L \text{ of one hairpin}} \Rightarrow 2 \pi r L \leq A_{required}$$

How to calculate T_w



An energy balance gives:

$$q = h_i A_i (t_{ave} - T_w) = h_o A_o (T_w - T_{ave})$$

$$q_{loss} = q_{accept}$$

Solving for T_w yields:

metal * $\frac{thickness}{\text{metal}}$
(Benzene & aniline) $\frac{thickness}{\text{metal}}$

$$T_w = \frac{h_i A_i t_{ave} + h_o A_o T_{ave}}{h_i A_i + h_o A_o}$$

Substituting $A = \pi DL$ for the areas and rearranging, we obtain:

$$T_w = \frac{h_i t_{ave} + h_o (D_o/D_i) T_{ave}}{h_i + h_o (D_o/D_i)}$$

Criteria for Fluid Placement, in Order of Priority

Tube-side fluid

Corrosive fluid

Cooling water

Fouling fluid

Less viscous fluid

Higher-pressure stream

Hotter fluid

Shell-side fluid

Condensing vapor (unless corrosive)

Fluid with large ΔT ($> 100^\circ\text{F}$)

لدي بي اي
surface
area

* البقاع العامة لدفنار فوقه

fluids

* يجب ان لا يكون بعينه الاعتبار الى metal المستخدم



* Heat exchanger 3 :

* Preliminary Design of Shell-and-Tube Exchangers:

Obtain the heat transfer area for the purpose of making a preliminary cost estimate of the exchanger.

tables 1 & 2 U values & heat transfer coefficients

* Ex 1 :

In a petroleum refinery, it is required to cool 30,000 lb/h of kerosene from 400°F to 250°F by heat exchange with 75,000 lb/h of gas oil, which is at 110°F. A shell-and-tube exchanger will be used, and the following data are available:

fluid property	kerosene	Gas oil
C_p (Btu/lbm·°F)	0.6	0.5
μ (cp)	0.45	3.5
k (Btu/h·ft·°F)	0.077	0.08

for the purpose of making a preliminary cost estimate, determine the required heat-transfer area of the exchanger.

Solve :

المطلوب

$$q = U A (\Delta T)_{lm}$$

المساحة

المعدل

غير متجانسة

$m \cdot c_p \cdot \Delta T$

tables

قيم T امل

فقط 3 قيم في 2 درجات حرارة

a) Calculate the heat load & outlet temperature by energy balances on the two streams.

$$q = m \cdot c_p \cdot \Delta T$$

$$q = 30,000 \frac{\text{lb}}{\text{h}} \times 0.6 \frac{\text{Btu}}{\text{lb} \cdot ^\circ\text{F}} (400 - 250) ^\circ\text{F}$$

$$q = 2.7 \times 10^6 \text{ Btu/h}$$

$$q_{\text{loss}} = q_{\text{accept}}$$

$$2.7 \times 10^6 \text{ Btu/h} = 75,000 \frac{\text{lb}}{\text{h}} \times 0.5 \frac{\text{Btu}}{\text{lb} \cdot ^\circ\text{F}} (T - 110)$$

$$T = 182 ^\circ\text{F}$$


b) Calculate the LMTD (assume pure counter current)

$$\Delta T_1 = 400 - 182 = 218 ^\circ\text{F}$$

$$\Delta T_2 = 250 - 110 = 140 ^\circ\text{F}$$

$$(\Delta T)_{lm} = \frac{\Delta T_2 - \Delta T_1}{\ln(\Delta T_2 / \Delta T_1)}$$

$$= 176.13 ^\circ\text{F}$$



c) Calculate the LMTD correction factor

For the purpose of this calculation, assume that the kerosene will flow in the shell. This assumption will not affect the result since the value of F is the same, regardless of which fluid is in the shell.

$$R = \frac{T_a - T_b}{t_b - t_a} = \frac{400 - 250}{182 - 110} = 2.083$$

$$P = \frac{t_b - t_a}{T_a - t_a} = \frac{182 - 110}{400 - 110} = 0.248$$

*assume 1-2 exchanger

$$F \approx 0.94$$

d) estimate U_D from table $\Rightarrow U_D$ in range 20 - 35 Btu/h.ft².°F

Therefore take $U_D = 27.5$ Btu/h.ft².°F
range 1 up to 20 up to 35

e) Calculate the required area

$$q = U A F (\Delta T)_{lm}$$

$$2.7 \times 10^6 \text{ Btu/h} = 27.5 \frac{\text{Btu}}{\text{h.ft}^2.\text{°F}} A (0.94) (176.13) \text{°F}$$

$$A = 593 \text{ ft}^2$$

* Rating a Shell-and-Tube Exchanger:

- Check of performance

بجانب دیا ہوا ہے H.F. کے ساتھ دیا گیا ہے

* دیکھیں، دیکھیں، double-pipe exchanger کے ساتھ، shell & tube کے ساتھ، double کے ساتھ، tubes کے ساتھ،

پس one pipe ہے

hi assumption ہے

assumed that all tubes in the exchanger are exposed to the same thermal & hydraulic conditions. The value of h_i is then the same for all tubes & the calculation can be made for a single tube.

- In computing the Reynolds number, the mass flowrate per tube must be used:

$$m_{\text{per tube}} = \frac{m_t}{n_t} n_p$$

where:

m_t = total mass flowrate of tube side fluid

n_p = # of tube side passes

n_t = # of tubes

double-pipe کے ساتھ، hi کے ساتھ،



* Method of shell-side coefficient, no calculations:

coarse قَبِيحٌ

The method utilizes the graph of modified Colburn factor.

chart w/o odds factor (dH) 1.10

$$\eta_0 = j\omega \left(\frac{k}{D_e} \right) P_r^{1/3} \left(\frac{\mu}{\mu_\infty} \right)^{-1/4}$$
$$\dot{J}_H = 0.5 (1 + B/d_s) (0.08 Re^{-0.6821} + 7 Re^{-1.772})$$
$$a_s = \frac{d_s}{CB} \cdot 144 P_T$$

$d_s \Rightarrow$ shell inside diameter in

B $\Rightarrow$ buffer spacing in

$P_T \Rightarrow$ Pitch, m

as $\Rightarrow$ shell flow areas, f_t



$$N+1 = \frac{L}{B}$$

عدد التمرير في الج

drop pressure

* B تقى B تنريد عدد

baffles بالتي تنريد عدد

cross تنريد عدد

drop pressure

shell mass flux

$$G = \dot{m} / a_s \Rightarrow lb / ft^2 \cdot h$$

Reynolds number for shell side fluid

$$Re = G D_o / \mu$$

* Thermal rating procedure for a shell-and-tube heat exchanger:

1- Calculate the required overall coefficient


$$U_{req} = \frac{q}{A F (\Delta T)_{lm} C_f}$$

2- Calculate the clean overall coefficient

$$U_c = \left[\frac{D_o}{h_i D_i} + \frac{D_o \ln(D_o / D_i)}{2k} + \frac{1}{h_o} \right]^{-1}$$

$U_c \Rightarrow$ clean heat exchanger

H.E في تصميم



$B \Rightarrow$ baffle space

$$\# \text{ of baffles} = \frac{L}{B} = \frac{20}{5} = 4$$

$N =$ number of cross :

$$N = \frac{L}{B} - 1 \Rightarrow N+1 = \frac{L}{B}$$

3 Is $U_c > U_{req}$?!

yes

↓

Continue

No

↓

exchanger is not suitable

4 Obtain required fouling factors, R_{Di} & R_{Do} then calculate

R_D

from tables

$$R_D = R_{Di} (D_o / D_i) + R_{Do}$$

5 Calculate the design overall coefficient

$$U_D = (1/U_c + R_D)^{-1}$$

6 Is $U_D > U_{req}$?

yes


↓

exchanger is thermally
suitable

No

↓

exchanger is not suitable



13th - Apr - 2022

* Ex 2:

30,000 lb/h of kerosene are to be cooled from 400°F to 250°F by heat exchange with 75,000 lb/h of gas oil which is at 110°F. Available for this duty is a shell-and-tube

exchanger having 156 tubes in a 21 1/4 in. ID shell. The tubes are 1-in OD, 14 BWG, 16 ft long on a 1 1/4 in. square pitch.

There is one pass on the shell side and six passes on the tube side. The baffles are 20% cut segmental type and are spaced at 5 in. intervals. Both the shell & tubes are carbon steel having $k = 26 \text{ Btu/h}\cdot\text{ft}^2\cdot^\circ\text{F}$. Fluid properties are given in the previous example. Will the exchanger be thermally suitable for this service ?

Fluid properties	kerosene	Gas oil
$C_p (\text{Btu/lbm}\cdot^\circ\text{F})$	0.6	0.5
$\mu (\text{cp})$	0.45	0.5
$k (\text{Btu/h}\cdot\text{ft}\cdot^\circ\text{F})$	0.077	0.08

BWG $\Rightarrow$ Birmingham wire gauge

20% segmental baffles $\Rightarrow$

area of 20% cut cross



Solu

step 1

هذا السؤال يتعلق بـ Fluid 1 و q المطلوب
المطلوب هو Fluid 1 و T المطلوب
المطلوب هو DT_{lm} و T المطلوب

$$q = C_p m \Delta T$$


$$q = 0.6 \frac{\text{Btu}}{\text{lbm} \cdot ^\circ\text{F}} \times 30000 \frac{\text{lb}}{\text{h}} \times (400 - 250) ^\circ\text{F}$$

$$q = 2.7 \times 10^6 \text{ Btu/h} \Rightarrow \text{from kerosene}$$

$$q \text{ to gas oil} = C_p m \Delta T$$

$$\frac{\text{Btu}}{\text{h}} 2.7 \times 10^6 = 0.5 \frac{\text{Btu}}{\text{lbm} \cdot ^\circ\text{F}} \times 75000 \frac{\text{lb}}{\text{h}} (T - 110)$$

$$T_2 = 182 ^\circ\text{F}$$



$$DT_1 = 218$$

$$DT_2 = 140$$

$$(DT_{lm})_{cf} = \frac{218 - 140}{\ln(218/140)} = 176 ^\circ\text{F}$$

F chart one pass of shell

$$F = 0.93$$

- The surface area is obtained from the dimensions of the exchanger

$$A = 156 \text{ tubes} \times 16 \text{ ft} \times 0.2618 \text{ ft}^2 = 653 \text{ ft}^2$$

table B-1 ↙ ft of tube

area / unit length 1 ft

$$U_{req} = \frac{q}{A F (\Delta T_{lm})_{cf}} = \frac{2.7 \times 10^6}{653 \times 0.93 \times 176} = 25.3 \text{ Btu/h-ft}^2 \cdot ^\circ\text{F}$$

step 2 Calculate U_c

- calculate the tube side Re

$$\dot{m} \text{ per tube} = \frac{\dot{m} \times \# \text{ of passes of tubes}}{\# \text{ of tubes}}$$

$$= \frac{75,000 \times 6}{156} = 2885 \text{ lb/h}$$

$$Re = \frac{4 \dot{m}}{\pi D_i \mu} = \frac{4 \times 2885}{\pi \left(\frac{0.834}{12} \right) \times 35 \times 2.419} = 6243 \Rightarrow \text{transition regime}$$

assumption: mass flow into tube, Re > 1000

$\Rightarrow$ all tubes are exposed to the same thermal



Calculate h_i

$$Nu = \frac{h_i D_i}{k} = 0.116 (Re^{2/3} - 125) Pr^{1/3} \left(\frac{\mu}{\mu_w}\right)^{0.14} \left(1 + (D_i/L)^{2/3}\right)$$

$$h_i = 0.8 \times 0.116 (6243^{2/3} - 125) \left(\frac{0.5 \times 3.5 \times 2.419}{0.8}\right)^{1/3} (1 + \left(\frac{0.834}{12 \times 16}\right)^{2/3})$$
$$h_i = 110 \text{ Btu/h} \cdot \text{ft}^2 \cdot ^\circ\text{F}$$

* Note: we assume the viscosity correction factor = 1, since no data were given for the temperature dependence of the oil viscosity

calculate the shell side Re


From Figure 1 $d_e = 0.99 \text{ in}$ & $C' = 0.250 \text{ in}$

$$D_e = d_e / 12 = 0.99 / 12 = 0.0825 \text{ ft}$$

$$a_s = \frac{d_s C' B}{144 P_T} = \frac{21.25 \times 0.25 \times 5}{144 \times 1.25} = 0.1476 \text{ ft}^2$$

$$G = \frac{m}{a_s} = \frac{30000}{0.1476} = 203294 \text{ lbm/h} \cdot \text{ft}^2$$

$$Re = \frac{D_e G}{\mu} = \frac{0.0825 \times 203294}{0.45 \times 2.419} = 15407$$



Calculate h_o

$$B \text{ / } \text{ols} = 5 / 21.25 = 0.235$$

From Figure 1 $j_H = 40$

$$h_o = j_H \frac{k}{D_o} P_r^{1/3} \left(\frac{\mu}{\mu_w} \right)^{0.14}$$

$$= \frac{40 \times 0.077}{0.825} \left(\frac{0.6 \times 45 \times 2.419}{0.77} \right)^{1/3}$$

$$h_o = 76 \text{ Btu/h} \cdot \text{ft}^2 \cdot ^\circ\text{F}$$


Calculate U_c

$$U_c = \left(\frac{D_o}{h_i D_i} + \frac{D_o \ln(D_o/D_i)}{2k} + \frac{1}{h_o} \right)^{-1}$$

$$= \left(\frac{1}{110 \times 0.834} + \frac{(1/12) \ln(1/0.834)}{2 \times 26} + \frac{1}{76} \right)^{-1}$$

$$U_c = 41.1 \text{ Btu/h} \cdot \text{ft}^2 \cdot ^\circ\text{F}$$

$\therefore U_c > U_{\text{req}}$, proceed to step 3



step 3 Obtain the required fouling factors. Taking .0025 for kerosene & .0035 for gas oil

$$R_D = \frac{R_{Di} D_o}{D_i} + R_{Do}$$

$$= \frac{.0035 \times 1}{.834} + .0025$$

$$R_D = .0067 \text{ h} \cdot \text{ft}^2 \cdot ^\circ\text{F} / \text{Btu}$$

step 4 Calculate U_D

$$U_D = \left(\frac{1}{U_c} + R_D \right)^{-1}$$

$$= \left(\frac{1}{41.1} + .0067 \right)^{-1}$$

$$U_D = 32 \text{ Btu} / \text{h} \cdot \text{ft}^2 \cdot ^\circ\text{F}$$

$$\Rightarrow U_D > U_{req}$$

$\therefore$ The exchanger is suitable



DESIGN OF DOUBLE-PIPE HEAT EXCHANGERS

* Total cost have 2 parameters:

- Capital cost
- Operating cost

نصف يكونوا low

Introduction

- y a reasonable
team and design
constraints. The
determine
een capital and

Introduction _ continue

- ❖ For low-viscosity liquids such as water, organic solvents, light hydrocarbons, etc., an allowance in the range of 7-20 psi is commonly used. For gases, a value in the range of 1-5 psi is often specified.
- ❖ The basic calculations involved in the thermal analysis of double-pipe heat exchangers (which given in the previous slides) are still required in this section of analysis. Moreover, Series-parallel configurations of hairpins are considered.

* كذا ارتفاع + low viscosity liquids
تقريباً 20 psi
* كذا + range يكون 7-20 psi
low operating cost

- Range of pressure

خلاف ذلك، range بضغط 1-5 psi
viscosity

* كذا ارتفاع + low viscosity liquids
تقريباً 20 psi
* كذا + range يكون 7-20 psi
low operating cost
* إذا زاد hairpin، range (ت) في درجة
بالنسبة للغازات، range 1-5 psi

Heat-Transfer Coefficients for Exchangers without Fins

- Heat-transfer correlations for pipes and annuli were presented in the previous lectures and their application to the analysis of double-pipe exchangers was also illustrated. In short (summary):
 - ✓ For turbulent flow ($Re \geq 10^4$), the Seider-Tate equation is used in the form:

$$Nu = 0.023 Re^{0.8} Pr^{1/3} (\mu/\mu_w)^{0.14} \dots\dots\dots (1)$$

Note: A coefficient of 0.023 is used here rather than 0.027. This coefficient (0.023) is often preferred for design work.

✓ For the transition region ($2100 < Re < 10^4$), the Hausen equation is used:

$$Nu = 0.116 [Re^{2/3} - 125] Pr^{1/3} (\mu/\mu_w)^{0.14} [1 + (D_i/L)^{2/3}] \dots\dots\dots (2)$$

✓ Equations (1) and (2) are used for both pipes and annuli, with the equivalent diameter, D_e , replacing D_i , the pipe ID, in the case of an annulus.

✓ For laminar flow ($Re \leq 2100$) in pipes, the Seider-Tate equation is used:


$$Nu = 1.86 [Re Pr D_i/L]^{1/3} (\mu/\mu_w)^{0.14} \dots\dots\dots (3)$$

But for laminar flow in annuli, the following equation should be used.

$$Nu = 3.66 + 1.2(D_2/D_1)^{0.8} + \frac{0.19[1 + 0.14(D_2/D_1)^{0.5}][Re Pr D_e/L]^{0.8}}{1 + 0.117[Re Pr D_e/L]^{0.467}} \dots\dots\dots (4)$$

✓ Double pipes 1 stage *
or hair pins 1 stage

- Series
- Series parallel



Equations for Exchangers without Fins

The main contribution to pressure drop in double-pipe exchangers is from fluid friction in the straight sections of pipe. For isothermal flow, this pressure drop can be expressed in terms of the friction factor, f , as:

$$\Delta P_f = \frac{f L \rho V^2}{2g_c D_i} \dots\dots\dots (5)$$

where isothermal flow في حالة تدفق متساوي الحرارة

L = pipe length

D_i = pipe ID

ρ = fluid density

V = average fluid velocity

average temperature of fluid $\approx$ temperature of wall

: pressure drop في ضغط *
(total length) hair pin 1 stage في -
(straight section of pipe)
change of direction in hair pin -
nozzles في -

This equation can be written in terms of the mass flux, G , and the specific gravity, s , of the fluid by making the substitutions $V = G/\rho$ and $\rho = s \cdot \rho_{\text{water}}$ to give:

$$\Delta P_f = \frac{f L G^2}{2g_c \rho_{\text{water}} D_i s} \dots\dots\dots (6)$$

* specific gravity (s) $\Rightarrow$

$$s = \frac{\rho}{\rho_{\text{water}}}$$

* DP في مقاسات *
range في

ask : believe & recieve

Notes

* إذا كان النظام في حالة غير متساوية الحرارة
 fluid wall correction factor
 DP is basic hydraulic equation by dividing the right side by 144φ.

⇒ correction factor = 144φ

Flow is basic hydraulic equation by dividing the right side by 144φ.

$(\mu/\mu_w)^{0.14}$ for turbulent flow

$(\mu/\mu_w)^{0.25}$ for laminar flow

The viscosity correction factor accounts for the effect of variable fluid properties on the friction factor in non-isothermal flow, while the factor of 144 converts the pressure drop from lbf/ft² to psi.

➤ The friction factor can be computed as follows: (cf)

For laminar flow in the inner pipe,

$$f = 64/Re$$

For laminar flow in the annulus

$$f = \left(\frac{64}{Re} \right) \left[\frac{(1 - \kappa)^2}{1 + \kappa^2 + (1 - \kappa^2)/\ln \kappa} \right]$$

where

$\kappa = D_1/D_2$

$D_1 = \text{OD of inner pipe}$

$D_2 = \text{ID of outer pipe}$


- For commercial pipe and turbulent flow with $Re > 3000$, the following equation can be used for both the pipe and the annulus:

$$f = 0.3673 Re^{-0.2314}$$




Series/Parallel Configurations of Hairpins

In order to meet pressure drop constraints, it is sometimes convenient to divide one stream into two or more parallel branches while leaving the other stream intact.



- Two hairpins connected in series
- Gives pure counter current flow (true counter flow)



- Hairpins with annuli connected in series and inner pipes connected in parallel.
- Although the flow is countercurrent in each hairpin, the overall flow pattern is not true counter flow.

Note: in particular that the temperature of the fluid entering hairpin is different in the two cases.

To account for the departure from true counter-flow in parallel configurations, the counter-flow temperature difference (LMTD) is multiplied by a correction factor, F , given by the following equations:

$$F = \left[\frac{(R-x)}{x(R-1)} \right] \frac{\ln[(1-P)/(1-PR)]}{\ln \left[\frac{(R-x)}{R(1-PR)^{1/x}} + x \right]}$$

$$F = \frac{P(1-x)}{x(1-P) \ln \left[\frac{(1-x)}{(1-P)^{1/x}} + x \right]}$$

$$P = (t_b - t_a) / (T_a - t_a)$$

$$R = (T_a - T_b) / (t_b - t_a)$$

where

x = number of parallel branches

T_a, T_b = inlet and outlet temperatures of

t_a, t_b = inlet and outlet temperatures of

* لغز به 1 series & parallel :

← (series) : بهش 1 inner fluid

دسته بهش داخل 1 hair pin
شکل سلسله متوالی

← (parallel) : بهش 1 inner fluid

- بهش بهش 1 hair pin داخل
- " " " " " "

← (series) : بهش 2 درجات مایه ها
سلسله متوالی

← (parallel) : بهش 1 Tin مشترک

تو درون mixing بعد از خروج


* 1 parallel بهش 1 true counter flow

شماره 1.5
تصحیح (F) correction factor true counter

درجه 1 F به (LMTD)

Multi-tube Exchangers

Un-finned multi-tube hairpin exchangers can be handled using the methods presented above with an appropriate value of the equivalent diameter. For an outer pipe with an ID of D_2 containing n_t tubes, each with OD of D_1 , the flow area and wetted perimeter are:



$$A_f = (\pi/4) (D_2^2 - n_t D_1^2)$$

$$\text{Wetted perimeter} = \pi (D_2 + n_t D_1)$$

Therefore, the equivalent diameter is given by:

$$D_e = 4 A_f / \text{wetted perimeter}$$

$$D_e = (D_2^2 - n_t D_1^2) / (D_2 + n_t D_1)$$

Note that for $n_t = 1$, this reduces to $D_e = D_2 - D_1$.

double pipe

Over-Surface and Over-Design

U clean

U design

- Over-surface is a measure of the safety factor incorporated in the design of a heat exchanger through fouling factors and the use of standard equipment sizes. Since it deals directly with exchanger surface area, it is easier to visualize than fouling factors and calculated versus required heat-transfer coefficients.
- The percentage over-surface is defined as follows:

$$\% \text{ over-surface} = \frac{A - A_c}{A_c} \times 100$$

where

A = actual heat-transfer surface area in the exchanger

A_c = calculated heat-transfer surface area based on U_c


ask : believe & recieve

- Over-surface depends on the relative magnitudes of the total fouling allowance and the film and wall resistances. While values of 20-40% may be considered typical, higher values are not unusual.
- The previous equation is often applied with the surface area calculated using the design coefficient, U_D , rather than the clean coefficient. In this case the computed quantity is referred to as the over-design; it represents the extra surface area beyond that required to compensate for fouling.
- Some over-design (typically about 10% or less) is considered acceptable and (often) desirable, since it provides an additional safety margin in the final design.
- The design procedure is illustrated via the following example.

* في التصميم اولى thermal calculation يجرى hydraulic calculation يجرى

Example

10,000 lb/h of benzene will be heated from 60°F to 120°F by heat exchange with an aniline stream that will be cooled from 150°F to 100°F. A number of 16-ft hairpins consisting of 2-in. by 1.25-in. schedule 40 stainless steel pipe (type 316, $k = 9.4 \text{ Btu/h} \cdot \text{ft} \cdot ^\circ\text{F}$) are available and will be used for this service. A maximum pressure drop of 20 psi is specified for each stream. The specific gravity of benzene is 0.879 and that of aniline is 1.022. Determine the number and configuration of hairpins that are required.



Solution

Assumptions;

- 1) We begin by assuming that the hairpins are connected in series on both sides, since this is the simplest configuration, and that the flow pattern is counter-current.
- 2) We also place the benzene in the inner pipe (however, either fluid could be placed in the inner pipe).

* اول شي نساخه assumptions :

- يعرض بالاول اننا connection عبارة عن series و parallel flows لـ

- يعرض ان inner & outer fluid حسب قواعد سايكس .

* من اسهل يتم عن طريق Try & error

First trial

- a) Fluid properties at the average stream temperatures are obtained from Figures A.1 and A.2, and Table A.15.

Fluid property	Benzene ($t_{ave} = 90^\circ\text{F}$)	Aniline ($T_{ave} = 125^\circ\text{F}$)
μ (cp)	0.55	2.0
C_p (Btu/lbm $\cdot$ $^\circ\text{F}$)	0.42	0.52
k (Btu/h $\cdot$ ft $\cdot$ $^\circ\text{F}$)	0.092	0.100

- b) Determine the heat load and an energy balances on the two streams

$$q = (\dot{m}C_p\Delta T)_B = 10,000 \times 0.42 \times$$

$$252,000 = (\dot{m}C_p\Delta T)_A = \dot{m}_A \times 0.5$$

$$\dot{m}_A = 9692 \text{ lb/h}$$


* لنسخدم energy balance

من المعطيات المعطى اننا نضع باقي المتغيرات

mass flowrate of other fluid : فنس

(c) Calculate the LMTD.

$$\Delta T_{lm} = \frac{40 - 30}{\ln(40/30)} =$$



(d) Calculate h_i assuming $\phi_i = 1.0$. $\Rightarrow$ لند و تدریس

* properties of inner pipe:

1.25 in schedule 40

$$D_i = 1.38 \text{ in}$$

$$D_o = 1.66 \text{ in}$$

$$D_i = 1.38/12 = 0.115 \text{ ft (from Table B.2)}$$

$$Re = \frac{4\dot{m}}{\pi D_i \mu} = \frac{4 \times 10,000}{\pi \times 0.115 \times 0.55 \times 2.419} = 83,217 \Rightarrow \text{turbulent flow}$$

تدفیق turbulent در این حالت


$$h_i = \frac{k}{D_i} \times 0.023 Re^{0.8} Pr^{1/3}$$

design

لند و تدریس
laminar & transition

$$h_i = \frac{0.092}{0.115} \times 0.023 (83,217)^{0.8} \left(\frac{0.42 \times 0.55 \times 2.419}{0.092} \right)^{1/3}$$

$$h_i = 290 \text{ Btu/h} \cdot \text{ft}^2 \cdot ^\circ\text{F}$$



$D_{eq} = D_{in} \text{ of outer tube} - D_{out} \text{ of inner tube}$

$$D_{eq} = 2.067 - 1.66 = 0.407 \text{ in}$$

(e) Calculate h_o assuming $\phi_o = 1.0$. $\Rightarrow$ لند و تدریس

* properties of outer pipe:

2 in schedule 40

$$D_i = 2.067 \text{ in}$$

$$D_o = 2.375 \text{ in}$$

$$\left. \begin{array}{l} D_2 = 2.067 \text{ in.} \\ D_1 = 1.660 \text{ in.} \end{array} \right\} \text{ (from Table B.2)}$$

$$D_e = D_2 - D_1 = \frac{2.067 - 1.660}{12} = 0.0339 \text{ ft}$$

$$\text{flow area} \equiv A_f = \frac{\pi}{4} (D_2^2 - D_1^2) = 0.00827 \text{ ft}^2$$


$$Re = \frac{D_e (\dot{m}/A_f)}{\mu} = \frac{0.0339 \times (9692/0.00827)}{2.0 \times 2.419} = 8212 \Rightarrow \text{transition flow}$$

Using the Hausen equation with $[1 + (D_e/L)^{2/3}] = 1.0$ gives:

$$h_o = \frac{k}{D_e} \times 0.116 [Re^{2/3} - 125] Pr^{1/3}$$

$$= \frac{0.1}{0.0339} \times 0.116 \times [(8212)^{2/3} - 125] \left(\frac{0.52 \times 2.0 \times 2.419}{0.1} \right)^{1/3}$$

$$h_o = 283 \text{ Btu/h} \cdot \text{ft}^2 \cdot ^\circ\text{F}$$



temperature.

$$T_w = \frac{h_i t_{ave} + h_o (D_o/D_i) T_{ave}}{h_i + h_o (D_o/D_i)}$$

$$T_w = \frac{290 \times 90 + 283 (1.66/1.38) \times 125}{290 + 283 \times (1.66/1.38)}$$

$$T_w = 108.9^\circ\text{F}$$

- (g) Calculate ϕ_i and ϕ_o , and corrected values of h_i and h_o .
From Figure A.1, at 108.9°F , $\mu_B = 0.47$ cp and $\mu_A = 2.4$ cp. Therefore,

$$q_{loss} = q_{accept}$$

$$h_o A (T_{avg} - T_w) = h_i A (T_w - t_{avg})$$

$$h_o A T_{avg} - h_o A T_w = h_i A T_w - h_i A t_{avg}$$

$$h_i A t_{avg} + h_o A T_{avg} = h_i A T_w + h_o A T_w$$

$$T_w = \frac{h_i t_{avg} + h_o T_{avg} (D_o/D_i)}{h_i + h_o (D_o/D_i)}$$

$$\phi_i = (0.55/0.47)^{0.14} = 1.0222$$

$$\phi_o = (20/2.4)^{0.14} = 0.9748$$

$$h_i = 290(1.0222) = 296 \text{ Btu/h} \cdot \text{ft}^2 \cdot ^\circ\text{F}$$

$$h_o = 283(0.9748) = 276 \text{ Btu/h} \cdot \text{ft}^2 \cdot ^\circ\text{F}$$

T_w is used as
corrected value
 $n: \Delta h_o$
 $h_i = \phi_i h_i$
 $h_o = \phi_o h_o$

D_o & $D_i \Rightarrow$ for inner tube
wall surface of inner tube

- (h) Obtain fouling factors. For liquid organic process chemicals such as benzene and aniline, a value of $0.001 \text{ h} \cdot \text{ft}^2 \cdot ^\circ\text{F}/\text{Btu}$ is appropriate.
(i) Compute the overall heat-transfer coefficient.

$$U_D = \left[\frac{D_o}{h_i D_i} + \frac{D_o \ln(D_o/D_i)}{2k} + \frac{1}{h_o} + \frac{R_{Di} D_o}{D_i} + R_{Do} \right]^{-1}$$

$$U_D = \left[\frac{1.66}{296 \times 1.38} + \frac{(1.66/12) \ln(1.66/1.38)}{2 \times 9.4} + \frac{1}{276} + \frac{0.001 \times 1.66}{1.38} + 0.001 \right]^{-1}$$

$$U_D = 89 \text{ Btu/h} \cdot \text{ft}^2 \cdot ^\circ\text{F}$$

- (j) Calculate the required surface area and number of hairpins.

$$q = U_D A \Delta T_{in}$$

$$A = \frac{q}{U_D \Delta T_{in}}$$

$$A = \frac{252,000}{89 \times 34.76} = 81.5 \text{ ft}^2$$



* Number of hairpins =

$$\frac{\text{Total length}}{\text{length of one hair pin}} = \frac{187.4}{(16 \times 2)}$$

$$5.9 \approx 6$$

الرقم الذي بعده
5 < 0.5 - يقرب الرقم للرقم الذي بعده
6 ≈ 5.6 or 5.7 or 5.8

From Table B.2, the external surface area per foot of 1.25-in. schedule 40 pipe is 0.435 ft^2 . calculate U_D .

$$L = \frac{81.5}{0.435} = 187.4 \text{ ft}$$

12 ft of pipe,

$$\text{Number of hairpins} = \frac{187.4}{32} = 5.9 \Rightarrow 6$$

$$A = \pi D_o L$$

$$A = \pi \left(\frac{1.66}{12} \right) L$$

$$L = \frac{A}{\pi (1.66)}$$

$$L = 187.4 \text{ ft}$$

(k) Calculate the pressure drop for the benzene stream (inner pipe).
The friction factor is calculated from Equation (4.8):

$$f = 0.3673 Re^{-0.2314} = 0.3673 (83,217)^{-0.2314}$$

$$f = 0.0267$$

$$A_f = 0.0104 \text{ ft}^2 \quad (\text{Table B.2})$$

$$G = \dot{m}/A_f = 10,000/0.0104 = 961,538 \text{ lbm/h} \cdot \text{ft}^2$$

The pressure drop in the straight sections of pipe is calculated using Equation (4.5):

$$\begin{aligned} \Delta P_f &= \frac{f L G^2}{7.50 \times 10^{12} D_{is} \phi} \\ &= \frac{0.0267 (6 \times 32) (961,538)^2}{7.50 \times 10^{12} (1.38/12) \times 0.879 \times 1.022} \\ \Delta P_f &= 6.1 \text{ psi} \end{aligned}$$

The pressure drop in the return bends is obtained from Equation (4.12):

$$\begin{aligned} \Delta P_r &= 1.6 \times 10^{-13} (2N_{HP} - 1) G^2 / s \\ &= 1.6 \times 10^{-13} (2 \times 6 - 1) (961,538)^2 / 0.879 \\ \Delta P_r &= 1.85 \text{ psi} \end{aligned}$$


Since the nozzle losses associated with the inner pipes are negligible, the total pressure drop, ΔP_i , is:

$$\Delta P_i = \Delta P_f + \Delta P_r = 6.1 + 1.85 = 7.95 \approx 8.0 \text{ psi}$$

< 20 psi

حاج في مسكنا

هذا بينا بشفوف DP لـ inline



- ne stream
Equation 11
- (1) Calculate the pressure drop for the aniline stream (annulus).
The friction factor is calculated from Equation (4.8):

$$f = 0.3673 Re^{-0.2314} = 0.3673 (8212)^{-0.2314}$$

$$f = 0.0456$$

$$G = \dot{m}/A_f = 9692/0.00827 = 1,171,947 \text{ lbm/h} \cdot \text{ft}^2$$

The pressure drop in the straight sections of pipe is again calculated using Equation (4.5) with the pipe diameter replaced by the equivalent diameter:

$$\Delta P_f = \frac{f L G^2}{7.50 \times 10^{12} D_{es} \phi}$$

$$= \frac{0.0456 (6 \times 32) (1,171,947)^2}{7.50 \times 10^{12} \times 0.0339 \times 1.022 \times 0.9748}$$

$$\Delta P_f = 47.5 \text{ psi} > 20 \text{ psi}$$

Since this value greatly exceeds the allowed pressure drop, the minor losses will not be calculated. This completes the first trial.

* دل قاتل بجي Switch ماكن بجي
 كذا في Benzene inner
 Benzene outer
 annulus inner & outer
 * دل قاتل بجي Switch ماكن بجي
 Benzene inner
 Benzene outer
 annulus inner & outer
 * دل قاتل بجي Switch ماكن بجي
 Benzene inner
 Benzene outer
 annulus inner & outer


Note

In summary, there are two problems with the initial configuration of the heat exchanger:

- I. The pressure drop on the annulus side is too large.
- II. The Reynolds number in the annulus is less than 10,000.

Since the dimensions of the hairpins are fixed in this problem, there are relatively few options for modifying the design. Two possibilities are:

- Switch the fluids, i.e., put the aniline in the inner pipe and the benzene in the annulus.
- Connect the annuli in parallel.




- The effects of these changes on the Reynolds numbers and pressure drops can be estimated as follows:

Try Method 1

- Switch the fluids. Since the flow rates of the two streams are approximately the same, the Reynolds numbers are essentially inversely proportional to the viscosity. Thus,

Handwritten: correction for Re $\left\{ \begin{array}{l} Re_i \rightarrow 83,217(0.55/2.0) \cong 23,000 \\ Re_o \rightarrow 8212(2.0/0.55) \cong 30,000 \end{array} \right.$



Hence, switching the fluids will result in fully turbulent flow on both sides of the exchanger. To estimate the effect on pressure drops, assume that the number of hairpins does not change. Then the main factors affecting ΔP are f and s . Hence,

$$\Delta P \sim f/s \sim Re^{-0.2314} s^{-1}$$

Handwritten: $f \Rightarrow$ function on Re

$$\Delta P_{f,i} \rightarrow 6.1(23,000/83,000)^{-0.2314}(1.022/0.879)^{-1} \cong 7 \text{ psi}$$

$$\Delta P_{f,o} \rightarrow 47.5(30,000/8200)^{-0.2314}(0.879/1.022)^{-1} \cong 41 \text{ psi}$$

Handwritten: لا في مشكلة بي 41 psi من 20

Clearly, switching the fluids does not reduce

Handwritten notes on a yellow sticky note:
 * اصل الـ 41 psi كـ splitting لـ aniline
 كيف نـ 41 psi كـ 7 psi؟
 عن طريق 41 psi connection لـ aniline
 parallel ، ممكن في 41 psi لـ parallel
 ينقسم لـ inlet إلى جزئين -
 $m^1 = \frac{1}{2} m^2$

Try method 2

- Connect the annuli in two parallel banks. This change will have no effect on the fluid flowing in the inner pipe. For the fluid in the annulus, however, both the flow rate and the length of the flow path will be halved. Therefore,

Handwritten: $Re_o \rightarrow 8212 \times 1/2 \cong 4100$
 $Re \propto m$

Assuming that the number of hairpins does not change,

Handwritten: Splitting ΔP $20 \text{ psi} > 7 \text{ psi}$

$$\Delta P_{f,o} \sim fG^2L$$

$$\Delta P_{f,o} \rightarrow 47.5(4100/8200)^{-0.2314}(1/2)^2(1/2) \cong 7 \text{ psi}$$

- Apparently this modification will take care of the pressure-drop problem, but will push the Reynolds number further into the transition region.
- Although neither modification by itself will correct the problems with the initial design, in combination they might. Hence, we consider a third alternative.

Try method 3

- Switch the fluids and connect the annuli in two Reynolds numbers will become:

$$Re_i \cong 23,000$$

$$Re_o \cong 15,000$$

$$30000/2$$

The pressure drops will become (assuming no change in the

$$\Delta P_{f,i} \cong 7 \text{ psi}$$

$$\Delta P_{f,o} \rightarrow 47.5(15,000/8200)^{-0.2314} (1/2)^2 (1/2) (0.879/1.022) \cong 6 \text{ psi}$$

It appears that this alternative will meet all design requirements. However, it is necessary to perform the detailed calculations because h_i , h_o and the mean temperature difference will all change, and hence the number of hairpins can be expected to change as well.

Second trial

* با این فرضیات در مسکن DP transition و تدریجاً تغییر می‌دهیم

- Benzene با جریان (annulus) و aniline با جریان
- انتقال در این دو جریان با هم یک parallel
دریافت می‌شود که در این صورت تغییر

Second trial

- a) Calculate the LMTD correction factor for the series/parallel configuration. Aniline in the inner pipe is the series stream and benzene in the annulus is the parallel stream. "See the previous figure for connection".

parallel) correction) بسبب (در ΔT_m)

$$\left\{ \begin{array}{l} T_a = 150^\circ\text{F} \quad t_a = 60^\circ\text{F} \\ T_b = 100^\circ\text{F} \quad t_b = 120^\circ\text{F} \\ P = (t_b - t_a) / (T_a - t_a) = (120 - 60) / (150 - 60) = 0.6667 \\ R = (T_a - T_b) / (t_b - t_a) = (150 - 100) / (120 - 60) = 0.8333 \\ x = 2 \text{ (number of parallel branches)} \end{array} \right.$$

Substituting into Equation (4.16) gives:

$$F = \left[\frac{(0.8333 - 2)}{2(0.8333 - 1)} \right] \ln \left[\frac{(1 - 0.6667) / (1 - 0.6667 \times 0.8333)}{(0.8333 - 2)} \right] + \left(\frac{2}{0.8333} \right)$$

$$F = 0.836$$

* فرض می‌کنیم مسکن و عدد و انتقالی transition
کمی بی‌اثر است و می‌تواند
با قطر 1/2 splitting این عملیات می‌تواند
است switch. جهت تغییر از Benzene
1 annuli و 1 aniline با جریان



Shell-and-tube Exchanger 5

Complete Design Procedure



Hydraulic Calculations

• Tube-side pressure drop

(main) ←

$$\Delta P_f = \frac{f n_p L G^2}{7.50 \times 10^{12} D_i s \phi}$$

where

f = Darcy friction factor (dimensionless)

L = tube length (ft)

G = mass flux (lbm/h · ft²)

D_i = tube ID (ft)

s = fluid specific gravity (dimensionless)

ϕ = viscosity correction factor (dimensionless)

= $(\mu/\mu_w)^{0.14}$ for turbulent flow

= $(\mu/\mu_w)^{0.25}$ for laminar flow

Note the effect of number of tube passes, n_p

return ←

$$\Delta P_r = 1.334 \times 10^{-13} \alpha_r G^2 / s$$

number of
velocity heads,
See table to get it.

* Note:

n_p = number of tube passes

L = tube length

$n_p L$ = total length of tube

$$f = 0.4137 Re^{-0.2585} \text{ turbulent } Re \geq 3000$$

$$f = \frac{64}{Re} \text{ Laminar}$$

* ΔP :
- ΔP لبيسي في tube
- ΔP في headers و return
- ΔP في Nozzle

Number of Velocity Heads, α_r , Allocated for Minor Losses on Tube Side

Flow regime	Regular tubes	U-tubes
Turbulent	$2n_p - 1.5$	$1.6n_p - 1.5$
Laminar, $Re \geq 500$	$3.25n_p - 1.5$	$2.38n_p - 1.5$

• Nozzle pressure loss

No. of shells

$$10^{-13} N_s G_n^2 / s \text{ (turbulent flow)}$$

$$10^{-13} N_s G_n^2 / s \text{ (laminar flow, } Re_n \geq 100)$$

Re_n are the mass flux and Reynolds number

$$\Delta P_{tot} = \Delta P_f + \Delta P_r + \Delta P_n$$

range ← بعد ΔP_{tot} مع (allowance)

ask : believe & recieve

• Shell-side pressure drop

$$\Delta P_f = \frac{f G^2 d_s (n_b + 1)}{7.50 \times 10^{12} d_e s \phi}$$

number of crosses

where

f = friction factor (dimensionless)

G = mass flux = $\dot{m}/a_s$ (lbm/h · ft²)

a_s = flow area across tube bundle (ft²)

= $d_s C' B / (144 P_T)$

d_s = shell ID (in.)

C' = clearance (in.)

B = baffle spacing (in.)

P_T = tube pitch (in.); replaced by $P_T/\sqrt{2}$ for 45° tube layout

n_b = number of baffles

d_e = equivalent diameter from Figure 3.12 (in.)

s = fluid specific gravity

ϕ = viscosity correction factor = $(\mu/\mu_w)^{0.14}$


ΔP_f = pressure drop (psi)

* The Friction Factor Function


on:

- Re

- $B \Rightarrow$ baffle space



the following figure



Note: For use in the previous Equation values from this figure must be

Tube-Count Tables

⇒ standard based on tube size & pitch & Cores (TEMA)

Table C.1 Tube Counts for 5/8-in. OD Tubes on 13/16-in. Square Pitch

Shell ID (in.)	TEMA P or S				TEMA U		
	Number of passes						
	1	2	4	6			
8	55	48	34	24			
10	88	78	62	56			
12	140	138	112	100	1		
13.25	178	172	146	136	1		
15.25	245	232	208	192	2		
17.25	320	308	274	260			
19.25	405	392	352	336	4		
21.25	502	484	442	424	5		
23.25	610	584	536	504	6		
25	700	676	618	600	7		
27	843	812	742	716	8		
29	970	942	868	840	998	956	920
31	1127	1096	1014	984	11		
33	1288	1250	1148	1118	13		
35	1479	1438	1308	1270	14		
37	1647	1604	1520	1480	16		
39	1840	1794	1700	1664	18		
42	2157	2112	2004	1968	21		
45	2511	2458	2326	2288	25		
48	2865	2808	2686	2656	29		
54	3656	3600	3462	3404	37		
60	4538	4472	4310	4256	46		

• designer's choice
• OD & pitch

→ total number of tubes

$$\text{Surface area total} = \text{total number of tubes} \times \text{surface of one tube}$$

• total surface area

$$q = h A \Delta T_m$$

$$A = \text{total surface area} = \frac{q}{h \Delta T_m}$$

total number of tubes
• (P or S & U) code
• number of passes
• number of tubes
Shell (ID)

OD Tubes on 15/16-in. Triangular Pitch

M	TEMA P or S				TEMA U			
	Number of passes				Number of passes			
	1	2	4	6	2	4	6	
34	24	34	32	16	18	32	24	24
52	50	60	62	52	44	64	52	52
12	94	96	109	98	78	98	88	78
13.25	124	112	126	120	106	126	116	108
15.25	166	168	183	168	146	180	160	148
17.25	228	220	237	228	202	238	224	204
19.25	290	280	297	286	258	298	280	262
21.25	364	348	372	356	324	370	352	334
23.25	430	420	450	430	392	456	428	404
25	512	488	518	498	456	534	500	474
27	602	584	618	602	548	628	604	570
29	704	688	729	708	650	736	712	668
31	814	792	843	812	744	846	812	780
33	944	920	962	934	868	972	928	904
35	1062	1036	1090	1064	990	1060	1008	1008
37	1200	1168	1233	1196	1132	1238	1200	1152
39	1338	1320	1365	1346	1266	1390	1336	1290
42	1578	1552	1611	1580	1498	1632	1568	1524
45	1830	1800	1875	1834	1736	1882	1820	1770
48	2106	2060	2132	2100	1964	2152	2092	2044
54	2682	2660	2730	2684	2536	2748	2680	2628
60	3360	3300	3395	3346	3228	3420	3340	3286
66	4088	4044						
72	4902	4868						
78	5786	5740						
84	6766	6680						
90	7832	7708						
96	8896	8844						
108	11336	11268						
120	14080	13984						

Design Guidelines

* لدرج قس ا design ادرج طبع ا fluid
& operating condition (T & P)

* قواعد عامه في ا design

• Fluid placement

❖ as given before.

metal في ا في ا metal

❖ corrosion and fouling very important factors that affect the fluid placement. Corrosive fluids should be placed on the tube side.
 * الفلدة التي يتسبب fouling & corrosion أكثر يدرج في ا tube side

❖ Fluids that are heavy fouler should be placed on the tube side because it is (usually) easier to clean deposits from the interior surfaces of the tubes than from the exterior surfaces.

❖ Cooling water is usually placed in the tubes due to its tendency to corrode carbon steel and to form scale, which is difficult to remove from the exterior tube surfaces.

❖ See text for details.

• Tubing selection

common

➤ The most frequently used tube sizes are 3/4 and 1 in.

➤ For water service, 3/4 in., 16 BWG tubes are recommended.

➤ For oil (liquid hydrocarbon) service, 3/4 in., 14 BWG tubes are recommended if the fluid is non-fouling, while 1 in., 14 BWG tubes should be used for fouling fluids.

➤ Tube lengths typically range from 8 to 30 ft, and sometimes longer depending on the type of construction and the tubing material.

➤ A good value to start with is 16 or 20 ft.



ترتيب tubes

• Tube layout (square or triangular)

✓ the most commonly used tube layouts are either triangular or square, with a pitch of 1.0 in. (for 3/4 in. tubes) or 1.25 in. (for 1-in. tubes).

* بعض المعطيات لـ تصميم نظام نقل الحرارة هي :
mass flowrate of fluids &
 T_{in} & T_{out} & P
في معادلات التصميم

* المعطيات التي قد تحتاجها لاستخدام H-E :
- cooling & reheating
heat recovery

* Note :
- cooling water $\Rightarrow$ cooling
- steam $\Rightarrow$ reheating

* Initial configuration :

- OD tubes
- Pitch
- length

تعتبر هذه الافتراضات (assumption) في التصميم

Design Strategy

* كيف نبدأ في التصميم :

Shell-and-tube design is an inherently iterative process, the main steps of which can be summarized as follows:

- Obtain an initial configuration for the heat exchanger. This can be accomplished by using the preliminary design procedure as given in previous sections to estimate the required heat-transfer surface area, along with the design guidelines and tube-count tables discussed above to completely specify the configuration.
- Rate the design to determine if it is thermally and hydraulically suitable.
- Modify the design, if necessary, based on the results of the rating calculations.
- Go to step (b) and iterate until an acceptable design is obtained.

بدي أولية الترخ مع إقيم المسوح ، قبل
بدي الترخ DP مع الحسابات من يقع ضمن range المسوح
ويتم تعديل التصميم في التصميم حتى نحصل على design المطلوب

The design procedure is illustrated
in the following examples

See text Ch. 5 and
Read these examples

اجباري

* آخر شيء مطلوب من الهندسة هو يقدم summery sheet تحتوي على جميع خواص tubes & fluid
مثل :

hot fluid

cold fluid

OD

pitch

length

U_c

U_D

ID shell

number of baffles

⋮




* Cross Flow Exchanger and Exchanger effectiveness:

1 - Cross Flow mixed-unmixed flow:

Cross $\Rightarrow$

Heating or cooling fluid $\perp$ Gas flow

90° = 90°



1. unmixed & mixed

- mixed $\Rightarrow$ "isothermal fluid"

- unmixed $\Rightarrow$ "special channel"

* Gas flow $\Rightarrow$ over tubes $\Rightarrow$ special channel

mix

* Heating or cooling fluid $\Rightarrow$ pipes $\Rightarrow$ unmixed




2 Cross flow exchanger both fluids unmixed

* Cross $\Rightarrow$ Gas flow $\perp$
Heating or cooling fluid

* both fluids unmixed

in channel of Gas flow $\perp$ Heating or cooling in a series of pipes $\perp$ fluid



Air conditioning system is H.E. so get rid of humidity

is fine

Surface area $\Rightarrow$ very large
unit volume

!! Compact exchanger small size slp
very large surface ratio $\perp$ vol

* Note:

- Cross flow exchanger mixed-unmixed flow $\Rightarrow$
Unfinned with one fluid mixed and the other unmixed
- Cross flow exchanger both fluids unmixed $\Rightarrow$
Finned with both fluid unmixed

* Applications - Economizers :

energy recovery في المبادل الحر


hot steam في المبادل الحر

في المبادل الحر

hot steam في المبادل الحر

في المبادل الحر

recovery energy



Cross flow mixed-unmixed

* Chart 1 (P, F) : (cross flow with both unmixed)

في المبادل الحر

stream في المبادل الحر

channel في المبادل الحر

unmixed




chart 2 Cross flow mixed-unmixed:

تقني الحسابات الحسابية بقولنا Pure counter

معامل قوت (ΔT_{me}) بر پایه F و ΔT_{me} محاسب می شود.

9 overall

$$: \ddot{O} \ddot{P} \ddot{O} : \text{H} \text{H} *$$

في صدد التفرغ الى العمل فتمت بكامله مع بعض الاعمال السببية ببقائه مع

one term $\rightarrow$ VA

* Heat Exchanger analysis : The effectiveness - NTU Method:

- This method is preferable when only inlet temperatures are known.

$$\text{efficiency} = \frac{\text{actual heat transfer}}{\text{maximum heat transfer}}$$

* P کی طرف سے validated یعنی انواع 1 H-E
سواء کا :-

- double pipe
- shell and tube
- cross flow

$q_{max} \Rightarrow$ In Counter Current

* Note:

يوجد في shell & tube q passed في q في اتجاه واحد
 في اتجاهين q في اتجاهين مختلفين

F في اتجاه واحد
 في اتجاهين F في اتجاهين مختلفين

$$q = mcp \Delta T$$

C هذا المقدار يسمى

و يسمى أيضا بـ

C_c

for cold stream

C_h

for hot stream

stream

heat capacitance $\leftarrow C$ (unit)

- Max possible heat transfer rate, q_{max} can be achieved in case of counter current flow exchanger of infinite length. But infinite length is not practical

* كيف يـ q_{max} ؟

$$q_{hot} = q_{cold}$$

$$C_h \Delta T_h = C_c \Delta T_c$$


$$\Rightarrow \text{If } C_c < C_h$$

$$\therefore \Delta T_c > \Delta T_h$$

range of temperature

$T_{h,i} - T_{c,i}$ و $T_{h,o} - T_{c,o}$

في اتجاه واحد q_{max}



* The cold fluid would be heated to inlet temperature of the hot fluid

is q_{max} $\rightarrow$ C_{min} is the smaller of C_c and C_h

C_{min} is the smaller of C_c and C_h

C_c C_h

$$\therefore q_{max} = C_{min} (T_{h,i} - t_{c,i})$$

$C_{min} = C_c$ $\rightarrow$ $\frac{1}{C_c}$ is the smaller

$$\therefore q_{max} = C_c (T_{h,i} - t_{c,i})$$

inlet temperature of the cold fluid is heated to inlet temperature of the hot fluid

2 If $C_h < C_c$

$$q_{cold} = q_{hot}$$

$$C_c \Delta T_c = C_h \Delta T_h$$

$$\therefore \Delta T_h > \Delta T_c$$

* The hot fluid would be cooled to the inlet temperature of the cold fluid.

$$q_{max} = C_{min} (T_{h,i} - t_{c,i})$$

$\rightarrow$ C_{min} is the smaller of C_c and C_h

C_{min} is the smaller of C_c and C_h

$$\therefore q_{max} = C_h (T_{h,i} - t_{c,i})$$

* In general, $q_{max} = C_{min} (T_{h,i} - t_{c,i})$

where C_{min} is equal to C_h or C_c whichever is smaller.



* Effectiveness, ϵ , is defined as the ratio of the actual heat transfer rate:

$$\epsilon = \frac{q_{\text{actual}}}{q_{\text{max}}}$$

∴ Note:

$$q_{\text{actual}} = q_c = q_h = C_c (T_{c,o} - T_{c,i}) \\ = C_h (T_{h,i} - T_{h,out})$$

حداکثر انتقال حرارت

$$\therefore \epsilon = C_h (T_{h,i} - T_{h,out}) / C_{\min} (T_{h,i} - T_{c,i})$$

or

$$\epsilon = C_c (T_{c,o} - T_{c,i}) / C_{\min} (T_{h,i} - T_{c,i})$$

یعنی بقدر اختلاف دما و ظرفیت گرمایی

گرم یا سرد stream



* Assume parallel-flow for which $C_{min} = C_h$, hence:

$$\epsilon = \cancel{C_h} (T_{h,i} - T_{h,o}) / \cancel{C_h} (T_{h,i} - t_{c,i})$$

$$\epsilon = (T_{h,i} - T_{h,o}) / (T_{h,i} - t_{c,i})$$

• If ϵ , $T_{h,i}$ & $t_{c,i}$ are known, the actual heat transfer:

$$q_{act} = \epsilon q_{max}$$

$$q_{act} = \epsilon C_{min} (T_{h,i} - t_{c,i})$$

= if unknown q_{act} is required to find T_{exit} or surface area

try & error

or guess q_{act} and T_{exit}

* For any exchanger it can be shown that

$$\epsilon = f(NTU, C_{min}/C_{max})$$

this means the ϵ function on $(NTU, C_{min}/C_{max})$

where:

$NTU \Rightarrow$ Number of transfer unit

$$NTU = UA / C_{min}$$

where:

$U \Rightarrow$ Overall heat transfer coefficient

$A \Rightarrow$ Surface area



* where :

C_{min} / C_{max} is equal to C_c / C_h or C_h / C_c , depending on the relative values of heat capacity rates.

- ϵ and NTU can be obtained from equations or charts.

* Example 10.1 *
A water-glycol mixture is heated by a hot oil in a parallel flow heat exchanger. The inlet temperatures are 15°C and 100°C, and the outlet temperatures are 40°C and 60°C. The heat capacity rates are 1.5 kW/K and 2.5 kW/K. Calculate the effectiveness and NTU of the heat exchanger.



* Example 1 :

Hot exhaust gases, which enter a finned-tube, cross flow heat exchanger at 300°C and leave at 100°C , are used to heat pressurized water at a flow rate of 1 kg/s from 35° to 125°C . The overall heat transfer coefficient based on the gas side surface area is $U_h = 100 \text{ W/m}^2 \cdot \text{K}$.

Determine the required gas-side surface area A_h using the NTU method.

* exhaust gas $\Rightarrow$

هو الغاز الناتج من احتراق الوقود

CO_2 , CO , O_2 , N_2


N_2 أكبر نسبة

* composition $\Rightarrow$ النسبة المئوية
mass or mole fraction $\Rightarrow$ النسبة المئوية

percent weight $\Rightarrow$ النسبة المئوية

pressurized water $\Rightarrow$

boiler system $\Rightarrow$ النظام




Finned tube, cross flow heat exchanger

$U_h = 100 \text{ W/m}^2 \cdot \text{K}$

Both fluids unmixed



* Assume counter



Sol:

Assumptions:

1. Negligible heat loss to the surroundings and kinetic and potential energy changes.
2. Constant properties

Properties:

$T_{c,avg} = 80^\circ\text{C}$ $c_p = 4197 \text{ J/kg}\cdot\text{K}$

$\Rightarrow$ for water

* Analysis:

The required surface area may be obtained from knowledge of the number of transfer units, which, in turn, may be obtained from knowledge of the ratio of heat capacity rates and the effectiveness.

C_{min} is not specified

To determine the minimum heat capacity rate, we begin by computing:

$$C_c = \dot{m} c_p c = \frac{1 \text{ kg}}{\text{s}} \times \frac{4197 \text{ kJ}}{\text{kg} \cdot \text{K}} = 4197 \text{ W/K}$$

Since $\dot{m}_h$ is not specified, C_h is obtained by combining the overall energy balances:

$$\dot{q}_{\text{cooled}} = \dot{q}_{\text{hot}} \Rightarrow \text{Assume no loss heat}$$

$$C_c \Delta T_c = C_h \Delta T_h$$

$$C_h = \frac{C_c \Delta T_c}{\Delta T_h} = \frac{C_c (T_{c,o} - T_{c,i})}{(T_{h,i} - T_{h,o})}$$

$$C_h = \frac{4197 \text{ W}}{\text{K}} \frac{(125 - 35) \text{ K}}{(300 - 100) \text{ K}} = 1889 \text{ W/K}$$

$$C_h < C_c$$


$$C_{min} = C_h$$

$$\dot{q}_{\text{max}} = C_{min} (T_{h,i} - T_{c,i}) = 1889 \frac{\text{W}}{\text{K}} (300 - 35) \text{ K}$$

$$\dot{q}_{\text{max}} = 5 \times 10^5 \text{ W}$$

$$\dot{q}_{\text{act}} = C_c \Delta T_c$$

$$= \frac{4197 \text{ W}}{\text{K}} (125 - 35) \text{ K} = 3.78 \times 10^5 \text{ W}$$



$$\epsilon = \frac{q_{act}}{q_{max}} = \frac{3.78 \times 10^5 \text{ W}}{5 \times 10^5 \text{ W}} = 0.755$$

$$\frac{C_{min}}{C_{max}} = \frac{1889}{4197} = 0.45$$


from figure both fluids unmixed:

$$NTU = \frac{U_n A_n}{C_{min}} = 2$$

$$A_n = \frac{2 (1889 \text{ W/K})}{100 \text{ W/m}^2 \cdot \text{K}} = 37.8 \text{ m}^2$$



* Thermodynamics:



لنفترض أن B ← نقطة في المنطقة

super heated

في المنطقة بين النقطة D و C

Saturated vapor

نفس الشيء في المنطقة بين النقطة A و D

dew point


Saturated liquid ← نفس الشيء في المنطقة بين النقطة A و D

bubble point

في المنطقة بين النقطة D و C يتم تسخين السائل ليصبح غاز

الحرارة هنا هي الحرارة الكامنة (latent heat) اللازمة لتحويل السائل إلى غاز

وهذا هو التسخين




Not change of phase $\leftarrow$ H-E $\leftarrow$ $\text{Si}^{\ominus}\text{Si}^{\ominus}$ B $\leftarrow$ radical $\times$
change of phase $\leftarrow$ condensation $\rightarrow$ gain $\rightarrow$ H-E $\leftarrow$ $\text{Si}^{\ominus}\text{Si}^{\ominus}$ D $\leftarrow$ C $\leftarrow$ radical $\times$
Not change of phase $\leftarrow$ H-E $\leftarrow$ $\text{Si}^{\ominus}\text{Si}^{\ominus}$ A $\leftarrow$ radical $\times$

i. Öffentlich

المنطق $A \wedge B$ ← تحسبها 9 كما في اسايه قبلًا :


$$q = m c_p \Delta T$$

* T-X diagram for condenser only condensation : No sub-cooling :



in the section 1. is
constant in mixture 1.
of temperature

(conclusion) const temp or u



ماہنامہ H.F. سہ ماہی

3 sections

* غالباً لا يصعب انتقال الحرارة بتقريب 3 modes حسب التي أختار
والتي هي mode 1 و mode 2 و mode 3

* modes of transfer heat :

- Conduction
- Convection
- Radiation

* كيف يمكن انتقال الحرارة by radiation ؟

$$q_{rad} = \epsilon \sigma T_s^4$$

إذا كانت T_s تؤهل إلى الفرق بيني انتقال الحرارة by radiation
أو إذا زادت T_s بيني انتقال الحرارة by radiation وبقية modes
transfer by radiation **dominante** (المهيمنة)

* modes of convection هو mode 2 و mode 3 moving fluid

* Modes of transfer heat in the condenser → Convection

بوجود moving fluid و في سطح التبريد و condensation

* شروط mode 1 : Condensation

- solid surface


- Temperature of solid surface must be below the saturation temperature

$$T_s < T_{sat}$$

* Condensation - Types and Mechanism:

- Condensation occurs when the temperature of the vapor is reduced below its saturation temperature.
- The solid surface whose temperature is below the saturation temperature of the vapor.

* لنشاهد الآن كيف يحدث التكثيف في السطح الذي هو
is Saturation temperature of vapor





التي تدخل في Condenser في
شكل feed التي عبارة عن
Sat vapor في وقتها في
التي هي في درجة حرارة
liquid التي هي في
التي هي في

في عملية التكثيف من B إلى C



- Two distinct forms of condensation:



Cover film (shell model)

- gravity + film thickness

Complete cover (contact)

partially cover of solid surface

* Film wise condensation:

- when liquid formed by condensation wets the surface.

It is more common type of condensation to occur.

general is liquid just *

- In Filmwise condensation liquid condensate forms a continuous film over the surface. this film flows down the surface under the action of gravity, shear force due to vapor flow, other forces.

: $\dot{m}$ *

condensate mass

liquid

over surface flow

- shear force

: film + μ + force *

- gravity

- shear

- buoyant


- The layer of liquid condensate acts as a barrier to heat flow due to its very low thermal conductivity and hence low heat transfer rate.

* layer of liquid acts as thermal resistance for heat transfer.

* انتقال الحرارة يكون بطيء في الطبقة السائلة.



Filmwise and dropwise Condensation



Heat transfer coefficient

$$h_{\text{film}} \ll h_{\text{drop}}$$

Condensation, ششود هودت

دوبور سطح صلب

surface (Ts < T_{sat})

(T_{sat} > T_{surface})

Filmwise Condensation: Nu

Idealizations:


- Laminar flow
- Constant properties
- Negligible subcooling of liquid
- Inertia effects negligible in momentum balance
- Vapor stationary, no drag
- Smooth liq-vap interface

velocity of liquid at surface = 0
& increase with δ

بالنسبة لزيادة δ


Cold plate

- thickness (δ)
- rate of condensation ($\dot{m}$)
- heat rate transfer




Laminar Film Condensation

• Vertical Flat surface



2-dimension



Definitions

Film thickness = δ at any z location

Width of the plate = W

Vol of element = $(\delta - y) W dz$

Types of forces acting on element

1. gravity force "+ve downward"
2. buoyancy force "-ve"
3. friction due to viscosity "-ve"

Force Balance on Element

- Gravity Force = Buoyancy + Friction

$$\rho_f \frac{g}{g_c} (\delta - y) W dz = \rho_v \frac{g}{g_c} (\delta - y) W dz + \tau_{yz} (W dz) \quad (1)$$

T_g is the sat. temp. may be $<$ ambient temp " T_∞ " or $=$ ambient temp " T_∞ "

Since $\tau_{yz} = \mu \frac{dV_z}{dy}$. Substitute in eq. 1

heat transfer $\rightarrow$ Fourier's law - mass transfer $\rightarrow$ Fick's law - $\rightarrow$ Newton's law for viscosity

and rearranging

$$\frac{dV_z}{dy} = \frac{g}{\mu g_c} (\delta - y) (\rho_f - \rho_v)$$

Integrating gives


$$V_z = \frac{g}{\mu g_c} (\rho_f - \rho_v) (\delta y - y^2/2) + C$$

B.C $y=0, V_z=0 \therefore C_1=0$

$\therefore$ velocity Profile $V_z = \frac{\delta^2 g}{\nu_f} (1 - \rho_v/\rho_f) (y/\delta - y^2/2\delta^2)$ (2)


$$\begin{aligned} \rho_f \frac{g}{g_c} (\delta - y) \omega dz &= \rho_v \frac{g}{g_c} (\delta - y) \omega dz + \tau_{yz} (\omega dz) \\ \frac{g}{g_c} (\delta - y) \omega dz (\rho_f - \rho_v) &= \mu \frac{dV_z}{dy} \\ \Rightarrow \frac{dV_z}{dy} &= \frac{g}{\mu g_c} (\delta - y) \omega dz (\rho_f - \rho_v) \end{aligned}$$

$\Rightarrow \frac{dV_z}{dy} \Rightarrow$ velocity gradient



Note

Eq. 2 can be integrated over the cross section 'normal to the direction of the Z-directed velocity V_z ' to get the mass flow rate of condensate, $\dot{m}_f$



$$\begin{aligned}
 \therefore \dot{m}_f &= \iint \rho_f V_z dA \\
 &= \int_0^w \int_0^h \frac{\rho_f g}{\nu_f} \left(1 - \frac{\rho_v}{\rho_f}\right) \left(\delta y - \frac{y^2}{2}\right) dy dx \\
 &= \frac{w \delta^3 g \rho_f}{3 \nu_f} \left(1 - \frac{\rho_v}{\rho_f}\right) \dots (3)
 \end{aligned}$$

kinematic
viscosity



Heat transfer equation

The heat flow at the wall within the area $W dz$ is given by

$$q_y = -k_f (W dz) \frac{dT}{dy} \Big|_{y=0} \Rightarrow \text{Fourier's law}$$

surface transfer for film

Assume a linear temp profile within the film varies from T_w at the wall to T_g , the saturation temp. at the liq-vap interface.

$$q_y = -k_f W dz \frac{T_w - T_g}{\delta}$$

* mechanism of heat transfer in boiler & condensor $\Rightarrow$ Convection moving fluid

The amount of condensate bet. z and $z+dz$ is given by

$$\begin{aligned} \text{Added Condensate} &= m_g \Big|_{z+dz} - m_g \Big|_z \\ \text{in } dz \\ \text{condensate in} &= \frac{dm_g}{dz} dz = \frac{dm_g}{d\delta} \cdot \frac{d\delta}{dz} dz \\ &= \frac{dm_g}{d\delta} \cdot d\delta \end{aligned}$$

from eq. 3

$$\frac{dm_g}{d\delta} \cdot d\delta = \frac{W k_f \delta^2 g}{2f} (1 - Pr_f) d\delta \Rightarrow \text{mass flowrate within differential element}$$

(4)

يجب أن يكون h_{fg} ← mass flow rate within differential element
 بقدره h_{fg} ← heat of vaporization
 Fourier's law ← بقدره h_{fg} ← heat of vaporization

Multiplying eq. 4 by h_{fg} gives q_y

$$\frac{W \rho_f \delta^2 g (1 - \rho_f / \rho_g) h_{fg} d\delta}{\rho_f g h_{fg} (1 - \rho_f / \rho_g)} = k_f W dz \frac{T_g - T_w}{\delta}$$

OR $\frac{1}{\rho_f g h_{fg} (1 - \rho_f / \rho_g)}$

$$\delta^3 d\delta = \frac{k_f \rho_f (T_g - T_w)}{\rho_f g h_{fg} (1 - \rho_f / \rho_g)} dz$$

الحد δ ← film

Integrating

$$\delta^4 = \frac{4 k_f \rho_f Z (T_g - T_w)}{\rho_f g h_{fg} (1 - \rho_f / \rho_g)} + C_1$$

B.C at $Z=0$, $\delta=0 \therefore C_1=0$

$$\therefore \delta = \left[\frac{4 k_f \rho_f Z (T_g - T_w)}{\rho_f g h_{fg} (1 - \rho_f / \rho_g)} \right]^{1/4}$$

⇒ thickness at any high

ask (5)

Express H. transfer in terms of local conv. Coeff. " h_z "

local at any point $\leftarrow h_z$ $w dz (T_w - T_f) = -k_f w dz \frac{T_f - T_w}{\delta}$

$$h_z = k_f / \delta$$

Newton's law & Fourier's law

Substituting in eq. (5)

$$h_z = k_f \left[\frac{\rho_f g h_{fg} (1 - \rho_v / \rho_f)}{4 k_f \nu_f z (T_f - T_w)} \right]^{1/4} \dots (6)$$

The Local Nusselt No is

$$Nu_z = \frac{h_z z}{k_f} = \left[\frac{\rho_f g z^3 h_{fg} (1 - \rho_v / \rho_f)}{4 k_f \nu_f (T_f - T_w)} \right]^{1/4} \dots (7)$$

Average Coeff. over the entire surface

$$\bar{h} = \frac{1}{LW} \int_0^W \int_0^L h_z dz dx$$

$w \Rightarrow$ constant

يعني مقدار ثابت

$\int_0^L h_z dz$ يعني التكامل

total length of plate

area

$$= \frac{1}{L} \int_0^L k_f \left[\frac{\rho_f g h_{fg} (1 - \rho_v / \rho_f)}{4 k_f \nu_f z (T_f - T_w)} \right]^{1/4} dz$$

Solving, we get

$$\bar{h} = \frac{4}{3} k_f \left[\frac{\rho_f g h_{fg} (1 - \rho_v / \rho_f)}{4 k_f \nu_f L (T_f - T_w)} \right]^{1/4} = \frac{4}{3} h_z \dots (8)$$

$$= 0.943 \left[\frac{k_f h_{fg} (1 - \rho_v / \rho_f)}{\nu_f L (T_f - T_w)} \right]^{1/4} \dots (8)$$

Nu based on the average coeff.

$$Nu = \frac{\bar{h} L}{k_f} = \frac{4}{3} \left[\frac{\rho_f g h_{fg} (1 - \rho_v / \rho_f) L^3}{4 k_f \nu_f (T_f - T_w)} \right]^{1/4} \dots (9)$$

condensation $\Rightarrow$ $Re < 1800 \Rightarrow$ laminar

$Re > 1800 \Rightarrow$ turbulent

$$\therefore Re = \frac{v D_h}{\nu_f}$$

v : avg. film velocity

D_h : Hydraulic diam

$$D_h = \frac{4A}{p} = \frac{4\delta W}{W} = 4\delta$$

$$\therefore Re = \frac{v (4\delta)}{\nu_f}$$


$$= \frac{\dot{m}_f}{\rho_f A} \cdot \frac{4\delta}{\nu_f} = \frac{4 \dot{m}_f \delta}{\rho_f (\delta W) \nu_f} = \frac{4 \dot{m}_f}{W \rho_f \nu_f} \dots (19)$$



(a) Vertical plate




(b) Vertical cylinder




(c) Horizontal cylinder

for laminar flow $Re < 1800$


The wetted perimeter p , the condensate cross-sectional area A_c , and the hydraulic diameter D_h for some geometries



(a) Vertical plate



(b) Vertical cylinder



(c) Horizontal cylinder

Note 1

Re can be written in terms of conv. coeff

$$\therefore q = h_L A_s (T_g - T_w) \dots \dots \dots (11)$$

where

A_s : surface area of plate in contact with the film

but

$$q = \dot{m}_f h_{fg}$$

$$\therefore \dot{m}_f = \frac{h_L A_s (T_g - T_w)}{h_{fg}} \dots \dots \dots (12)$$

Substituting into eq. (10)

$$\therefore Re = \frac{4 h_L A_s (T_g - T_w)}{W h_{fg} \rho_f \nu_f} \dots \dots \dots (13)$$

Note 2

- Experimental values of the convective coefficient can be as much as 20 % higher than those predicted by eq. (8) for laminar flow;

$$\bar{h} = 1.13 \left[\frac{\rho_f k_f^3 h_{fg} g (1 - \rho_v / \rho_f)}{\nu_f L (T_g - T_w)} \right]^{1/4}$$

20% h derived h experimental





Notes

1. Tube loading, $\Gamma = \frac{\dot{m}_f}{\pi D}$ Condensate ^{liq} per unit tube perimeter
wetted perimeter
2. Plate loading, $\Gamma = \frac{\dot{m}_f}{W}$
- ∴ $Re_\delta \text{ (tube)} = \frac{4\Gamma}{\mu_f}$
3. for a tube bundle, $\Gamma = \frac{\dot{m}_f}{N_t \pi D}$
number of tube

Film Condensation on a horizontal tube and a horizontal tube bank

- assume any pipe doesn't effect on other pipe

- Isothermal



for one tube

vertical ← $\bar{h} = 0.728 \left[\frac{g \rho_f (1 - \rho_f / \rho_g) k_f^3 h_{fg}}{\nu_f (T_g - T_w) D} \right]^{1/4}$ laminar filmwise
 where D: outside diam (15)

number of rows
For j tubes vertically above each other

← $\bar{h} = 0.728 \left[\frac{g \rho_f (1 - \rho_f / \rho_g) k_f^3 h_{fg}}{\nu_f (T_g - T_w) j D} \right]^{1/4}$
 OR
 $\bar{h}_j = \bar{h} \cdot j^{-1/4}$ (16)

Note

In practice, it is better to use index $1/6$ in stead of $1/4$

$h_l = \bar{h} \cdot j^{-1/6}$ من تا ۱/۶ به ۱/۴ تغییر دادیم
 tube bundle (17)



condensation ← $\bar{h}$ به h_l تبدیل شد

pipes ask

adar & recieve

* Film condensation within Horizontal tubes :

• for low vapor velocities, the following expression for condensation of refrigerants can be used.



$T_{gas} = T_{w,p}$ at saturated temperature

condensation in a tube conveying a two phase mixture at a low

flow rate

* نیکو دافق ۱ phase in the pipe
تجمیع ۱ liquid ۱ في bottom
vapor ۱ top في اقلی

Air condition : * من اقلی

$$Re_D = \frac{v_{avg} ID}{\mu} < 35000$$

$v_{avg} \Rightarrow$ kinematic viscosity

$ID \Rightarrow$ inside diameter

* the Chao Equation has been derived:

$$Nu_D = 0.555 \left[\frac{g \rho_f (1 - \rho_g / \rho_f) k_f^3 h_{fg}}{\mu_f (T_g - T_w) ID} \right]^{1/4}$$

where: v_{avg} is the average velocity of the vapor

ID is the inside diameter of the tube

$$h_{fg} = h_{fg} + \frac{3}{8} C_p (T_g - T_w)$$

Reynolds number evaluated at the inlet temperature

* Liquid properties at $(T_g + T_w)/2$

k_{fg} at $T_{w,p}$

* for higher flow rates, the flow becomes quite complicated. Correlations are available in the literature, however.

* في حالت نیکو multi component

کیمیائی اقلی ۱ properties

low Temperature ۱ اقلی

properties ۱ اقلی

* حالتی، اقلی:

- laminar

- بشید Re ۱۳۱۰ کی ۱۸۰۰

یکم اقلی ۱ laminar، ۱۳۱۰ کی ۱۸۰۰

توربولن ۱ turbulent

- q (heat of condensation) اقلی

$$m = q / h_{fg}$$



12th - May - 2022

* Introduction

Phase change + Convective fluid motion

* Modes of heat transfer in condensation & boiling $\Rightarrow$
convection heat transfer due to moving fluid

* Important features:

- Large heat transfer rates with small temperature differences (nearly isothermal)

$\Rightarrow$ ΔT is small, change of phase is large $\Rightarrow$ $\frac{Q}{\Delta T}$ is large


- ΔT is small

- High heat transfer coefficient
- Excellent for high heat fluxes (compact).

* Some of applications:

- Refrigeration, boilers, heat exchangers.
- Petroleum refining, chemical processing, cryogenics
physical separation of gases (N_2 , etc).

Boiling occurs when a liquid is brought into contact with a surface at a temperature above the sat temperature of the liq.



من مميزات التبريد في السوائل

* Boiling:

Is evaporation at a solid-liquid interface, and occurs when

$T_s > T_{sat}$, where T_{sat} is the temperature for liquid to

gas phase change, and is a function of pressure.

e.g., for water at 1 atm, $T_{sat} = 100^\circ\text{C}$ & $h_{fg} = 2256.4 \text{ kJ/kg}$

• In boiling, the rate equation (Newton's law of cooling) is:

$$q'' = h(T_s - T_{sat}) = h \Delta T_e$$

where: ΔT_e is the excess temperature

* Modes of Boiling:

Boiling can be classified as:

1- Pool Boiling

quiescent liquid, motion near the surface is due to free convection

and mixing due to bubble growth and detachment.

* liquid motion near surface.

تيكه current (تيارات) شيتت ل.

density difference (natural convection)

دتكور فقاعات بالقرب من السطح بعدد تيقن

فصل السائل إلى سطح السائل إلى أن تفتت من السطح

وتحول إلى vapor



* سائل هادي الحركة، الحركة بالقرب من

السطح ثابتة عن الحمل الحراري والاستقرار

بسبب تفاوت الكثافات وانفصالها.

* الفقاعات تزداد بحجمها (coalescence)

لثقل (تلتصق الفقاعات معاً).



2- forced convection:



Boiling (flow boiling)

- external means drive fluid motion

is through pipes تحت
under pressure

boiler system +

flow boiling



Pool boiling

* Modes of boiling:

Boiling can also be classified, alternatively, as:


- Subcooled (local) boiling

• T_{liq} is below T_{sat}

• bubbles formed at the solid surface condense in the liquid.

* الفقاعات مابتوص سطح السائل

لذا تتكاثف قبل ان تفرج الى السائل



* درجة حرارة السائل $<$ درجة حرارة (surface)

* يتكون فقاعات بالقرب من السطح الصلب ، درجة

حرارة الفقاعات عالية ، تتفكك قبل ان تفرج


لذا تتكاثف قبل ان تفرج الى السائل

درجة حرارة السائل ، يحدث تقصير حجم الفقاعات ثم تتدثر

- Saturated boiling

T_{liq} is slightly $>$ T_{sat}

• bubbles can rise and escape



* الفقاعات تافقظ على السطح ، ودرجة السائل

التي هي (على سطح السائل) ، بعد ذلك يتغير

وتتولد الى السطح

* Dimensionless Parameter:

- Grashof like number, $[\rho g (\rho_l - \rho_v) L^3] / \mu^2$
buoyancy force $\propto \rho g$

* Pool boiling:

Pool boiling is boiling at the surface of a body in an extensive pool of quiescent liquid.

• Variables:

- heat flux
- thermophysical properties (liquid & vapor)
- surface material and finish
- size of the heated surface.


• Two possibilities (control & application)

- Temperature control درجه حرارت
- Heat flux control



* Different boiling regimes in pool boiling:

* Control of temperature: $\Delta T_e \rightarrow$ بکن




$\Delta T_e \rightarrow$ فرق

Natural convection system ۱

current ۲

Density difference ۳



مع بک ΔT_e بک


generation of bubbles

تولید حباب

تولید

بک

ΔT_e بک



c Transition boiling

vapor pockets

Heating

$\Delta T_e = 80^\circ\text{C}$

Solid surface


۱. بک

vapor pockets

(insulation) ۲

$\Rightarrow$ Resistance of heat transfer

ask : believe & recieve



في فيلم بخار

(insulation)

Resistance of heat transfer

* في المخطط (q'' vs ΔT_e) في 4 أنواع

- In Natural convection & Nucleate boiling

q'' (W/m^2) $\uparrow$ with $\Delta T_e \uparrow$

(Maximum critical heat flux q''_{max})

- In transition boiling

q'' $\downarrow$ with $\Delta T_e \uparrow$

المسبب تكون جيوب البخار pockets

(D) عند الحد الأدنى من q''

(Leidenfrost point)

- In film boiling

$q'' \uparrow$ with $\Delta T_e \uparrow$

بترجع الحرارة ترتفع مع زيادة ΔT_e وليس كذلك طريقة انتقال الحرارة by radiation

* heat transfer by radiation from hot solid surface.

تستمر لدرجة بالارتفاع مع ΔT إلى أن يصل إلى نقطة عتية (E) تسمى (burn out) لنقل الحرارة، النقطة C

* Pool Boiling correlations:

1- Nucleate boiling

$$q = \mu_L h_{fg} \left[\frac{g(P_L - P_v)}{\sigma} \right]^{1/2} \left[\frac{C_{p,L} (T_s - T_{sat})}{C_{s,f} h_{fg} Pr_L^n} \right]^3$$

where:

$\mu_L \Rightarrow$ viscosity of liquid

$h_{fg} \Rightarrow$ heat of vaporization

$P_L \Rightarrow$ density of liquid

$P_v \Rightarrow$ " " vapor

$\sigma \Rightarrow$ surface tension

$C_{p,L} \Rightarrow$ heat capacity of liq

$C_{s,f} \Rightarrow$ surface fluid combination

n & $C_{s,f}$ يعتمدان على نوع السطح الصلب

2. Critical heat flux:


$$q_{max} = \frac{\pi}{24} h_{fg} \rho_L \left[\frac{g \sigma (\rho_L - \rho_v)}{\rho_v^2} \right]^{1/4} \left(\frac{\rho_L + \rho_v}{\rho_v} \right)^{1/2}$$

$$\Delta T \approx 15-30$$

3. Minimum heat flux

$$q_{min} = 0.09 \rho_L h_{fg} \left[\frac{g \sigma (\rho_L - \rho_v)}{(\rho_L + \rho_v)^2} \right]^{1/4}$$

4. Film boiling:



$$Nu = \frac{\bar{h}_{conv} \cdot D}{k_v} = C \left[\frac{g (\rho_L - \rho_v) h'_{fg} D^3}{\nu_L k_L (T_s - T_{sat})} \right]^{1/4}$$

where:

$C = 0.62$ for horz cylinder

$C = 0.67$ for sphere

$$h'_{fg} = h_{fg} + 0.8 C_p \nu (T_s - T_{sat})$$

where:

$\bar{h}_{conv}$: average boiling H.T.C in absence of radiation.

radiation effects is

At high temperature. $T_s \gg 300^\circ\text{C}$: radiation mode affect the process : Total H.T.C is

$$(\bar{h})^{4/3} = (\bar{h}_{\text{conv}})^{4/3} + (\bar{h}_{\text{rad}})^{4/3}$$

If $\bar{h}_{\text{rad}} < \bar{h}_{\text{conv}}$

$$\bar{h} = \bar{h}_{\text{conv}} + \frac{3}{4} \bar{h}_{\text{rad}}$$

The effective rad. coeff. $\bar{h}_{\text{rad}}$ is obtained from

$$\bar{h}_{\text{rad}} = \frac{\varepsilon \sigma (T_s^4 - T_{\text{sat}}^4)}{(T_s - T_{\text{sat}})}$$

where:

σ : Stefan - Boltzmann const.

ε : emissivity of the solid.

Note:

It is recommended to operate near or below the temp. excess that corresponds to critical flux "peak point".



* Radiation

All objects with a temperature above absolute zero radiate.

* Radiation propagates

in vacuum.

(No medium)

* heat transfer by

radiation at high temperature

* يتوقف / radiation عنها يقع درجة حرارة الجسم = abs zero

* تأثير انتقال الحرارة بالإشعاع عند درجات حرارة عالية جداً (موجس أنشأ radiation)

* يعتمد انتقال الإشعاع على T of surface

* جميع أنواع انتقال الحرارة - موجس فقط

(radiation & convection &)

convection


وكمزج كمزج mode مسيطر أكثر من غيره.

* Physical concepts:

- Mechanism of radiation:

- 1- Electromagnetic waves ~ Solar radiation, X-ray radio waves
- 2- Photons a discrete packets of energy.

* Radiation propagates in vacuum



$$q_{rad} \Rightarrow q + q_{from\ sur\ to\ sur}$$

* تنتقل الحرارة بالإشعاع في طريق انتقال الجسيمات موجبات كهرومغناطيسية تتحرك بالانقسام وتتحول إلى حرارة.

أو عبر طريق الفوتون.

ask :: believe & recieve

- The wave nature of thermal radiation implies that the wave length - λ should be associated with the frequency of radiation - ν . The relation between λ & ν is given by:

$$\lambda = c / \nu$$

where:

$c \Rightarrow$ سرعة الانتشار = 3×10^8 m/s $\Rightarrow$ speed of propagation

- Thermal radiation is the radiation due to the temperature of body.

* Spectrum of electromagnetic radiation:

الطول الموجي = $(10^{-1} - 10^2)$ Mm $\Rightarrow$ (الطول الموجي للحرارة)


Thermal radiation

الطول الموجي المرئي (visible) $\leftarrow (0.4 - 0.7) \mu m$

* Characteristics of blackbody (ideal):

- For a given surface temperature & wavelength, no surface can emit more radiation than a black body, a black body is a perfect emitter. (الحرارة المبعثرة 100%)

- A black body is absorb all incident radiation regardless of its direction and wavelength, a black body is a perfect absorber.




* A black body emits radiation in all directions it is a diffuse emitter.

* Cavity model of a black body:

القوة الشمسية، الإشعاع، الإشعاع

* Absorption, reflection & Transmission by Real surface:



$$* G_{\lambda} = G_{\lambda, \text{abs}} + G_{\lambda, \text{ref}} + G_{\lambda, \text{tr}}$$

$$\frac{G_{\lambda, \text{abs}}}{G_{\lambda}} = \text{absorptivity}$$

$$\frac{G_{\lambda, \text{ref}}}{G_{\lambda}} = \text{reflectivity}$$

$$\frac{G_{\lambda, \text{tr}}}{G_{\lambda}} = \text{transmissivity}$$

$$\frac{1}{1} = \text{perfect absorber}$$

for black surface

$$\Rightarrow \text{absorptivity} = 1$$

* The black body gives max emissive or max absorption

* Black body emissive power:

$$E_{b\lambda}(T) = \frac{C_1}{\lambda^5 \left[\exp(C_2/(\lambda T)) - 1 \right]}$$

where:

$$C_1 = 2\pi h c^2 = 3.743 \times 10^8 \text{ W } \mu\text{m}^4/\text{m}^2$$

$$C_2 = 1.4387 \times 10^4 \text{ } \mu\text{m} \cdot \text{K}$$

T = absolute temp (K)

c = Speed of propagation, m/s

h = Planck's const

λ = wave length, μm

* Black body Radiation Function:

$$E_{b, 0 \rightarrow \lambda}(T) = \int_0^{\lambda} E_{b\lambda}(T) d\lambda$$

↓
band


$$f_{0\lambda}(T) = \frac{\int_0^{\lambda} E_{b\lambda}(T) d\lambda}{\int_0^{\infty} E_{b\lambda}(T) d\lambda} = \frac{\int_0^{\lambda} E_{b\lambda}(T) d\lambda}{\sigma T^4}$$

table →

* $f_{0\lambda}(T) \Rightarrow$ black body Radiation Function given in table

* over a finite - wave length band $\lambda_1 - \lambda_2$

$$P_{\lambda_1 - \lambda_2}(T) = P_{0 - \lambda_2}(T) - P_{0 - \lambda_1}(T)$$



* Example (3):

A light bulb radiates like a black body at 2800K. find the percentage of total emitted energy that lies in the visible range.

visible rang $\Rightarrow \lambda = (0.4 - 0.7) \mu m$

$$P_{\lambda_1 - \lambda_2}(T) = P_{0 - 0.7} - P_{0 - 0.4}$$

$$\lambda T = 0.7 (2800) = 1960$$

$$\lambda T = 0.4 (2800) = 1120$$

بمعرفه table 1

مقدار F

من

الكمية المنبعثة في النطاق المرئي

الكمية المنبعثة في النطاق المرئي (total) quantity emitted

$$\int_0^\infty E_{b\lambda}(T) = \sigma T^4$$

ask :: believe & recieve

* Radiation properties of surfaces

• Absorption and emission of radiation depend on:

- Type of material
- Temp or wavelength

* Type of materials

metals, wood, stone

- Opaque to thermal radiation.

شبه شفاف و شفاف

- Emission or absorption within a very short distance.

glass, water

- Semitransparent to radiation

شبه شفاف و شفاف

- penetrate into the depth

عمق


شبه شفاف و شفاف

عمق

* Note:

Most engineering materials are opaque to thermal radiation

(gray) شبه شفاف و شفاف



* Emissivity: ϵ :

$$\epsilon = \frac{\text{Energy emitted by a real surface}}{\text{Energy emitted by a black body}} \quad \left. \vphantom{\frac{\text{Energy emitted by a real surface}}{\text{Energy emitted by a black body}}} \right\} \text{ at the same temp}$$

ϵ for black body = 1

* $\epsilon = f(T, \text{wavelength } \lambda, \text{Direction})$

* Hemi spherical emissivity $\epsilon(T) \Rightarrow$ reference shape
Definition:

$\epsilon(T) = \frac{\text{Rad. flux by real body overall wavelength}}{\text{energy emitted by black body at same } T}$
"into a hemi spherical space"


$$\epsilon(T) = \frac{q(T)}{E_b(T)} \quad \text{OR}$$

$$q(T) = \epsilon(T) E_b(T) = \epsilon(T) \sigma T^4 \text{ w/m}^2$$

* Note 1:

Oxidation $\uparrow$ $\epsilon(T) \uparrow$

ϵ $\uparrow$ $\Rightarrow$ Oxidation $\uparrow$ metal $\uparrow$ is!



* Note (2) :

Spectral hemispherical emissivity ϵ_λ

at a given λ

experimental symbol $\bar{\epsilon}$

$\bar{\epsilon}$ = emissivity at a specific wavelength λ at a certain temp

* determine experimentally

* Can be used to obtain the average value of ϵ like this

$$\epsilon = \frac{\int_0^\infty \epsilon_\lambda E_{b\lambda}(T) d\lambda}{\int_0^\infty E_{b\lambda}(T) d\lambda} = \frac{\int_0^\infty \epsilon_\lambda E_{b\lambda} d\lambda}{\sigma T^4} \quad \dots //$$

look $\int_0^\infty \epsilon_\lambda E_{b\lambda}(T) d\lambda$ can be treated as band of cons ϵ

مقسمة ϵ إلى فترات بافتراض ϵ ثابت

From 0 to λ_1 $\epsilon_\lambda = \epsilon_1 = \text{cons}$

From λ_1 to λ_2 $\epsilon_\lambda = \epsilon_2 = \text{cons}$

From λ_2 to ∞ $\epsilon_\lambda = \epsilon_3 = \text{cons}$

النتيجة هي



$$\epsilon = \int_0^{\lambda_1} \frac{\epsilon_1 E_{b\lambda}(T) d\lambda}{\sigma T^4} + \int_{\lambda_1}^{\lambda_2} \frac{\epsilon_2 E_{b\lambda} d\lambda}{\sigma T^4} + \int_{\lambda_2}^{\infty} \frac{\epsilon_3 E_{b\lambda} d\lambda}{\sigma T^4}$$


$$\epsilon_1, \lambda_1, \epsilon_2, \lambda_2, \epsilon_3 \Rightarrow \text{constant}$$

$$\epsilon = \epsilon_1 \int_0^{\lambda_1} \frac{E_{b\lambda}(T) d\lambda}{\sigma T^4} + \epsilon_2 \int_{\lambda_1}^{\lambda_2} \frac{E_{b\lambda} d\lambda}{\sigma T^4} + \epsilon_3 \int_{\lambda_2}^{\infty} \frac{E_{b\lambda} d\lambda}{\sigma T^4}$$

$$\epsilon = \epsilon_1 f_{0 \rightarrow \lambda_1} + \epsilon_2 [f_{0 \rightarrow \lambda_2} - f_{0 \rightarrow \lambda_1}] + \epsilon_3 [1 - f_{0 \rightarrow \lambda_2}]$$

$$0 \rightarrow \lambda_2 + \lambda_2 \rightarrow \infty = 1 \quad \leftarrow$$

$$\lambda_2 \rightarrow \infty = 1 - 0 \rightarrow \lambda_2$$



$\Rightarrow$ knowing ϵ_1, ϵ_2 & ϵ_3 , we can obtain ϵ from the previous equation by using the table of black body radiation functions " $f_{0 \rightarrow \lambda}(T)$ ".

* Emission of Radiation:

- Monochromatic radiation $\equiv$ radiation of a single wavelength.
- A beam of thermal radiation is not monochromatic but a wide or a band of wavelengths.

(band $\Rightarrow$ wavelength λ or $\Delta\lambda$)

- At temp above $500^\circ\text{C} \Rightarrow$ heat radiation in the visible spectrum becomes significant "Red heat" and "white heat" are commonly used.

الحرارة الإشعاعية

* State of aggregation and molecular structure of the substance affect radiations

- Mono atomic and diatomic gases (O_2, N_2, Ar) radiate weakly even at high temp.

- Poly atomic gases (H_2O, CO_2) emit and absorb radiation at several wavelengths.

- Solid & liquids absorb and emit radiation over the entire spectrum in thin layers

* Radiation travels in a straight line "beam". like light


* Net energy transfer from hotter body A to cold body B.

* Mono Chromatic energy emitted by an object depends on (Temp & λ)

الطاقة الإشعاعية E في λ تعتمد على

(max) E في λ يعتمد على

تدريج E في T



* Types of Bodies :

1- Opaque body (أبيض) $\Rightarrow$ No transmission of electromagnetic radiation is possible

$$t=0 \quad \alpha + r=1$$

2- White body : any body whose surface reflects incident rays of radiation

$$\alpha=1 \quad r=1$$

اللون الأبيض في الجسم ينعكس جميع الأشعة المرئية ، ولا يمتص شيء من الأشعة المرئية ، لذلك $t=0$

3- Black body :

$$\alpha=1 \quad r=0$$

4- Gray body

$$0 < \alpha < 1$$

* Absorptivity similar to emissivity

• Hemispherical absorptivity α

• Spectral hemispherical absorptivity α_λ

$$\alpha = f(T_{\text{source}}, \text{Material } \lambda)$$

معامل الامتصاص α يعتمد على درجة حرارة المصدر وخصائص المادة

* Gray body Approximation :

في الحالة العامة ϵ و α هما دالتان لـ λ و T و λ هو الطول الموجي و T هي درجة الحرارة.

في حالة الجسم الرمادي (Gray body) $\epsilon = \alpha$ و ϵ و α هما دالتان لـ λ و T و λ هو الطول الموجي و T هي درجة الحرارة.


$$\text{Gray body} \neq P(1)$$

* Relation between ϵ & α

after equilibrium :

$$T_{\text{body}} = T_{\text{enclosure}}$$

sphere & body في حالة التوازن (Solvent)



hollow sphere

$I \Rightarrow$ The intensity of radiation falling upon the body A_1 .

at conc T

الطاقة الإشعاعية الساقطة على الجسم

$E_1 \Rightarrow$ The total emissive power by the body.

الطاقة الإشعاعية الكلية المنبعثة من الجسم



The energy emitted by the body A_1 = The energy received.

$$E_1 A = I \alpha_1 A$$


$$E_1 = I \alpha_1$$

for black body $\alpha = 1$

* Radiation Intensity: شدة الإشعاع





The surface is very smooth
 θ of incidence = θ of Reflection



في (نظام إحداثيات) ثلاثي الأبعاد $\vec{r}$ في $\vec{i}$ $\vec{j}$ $\vec{k}$
 hemispherical coordinate system

* Mathematical Definitions:



في solid angle ω $\vec{r}$ $\vec{i}$ $\vec{j}$ $\vec{k}$
 spherical coordinate ω
 system.

* Radiation Intensity, I

$$I(\lambda, \theta, \phi) = \frac{dq}{dA_1 \cos \theta \cdot d\omega \cdot d\lambda}$$

I are depend on:

- q
- Geometry (A)
- direction (θ)
- solid angle
- wave length

$$\frac{dq}{d\lambda} = dq_\lambda = I_{\lambda e}(\lambda, \theta, \phi) dA_1 \cos \theta d\omega$$


where: $(dq/d\lambda)$ dq_λ is the rate at which radiation of wavelength λ leaves dA_1 & passes through dA_n

But solid angle is:

$$d\omega = \sin \theta d\theta d\phi$$

Therefore, the heat flux from dA_1 becomes:


$$dq''_\lambda = I_{\lambda e}(\lambda, \theta, \phi) \cos \theta \sin \theta d\theta d\phi$$



* Hemispherical direction:

$\theta \Rightarrow$ من الزوايا متزاوج من
 $0 \rightarrow \frac{\pi}{2}$

$\phi \Rightarrow$ متزاوج من $0 \rightarrow 2\pi$



$$E_{\lambda}(\lambda) = q''_{\lambda}(\lambda) = \int_0^{2\pi} \int_0^{\pi/2} I_{\lambda e} \cos \theta \sin \theta d\theta d\phi$$

* The total hemispherical emissive power, E (W/m^2) is the rate at which radiation is emitted per unit area at all possible wavelengths and in all possible directions:

السلطة الإشعاعية الكلية = كمية الطاقة المنبعثة من وحدة المساحة في جميع الاتجاهات وجميع الأطوال الموجبة

وهي القوة الإشعاعية الكلية لكل وحدة المساحة في جميع الاتجاهات وجميع الأطوال الموجبة

فإنها E هي القوة الإشعاعية الكلية لكل وحدة المساحة في جميع الاتجاهات وجميع الأطوال الموجبة

$$E = \int_0^{\infty} \int_0^{2\pi} \int_0^{\pi/2} I_{\lambda e}(\lambda, \theta, \phi) \cos \theta \sin \theta d\theta d\phi d\lambda$$



* Suppose a diffuse surface (emitted radiation is independent of direction), intensity, I_e , doesn't depend on direction θ and $\phi \Rightarrow I_{e, \lambda}(\lambda, \theta, \phi) = I_{e, \lambda}(\lambda)$. Hence, the previous eq. becomes:


$$E = \pi I_e$$

Direction λ is independent of Diffuse surface λ و I_e مستقل على الاتجاه
 E هو الإشعاع الكلي في الاتجاه λ
 $E = \int_0^{2\pi} \int_0^\pi I_e \cos\theta \sin\theta d\theta d\phi$ و I_e مستقل على الاتجاه
 $E = I_e \int_0^{2\pi} \int_0^\pi \cos\theta \sin\theta d\theta d\phi$ و I_e مستقل على الاتجاه

* The constant in the above equation is π and not 2π and has the unit **steradians** radians & degree $\rightarrow$ solid angle $\rightarrow$ وحدة الزاوية الصلبة

* ex: A small surface of area $A_1 = 10^{-3} \text{ m}^2$ is known to emit diffusely, and from measurements the total intensity associated with emission in the normal direction is $I_n = 7000 \text{ W/m}^2 \cdot \text{sr}$.

* Radiation emitted from the surface is intercepted by 3 other surfaces of Area $A_2 = A_3 = A_4 = 10^{-3} \text{ m}^2$, which are 0.5 m from A_1 and are oriented as shown.



what is the intensity associated with emission in each of the three directions ? what are the solid angles subtended by the three surfaces when viewed from A_1 ? what is the rate at which radiation emitted by A_1 is intercepted by the the three surfaces ?

* الإشعاع الخارج من A_1 يتم إبعاده بواسطة A_2, A_3, A_4

- نسبة الإشعاع في كل اتجاه من الاتجاهات الستة !؟

- Solid angle عند نقطة من A_1 !؟

- معدل الإشعاع المنبعث من A_1 !؟

a) Diffuse surface $\Rightarrow$ السطح ذو الإشعاع المنتظم (كثيرة)

$$\therefore I = 7000 \text{ W/m}^2 \cdot \text{sr}$$

Continue ---




* General comment :

The Net heat transfer between Two surfaces :

$$Q_{net} = A_1 \sigma (T_2^4 - T_1^4)$$

black body $\epsilon = 1$

- If T_1 is more than T_2 , the black body cools down, because the net loss of heat until T_1 and T_2 are equal.



قوة الجاذبية 2 ← 1 في اتجاه واحد

قوة الجاذبية

Black body inside

- If T_1 is less than T_2 , net heat will added to the black body until T_1 & T_2 are again equal.

another black body

* Note:

for gray body inside another gray body

$$Q_{net} = A_1 \epsilon_1 \sigma T_1^4 - A_1 \alpha_1 \sigma T_2^4$$




Example 1

A small oxidized metal tube of diam = 2.5 cm and long = 60 cm, $T_s = 500$ K is in a very large furnace enclosure with fire-brick walls and surrounding air at 1100 K. Assume oxidized metal tube emissivity = 0.75. Calculate the heat transfer to the metal tube.

$$\begin{aligned}
 q &= h_r (T_{\text{sur}} - T_s) \\
 &= \epsilon \sigma (T_{\text{sur}}^4 - T_s^4) \cdot A \\
 &= 0.75 \times 5.67 \times 10^{-8} \frac{\text{W}}{\text{m}^2 \cdot \text{K}^4} (1100^4 - 500^4) \times \pi \times 0.025 \text{ m} \times 0.6 \text{ m} = 28.087 \text{ kW}
 \end{aligned}$$

Schematic



Example 2

Recalculate Example 1 for combined radiation plus natural convection to the

في المثال الأول نحتاج إلى h_{conv} و h_{rad} *

نحتاج إلى معرفة regime هل laminar or turbulent *

نحتاج إلى معرفة geometry & regime ، من أجل Nu ، Gr ، Pr ، h_{conv} *

$$Pr = \frac{\mu}{\rho \alpha} = 0.728$$

نحتاج إلى معرفة Gr و Nu من خلال h_{conv} *

نحتاج إلى معرفة h_{conv} من خلال Gr و Nu من خلال h_{conv} *

Note: Simplified Equations for Natural Convection from Various Surfaces

		Equation	
Physical Geometry	$N_{Gr} N_{Pr}$	$h = \text{btu/h} \cdot \text{ft}^2 \cdot ^\circ\text{F}$ $L = \text{ft}, \Delta T = ^\circ\text{F}$ $D = \text{ft}$	$h = \text{W/m}^2 \cdot \text{K}$ $L = \text{m}, \Delta T = \text{K}$ $D = \text{m}$
Air at 101.32 kPa (1 atm) abs pressure			
Vertical planes and cylinders	$10^4 - 10^9$	$h = 0.28(\Delta T/L)^{1/4}$	$h = 1.37(\Delta T/L)^{1/4}$
	$> 10^9$	$h = 0.18(\Delta T)^{1/3}$	$h = 1.24 \Delta T^{1/3}$
Horizontal cylinders	$10^3 - 10^9$	$h = 0.27(\Delta T/D)^{1/4}$	$h = 1.32(\Delta T/D)^{1/4}$
	$> 10^9$	$h = 0.18(\Delta T)^{1/3}$	$h = 1.24 \Delta T^{1/3}$
Horizontal plates			
Heated plate facing upward or cooled plate facing downward	$10^5 - 2 \times 10^7$	$h = 0.27(\Delta T/L)^{1/4}$	$h = 1.32(\Delta T/L)^{1/4}$
	$2 \times 10^7 - 3 \times 10^{10}$	$h = 0.22(\Delta T)^{1/3}$	$h = 1.52 \Delta T^{1/3}$
Heated plate facing downward or cooled plate facing upward	$3 \times 10^5 - 3 \times 10^{10}$	$h = 0.12(\Delta T/L)^{1/4}$	$h = 0.59(\Delta T/L)^{1/4}$
Water at 70°F (294 K)			
Vertical planes and cylinders	$10^4 - 10^9$	$h = 26(\Delta T/L)^{1/4}$	$h = 127(\Delta T/L)^{1/4}$
Organic liquids at 70°F (294 K)			
Vertical planes and cylinders	$10^4 - 10^9$	$h = 12(\Delta T/L)^{1/4}$	$h = 59(\Delta T/L)^{1/4}$

example 2

$Gr \Rightarrow$ Grashof number

$$Gr = g \beta \frac{(T_{wall} - T_{\infty}) L^3}{\nu^2}$$

$g \Rightarrow$ gravity acceleration

$\beta \Rightarrow \frac{1}{T_{\infty}}$ for T_{∞} in K

$T_{\infty} \Rightarrow$ bulk temperature

$\nu \Rightarrow$ kinematic viscosity

ν for air at $1100 \text{ K} = 141.8 \times 10^{-6} \text{ m}^2/\text{s}$

$$Gr = 9.8 \frac{\text{m}}{\text{s}^2} \times \frac{1}{1100 \text{ K}} \times \frac{(1100 - 500) \text{ K} \times 0.6^3 \text{ m}^3}{(141.8 \times 10^{-6} \text{ m}^2/\text{s})^2}$$

$$Gr = 5.7423 \times 10^7$$

$$Gr \times Pr = 4.18 \times 10^7$$

$$h_{conv} = 1.32 (\Delta T / D)^{1/4} = 1.32 (600 / 0.25)^{1/4}$$

$$h_{conv} = 16.42 \text{ W/m}^2 \cdot \text{K}$$

$$q''_{conv} = h (T_{\infty} - T_w) = 16.42 \frac{\text{W}}{\text{m}^2 \cdot \text{K}} (1100 - 500) \text{ K} = 9852 \frac{\text{W}}{\text{m}^2}$$


$$q_{conv} = q''_{conv} \times A = 9852 \frac{\text{W}}{\text{m}^2} \times \pi (0.25 \text{ m}) \times 0.6 \text{ m} = 464.26 \text{ W}$$

$$q_{tot} = q_{rad} + q_{conv} = 28.087 + 464.26 \text{ kW} = 28.55 \text{ kW}$$

ask ; believe & recieve

Example 3

A light bulb radiates like a black body at 2800 K. find the percentage of total emitted energy that lies in the visible range.



Example 3:


$$T_s = 2800 \text{ K}$$

Find the percentage of total emitted energy from $(.4 - .7) \mu\text{m}$

black body radiation plot is given as function

visible range

$$\int_{\lambda_1 - \lambda_2} f(\lambda, T) = \int_{0 - \lambda_2} f(\lambda, T) - \int_{0 - \lambda_1} f(\lambda, T)$$



$$\int_{.4 - .7} f(\lambda, T) = \int_{0 - .7} f(\lambda, T) - \int_{0 - .4} f(\lambda, T)$$

$$\lambda_1 T = .4 \times 2800 = 1120 \mu\text{m} \cdot \text{K}$$

$$\lambda_2 T = .7 \times 2800 = 1960 \mu\text{m} \cdot \text{K}$$

use table 1.2

$f_{0-.7}$ & $f_{0-.4}$


$$f_{.4-.7} = \underset{\substack{\text{by interpolation}}}{.0612506} - \underset{\substack{\text{interpolation}}}{.002134} = \underset{\substack{\text{percentage of total emitted}}}{.0591166}$$

$$\begin{aligned} \text{quantity emitted} &= .0591166 \times 5.67 \times 10^{-8} \frac{\text{W}}{\text{m}^2 \cdot \text{K}^4} \times (2800)^4 \text{ K}^4 \\ &= 206.027 \frac{\text{W}}{\text{m}^2} \end{aligned}$$


ask :: believe & recieve

* Types of Bodies:


1. **Opaque body:** no transmission of electromagnetic radiation is possible. $t=0$, $\alpha + r = 1$



2. **White body:** Any body whose surface reflects incident rays of radiation. $\alpha = 0$, $r = 1$



3. **Black body:** $\alpha = 1$, $r = 0$



4. **Gray body:** $0 < \alpha < 1$

كل جسم يمتص بعض الإشعاع
كل جسم ينعكس بعض الإشعاع
بعض الإشعاع لا ينعكس ولا يمتص

$$E_1 A_1 = I \alpha_1 A_1$$

$$\therefore E_1 = I \alpha_1$$

فصلين لـ I في جوف الفلقة المستطيلة
لذلك يجب على شدة الإشعاع المسقط على الجسم
(1) ...

- If the body is replaced by another of identical shape and equil. is again attained

الاجسام في الجسم وليس شدة الإشعاع

$$\therefore E_2 = I \alpha_2$$

لأن I ثابت
(2) ...

- Now, If a blackbody is placed instead of the later


$$\therefore E_b = I$$

because $\alpha = 1$

(3) ...

ask :: believe & recieve

Application



$$\rho = 1 - \alpha$$

- مقدار از سطح ۲ طاقت مقدار E_1 ، احتیای سطح ۲

بزرگ E_1 تصادفی (E_1, α_2) ، وارد تا بقیه به طاقت

بعد از $\rho_2 E_1$ ، تا بقیه به طاقت $(\rho_2 E_1) = (1 - \alpha_2) E_1$

- احتیای سطح ۱ تا ارد به سطح ۲ مقدار طاقت $(\alpha_1 \rho_2 E_1)$ ، بعد به ارد تا بقیه به طاقت

و هكذا $(\rho_1 \rho_2 E_1) = ((1 - \alpha_1) \rho_2 E_1)$


For Gray Surfaces with zero transmissivity;

and $\rho = 1 - \alpha = 1 - \epsilon$
 $E = \epsilon \sigma T^4$

$\Rightarrow 1 - \alpha = 1 - \epsilon$

$\boxed{\alpha = \epsilon}$ at equilibrium

$\therefore \text{Net } \frac{q_{1-2}}{A} = \frac{\overset{\alpha_2}{\epsilon_2} \overset{E_1}{\epsilon_1} \sigma T_1^4 - \overset{\alpha_1}{\epsilon_1} \overset{E_2}{\epsilon_2} \sigma T_2^4}{1 - (1 - \epsilon_1)(1 - \epsilon_2)}$



$= \frac{\epsilon_2 \epsilon_1 [\sigma (T_1^4 - T_2^4)]}{1 - 1 + \epsilon_2 + \epsilon_1 - \epsilon_1 \epsilon_2}$

$= \frac{\sigma (T_1^4 - T_2^4)}{\frac{1}{\epsilon_1} + \frac{1}{\epsilon_2} - 1}$


$\text{Net } \frac{q_{1-2}}{A}$

for parallel plate

$\frac{1}{\epsilon_1} + \frac{1}{\epsilon_2} - 1$

ask I believe & receive

* Example: The bottom of a copper pan, 0.3 m in diameter, is maintained at 118°C by an electric heater. Estimate the power required to boil water in this pan. what is the evaporation rate? Estimate the critical heat flux.



في الشكل عرفت ان Pool boil في
tubes or pipes

* لندم احسب ΔT_e واربع على chart ونعرف المنطقة التي نرج استعمل عليها

$$\Delta T_e = T_s - T_{\text{sat}} = 118 - 100 = 18^\circ\text{C}$$

في chart عرفت اني في Nucleate boiling

$\Delta T_e = 5 \rightarrow 10 \Rightarrow$ Bubbles collapse

$\Delta T_e = 10 \rightarrow 30 \Rightarrow$ Bubbles rise to the free surface

هذه المنطقة المذكورة في السؤال

* اختيار correlation ونطبق حسب q ثم $m = \frac{q}{h_{fg}}$

بدرج من معادلات q_{max} حسب المطلوب انظر

$$1) \quad q'' = M_L h_{fg} \left[\frac{g(\rho_l - \rho_v)}{\sigma} \right]^{1/2} \left[\frac{C_{p,l}(T_s - T_{\text{sat}})}{C_{p,l} h_{fg} Pr_l^n} \right]^{1/4}$$

heat flux $\Rightarrow$ heat في A عتبار A في q''

$$A = \frac{\pi D^2}{4}$$

* All properties at T_{sat}

$$\Delta T_e = 118 - 100 = 18^\circ\text{C} \quad \text{so Nucleate boiling}$$

all properties at 100°C (373 K)

$$\mu_L = 279 \times 10^{-6} \text{ N}\cdot\text{s}/\text{m}^2$$

$$h_{fg} = 2257 \text{ kJ/kg}$$

$$\rho_L = \frac{1}{v} = \frac{1}{1.044 \times 10^{-3}} = 957.85 \text{ kg/m}^3$$

$$\rho_v = \frac{1}{v} = \frac{1}{1.679} = 0.5956 \text{ kg/m}^3$$

$$\sigma = 58.9 \times 10^{-3} \frac{\text{N}}{\text{m}}$$

$$C_{p_L} = 4.217 \text{ kJ/kg}\cdot\text{K}$$

$$Pr = 1.76$$

From table find $C_{s,f} = 0.0128$ & $n=1$

$$q = 279 \times 10^{-6} \times \frac{2257}{\cancel{4.217}} \left(\frac{9.8 (957.85 - 0.5956)}{58.9 \times 10^{-3}} \right)^{1/2} \left(\frac{4.217 (118 - 100)}{0.0128 \times 2257 \times 1.76} \right)^3$$

$$q'' = 836.12 \frac{\text{kW}}{\text{m}^2}$$

$$\Rightarrow \text{Power} = q'' A = q'' \frac{\pi D^2}{4} = 836.12 \frac{\text{kW}}{\text{m}^2} \times \frac{\pi}{4} (0.3)^2 \text{ m}^2$$

$$\Rightarrow \text{Power} = 59.1 \text{ kW}$$

$$q = m h_{fg}$$


$$\Rightarrow m = \frac{q}{h_{fg}} = \frac{59.1 \text{ kW}}{2257 \text{ kJ/kg}} = 0.026 \frac{\text{kg}}{\text{s}}$$

3 Critical heat flux

$$q_{\max} = \frac{\pi}{24} h_{fg} \rho_L \left(\frac{\sigma g (\rho_L - \rho_v)}{\rho_L^2} \right)^{1/4} \left(\frac{\rho_L + \rho_v}{\rho_L} \right)^{1/2}$$

في الجدول الخاص بخواص السوائل

View Factor Concept




view factor $\Rightarrow$ كيف تنظر لك من هنا
size of surface & Orientation $\Leftarrow$ من هنا

Introduction

- Radiation Between surfaces are strongly affected by :
 - a. Orientation
 - b. size of the surfaces relative to each other.
- In order to formulate the effects of orientation in the analysis of radiation heat exchange among surfaces, the concept of view factor must be considered.

- View Factor ~ Shape Factor ~ angle Factor ~ Configuration Factor have been used in literature.




view factor $\Rightarrow$ fraction $\Rightarrow$ مقدار الطاقة التي وصلت جسم معين $\Rightarrow$ نسبة المساحة التي انبعتج من السطح

Orientation

- We are going to consider only **the surfaces of diffuse emitters and diffuse reflectors**. (Diffuse view factor)
Thus, we simply use the term view factor, and it will imply the diffuse view factor.
- The physical significance of the view factor:
The view factor between two surfaces represents the fraction of the radiative energy leaving one surface that strikes the other surface directly.

View factor definition



View Factor Derivation

$$dq_{1-2} = I \cos \theta_1 dA_1 dw_{2-1} \dots (1)$$

solid angle $\frac{d\omega}{2-\pi} = \frac{\cos \theta_2 dA_2}{r^2}$ (2)

But for black surface

$$I = \frac{E}{\pi} = \frac{\sigma T_1^4}{\pi} \dots (3)$$

Substituting eq. 2 and 3 in 1, we obtain

$$dq_{1-2} = \frac{\sigma T_1^4 \cos \theta_1 \cos \theta_2 dA_1 dA_2}{\pi L^2} \dots \dots (4)$$

- Following the same procedure, we can write

$$q_{1 \rightarrow 2} \text{ radiation from } T_1 \text{ to } T_2 = \frac{\sigma T_1^4}{\pi} \frac{\cos \theta_1 \cos \theta_2 dA_1 dA_2}{L^2} \dots (5)$$

- The net of radiation between dA_1 and dA_2 is

$$dq_{1 \rightarrow 2} = dq_{1 \rightarrow 2} - dq_{2 \rightarrow 1} \dots (6)$$

$$= \sigma (T_1^4 - T_2^4) \frac{\cos \theta_1 \cos \theta_2 dA_1 dA_2}{\pi L^2} \dots (7)$$


On a per unit area basis

$$\frac{dq_{1 \rightarrow 2}}{dA_1} = \sigma (T_1^4 - T_2^4) \underbrace{\frac{\cos \theta_1 \cos \theta_2 dA_2}{\pi L^2}}_{\text{View factor, } F_A} \dots (8)$$

length & area

The elemental View Factor

$dF \Rightarrow$ differential



Definition: The elemental View Factor

The elemental view factor $dF_{dA_1-dA_2}$, by definition, is the ratio of the radiative energy leaving dA_1 that strikes dA_2 directly to the radiative energy leaving dA_1 in all directions into the hemispherical space. It is given by

$$dF_{dA_1-dA_2} = \frac{\cos \theta_1 \cos \theta_2 dA_2}{\pi r^2}$$

The elemental view factor $dF_{dA_2-dA_1}$ from dA_2 to dA_1 is now immediately obtained from previous eq. by interchanging subscripts 1 and 2. We find

$$dF_{dA_2-dA_1} = \frac{\cos \theta_1 \cos \theta_2 dA_1}{\pi r^2}$$

Reciprocity Relation

- The reciprocity relation between the view factors $dF_{dA_1-dA_2}$ and $dF_{dA_2-dA_1}$ of the previous two Eqs. is :

$$dA_1 dF_{dA_1-dA_2} = dA_2 dF_{dA_2-dA_1}$$

area 1 × view factor = area 2 × view factor

- The view factors between surfaces A_i and A_j of the enclosure obey the following relation:

$$A_i F_{A_i \rightarrow A_j} = A_j F_{A_j \rightarrow A_i}$$

- Summation relation

$$\sum_{k=1}^N F_{A_i \rightarrow A_k} = 1$$

سواء $F_{A_i \rightarrow A_k}$ عبارة
fraction


Note

$F_{A_i \rightarrow A_i} = 0$	$\text{if } A_i \text{ plane or convex} \rightarrow$	مستوي
$F_{A_i \rightarrow A_i} \neq 0$	$\text{if } A_i \text{ concave} \Rightarrow$	مقعور

by correlation or chart ? view-factor

View-Factor Determination

- Equations were derived for simple shapes. These expressions given in tables. correlation
- Graphs for simple configurations.
- Note: View factor Algebra



$$F_{i-j} = F_{i-1} + F_{i-2} \dots F_{i-n}$$

$$A_i F_{i-j} = A_1 F_{1-j} + A_2 F_{2-j} \dots A_n F_{n-j}$$

Use reciprocity relation

$$A_j F_{j-i} = A_1 F_{1-i} + A_2 F_{2-i} + \dots + A_n F_{n-i}$$

$$F_{j-i} = [A_1 F_{1-i} + A_2 F_{2-i} + \dots + A_n F_{n-i}] / A_j$$

$$F_{j-i} = [A_1 F_{1-i} + A_2 F_{2-i} + \dots + A_n F_{n-i}] / [A_1 + A_2 + \dots + A_n]$$

Areas used to illustrate view factor relations.

View Factors for Three-Dimensional Geometries


Geometry

Relation

Aligned Parallel Rectangles

$$\bar{X} = X/L, \bar{Y} = Y/L$$


(Figure A)



$$F_{ij} = \frac{2}{\pi \bar{X} \bar{Y}} \left\{ \ln \left[\frac{(1 + \bar{X}^2)(1 + \bar{Y}^2)}{1 + \bar{X}^2 + \bar{Y}^2} \right]^{1/2} + \bar{X}(1 + \bar{Y}^2)^{1/2} \tan^{-1} \frac{\bar{X}}{(1 + \bar{Y}^2)^{1/2}} + \bar{Y}(1 + \bar{X}^2)^{1/2} \tan^{-1} \frac{\bar{Y}}{(1 + \bar{X}^2)^{1/2}} - \bar{X} \tan^{-1} \bar{X} - \bar{Y} \tan^{-1} \bar{Y} \right\}$$

Coaxial Parallel Disks

(Figure B)




$$R_i = r_i/L, R_j = r_j/L$$

$$S = 1 + \frac{1 + R_j^2}{R_i^2}$$

$$F_{ij} = \frac{1}{2} \{ S - [S^2 - 4(R_j/r_i)^2]^{1/2} \}$$

Perpendicular Rectangles with a Common Edge

(Figure C)




$$H = Z/X, W = Y/X$$

$$F_{ij} = \frac{1}{\pi W} \left\{ W \tan^{-1} \frac{1}{W} + H \tan^{-1} \frac{1}{H} - (H^2 + W^2)^{1/2} \tan^{-1} \frac{1}{(H^2 + W^2)^{1/2}} + \frac{1}{4} \ln \left\{ \frac{(1 + W^2)(1 + H^2)}{1 + W^2 + H^2} \left[\frac{W^2(1 + W^2 + H^2)}{(1 + W^2)(W^2 + H^2)} \right]^{W^2} \times \left[\frac{H^2(1 + H^2 + W^2)}{(1 + H^2)(H^2 + W^2)} \right]^{H^2} \right\} \right\}$$

Common edge
"هم جدار"

استفاده از chart




aligned rectangles.

if F_{12} & F_{14} given find F_{31} ?


$\frac{2}{1} \times \frac{1}{1} = \frac{1}{1}$ $\frac{4}{1} \times \frac{1}{1} = \frac{1}{1}$

$$F_{13} = F_{12} - F_{14}$$

$$\Rightarrow F_{31} = \frac{A_1}{A_3} (F_{12} - F_{14}) \quad \text{given} \quad \#$$



کتاب کی قیمت FAB سے بڑھتی ہے اور chart سے کم ہے
+ chart استعمال کے بعد chart سے بڑھتی ہے اور chart سے کم ہے
اسی لیے ان کے درمیان فرق ہے FAB سے بڑھتی ہے اور chart سے کم ہے



F₄₅

$$F_{12} \quad \text{or} \quad F_{(3+4)-(5+6)}$$

بقدر الظاهر بسببها

↳ une PD peut être chartée
(commun)

F_{63} area دے دیں $F_{36} + F_{46}$ ہر ایک کی

$$F(3+4)-(5+6) = F(3+4)-5 + F(3+4)-6$$

$$= F(3+4)-5 + \frac{A_6}{A_3+A_4} (F_{63} + F_{64})$$

$$F_{63} = \left(F(3+4)-(5+6) - F(3+4)-5 \right) \frac{A_3+A_4}{A_6} F_{6-4} \dots$$

F_{64} کی جگہ F_{6-4} دے دیں

$$(A_5+A_6) F(5+6)-4 = A_5 F_{54} + A_6 F_{64}$$

$$F_{64} = \frac{A_5+A_6}{A_6} F(5+6)-4 - \frac{A_5}{A_6} F_{54}$$

بعض باتوں پر

F_{63} کی جگہ

دے دیں :

$$F(3+4)-5$$

